Web-Tech Australia Pty Ltd

Model WT1200 Weighfeeder

Installation, Operation & Maintenance Manual

Web-Tech Australia Pty Ltd
PO Box 4006
11 Electronics St
Eight Mile Plains QLD 4113
Ph: 61 7 3841 2844
Fax: 61 7 3841 0005
e-mail: webtech@bigpond.com

Web-Tech Australia Pty Ltd

TABLE OF CONTENTS

Section	Description
1.	Introduction.
2.	Delivery & Unpacking.
3.	Mechanical Installation.
4.	Electrical Installation
5.	Weighfeeder Electronics
6.	Calibration
7.	Gearmotor Manual
8.	Variable Speed Drive Manual (if applicable)
9.	Drawings
10.	Calibration Sheets/Addendums

SECTION 1 - INTRODUCTION

The Web-Tech model 1200 weighfeeders consist of a range of light to medium duty weighfeeders capable of handling various products. The model number extension eg. “300” denotes the belt width. Therefore a 1200-300 is a model 1200 with a belt width of 300mm. Web-Tech has selected a belt width based on the operating parameters supplied to us. Standard belt widths are 300mm, 450mm, 600mm, 750mm, 900mm and 1200mm.

The model WT1200 is available in either “open” or “enclosed” construction. Apart from the enclosure, the mechanical aspects are the same for both types. For open construction models, the weighfeeder may be supplied with an inlet chute with flange connection, or, with a “horseshoe” type inlet which consists of side and rear skirts. Enclosed construction models are supplied with internal inlet chutes. The inlet chute flange may be bolted directly to the outlet of a bin, however it is not designed to support any loads. This may happen for example if the bin is supported by a structure that can deflect when fully loaded. If this is the case a flexible connection should be used.

The weighfeeder dimensional layout and capacity have been determined by information supplied to Web-Tech at the product enquiry stage. Some 1200 weighfeeders may change in overall dimensions and/or supply of ancillaries to suit the operational requirements. Should your weighfeeder vary from the standard design, an addendum will have been inserted in this manual to reflect the changes.

If there are any questions regarding any aspect of the weighfeeder design or installation, please do not hesitate in contacting Web-Tech for clarification **before** placing the weighfeeder into operation. The weighfeeder is generally programmed and calibrated in our factory prior to dispatch, however the weighfeeder will need to have the calibration re-checked after installation. The calibration sheets are located at the rear of this manual.

PLEASE READ ALL SECTIONS OF THE MANUAL BEFORE PLACING THE WEIGHFEEDER INTO SERVICE.

SECTION 2 – DELIVERY & UNPACKING

Your weighfeeder has been crated for protection during transit. The weighfeeder electronics is normally packed separately in secure cardboard packaging. Upon delivery, please inspect all packaging for signs of damage. Report any damage to both the transport company and Web-Tech.

The basic components are:

- Assembled weighfeeder c/w gearmotor, load cell(s) and belt speed sensor.
- Masterweigh/Optimus electronics.
- Calibration chain/weights.

Optional:

- Variable Speed Controller.
- Remote Instruments.
- Spare Parts.

If in any doubt regarding any aspect of the delivery, contact:

Web-Tech Australia Pty Ltd
Ph: 61 7 3841 2844
Fax: 61 7 3841 0005
Email: webtech@bigpond.com

UNPACKING

1. Carefully open the crate.
2. The weighfeeder is held in place by bolts in the mounting feet.
3. Remove the bolts and lift the weighfeeder clear of the crate using web slings – **NOT CHAINS**.
4. Ensure no parts have come loose during transit.
5. Carefully transport the weighfeeder to point of installation.
6. Open the cardboard box containing the electronics. Remove the electronics and check box for any remaining items.
7. Check electronics enclosure for any obvious damage.
8. Proceed to Mechanical and Electrical installation sections.

PLEASE READ ALL SECTIONS OF THE MANUAL BEFORE PLACING THE WEIGHFEEDER INTO SERVICE.

SECTION 3 – MECHANICAL INSTALLATION

Refer to the general arrangement drawing at the rear of the manual.

OPEN CONSTRUCTION WITH INLET CHUTE MODEL

The following is a summary of works required for the mechanical installation of an "open" construction model WT1200 weighfeeder which is supplied with an inlet chute.

1. For high vibration areas the weighfeeder will be supplied with isolation blocks (loose supply). Locate these blocks and bolt them to the weighfeeder support feet.
2. Cover the weighfeeder if any metal cutting is to be performed. If any welding is to be carried out, remove the load cell from the weighfeeder.
3. Locate the weighfeeder on the support structure ensuring correct alignment. The structure must be sufficiently rigid to eliminate any deflection due to the weight of the weighfeeder and the product it's transporting.
4. Level the weighfeeder by placing a spirit level across and along the weighfeeder belt/structure. Any vertical alignment should be compensated for by using shim material under the support structure or weighfeeder isolation blocks/mounting feet. **DO NOT "PULL UP" ANY GAPS BY USING THE MOUNTING BOLTS AS THIS MAY TWIST THE WEIGHFEEDER FRAME.** The weighfeeder should be level in both directions to $\pm 1^0$.
5. If the weighfeeder is to be bolted directly to an overhead bin, a flexible gasket should be used between the bin and weighfeeder flanges. The thickness of the gasket should be sufficient to take-up and variation in gap that may exist between the two flanges.
6. Carefully tighten the flange bolts so that the gasket is compressed and the gap is completely closed. **DO NOT OVERTIGHTEN THE CONNECTION BOLTS SO THAT THE FLANGE IS BENT**.
7. If a flexible connection is to be used, ensure that any excess in the flexible material does not create a ledge, or restrict the flow of material from the outlet of the bin.
8. Locate and remove the gravity take-up transit bolt. The transit bolt head will have been painted red for easy identification. Refer to drawing "WT1200-021" for location. Carefully lower the gravity take-up roll down onto the return belt.
9. Refer to drawing "WT1200-031". This drawing will show that the load cell is fitted with an overload bolt. On belt widths up to 750mm, one load cell is used. On wider belt widths, two load cells are used (one per side). These bolts have been factory set and should not be altered. One each of these bolts there is a red transit nut. During transit, these nuts should be tightened upwards against the bottom of the load cell. Before operation these nuts should be lowered to the bottom of the overload bolts as shown on the drawing. **MAKE SURE THAT THE OVERLOAD BOLTS ARE NOT MOVED WHEN ADJUSTING THE TRANSIT NUTS.**
10. Before placing into operation, the alignment of the weigh bar should be checked. Referring to drawing "WT1200-031", locate the weigh bar position. Place a straight edge along each edge of the carry bars and check the height of the weigh bar. The weigh bar should with respect to the approach and retreat bars to a tolerance of +0.25mm/-0.00mm. If the weigh bar requires adjustment, remove the plastic plug in the end of the weigh bar and adjust the grub screw. When finished replace the plastic plugs.
11. The mechanical installation is now complete; proceed to the electrical installation section.

OPEN CONSTRUCTION WITH "HORSESHOE" INLET MODEL

The following is a summary of works required for the mechanical installation of an "open" construction model WT1200 weighfeeder which is supplied with a "horseshoe" inlet.

SECTION 3 – MECHANICAL INSTALLATION

1. For high vibration areas the weighfeeder will be supplied with isolation blocks (loose supply). Locate these blocks and bolt them to the weighfeeder support feet.
2. Cover the weighfeeder if any metal cutting is to be performed. If any welding is to be carried out, remove the load cell from the weighfeeder.
3. Locate the weighfeeder on the support structure ensuring correct alignment. The structure must be sufficiently rigid to eliminate any deflection due to the weight of the weighfeeder and the product it's transporting.
4. Level the weighfeeder by placing a spirit level across and along the weighfeeder belt/structure. Any vertical alignment should be compensated for by using shim material under the support structure or weighfeeder isolation blocks/mounting feet. **DO NOT "PULL UP" ANY GAPS BY USING THE MOUNTING BOLTS AS THIS MAY TWIST THE WEIGHFEEDER FRAME.** The weighfeeder should be level in both directions to $\pm 1^0$.
5. The use of the "horseshoe" style inlet allows for a chute, metering tube or a pre-feeder such as a vibratory feeder to be used. If using a chute or metering tube, ensure that the bottom of the chute/metering tube does not interfere with the belt.
6. If the bottom of the chute/metering tube is fitted with skirts, ensure that excessive load is not placed on the belt. The skirts should just be in contact with the belt.
7. If the weighfeeder is to be supplied with a pre-feeding device such as a vibratory feeder, ensure that material is not deposited too far along the weighfeeder so that it is deposited on the weigh area (refer to the drawing for location of the product limits).
8. Locate and remove the gravity take-up transit bolt. The transit bolt head will have been painted red for easy identification. Refer to drawing "WT1200-021" or location. Carefully lower the gravity take-up roll down onto the return belt.
9. Refer to drawing "WT1200-031". This drawing will show that the load cell is fitted with an overload bolt. On belt widths up to 750mm, one load cell is used. On wider belt widths, two load cells are used (one per side). These bolts have been factory set and should not be altered. One each of these bolts there is a red transit nut. During transit, these nuts should be tightened upwards against the bottom of the load cell. Before operation these nuts should be lowered to the bottom of the overload bolts as shown on the drawing. **MAKE SURE THAT THE OVERLOAD BOLTS ARE NOT MOVED WHEN ADJUSTING THE TRANSIT NUTS.**
10. Before placing into operation, the alignment of the weigh bar should be checked. Referring to drawing "WT1200-031", locate the weigh bar position. Place a straight edge along each edge of the carry bars and check the height of the weigh bar. The weigh bar should with respect to the approach and retreat bars to a tolerance of +0.25mm/-0.00mm. If the weigh bar requires adjustment, remove the plastic plug in the end of the weigh bar and adjust the grub screw. When finished replace the plastic plugs.
11. The mechanical installation is now complete; proceed to the electrical installation section.

ENCLOSED CONSTRUCTION MODEL

The following is a summary of works required for the mechanical installation of an "enclosed" construction model WT1200 weighfeeder which is supplied with an internal inlet chute.

1. For high vibration areas the weighfeeder will be supplied with isolation blocks (loose supply). Locate these blocks and bolt them to the weighfeeder support feet.
2. Cover the weighfeeder if any metal cutting is to be performed. If any welding is to be carried out, remove the load cell from the weighfeeder.
3. Remove the side covers from the weighfeeder.
4. Locate the weighfeeder on the support structure ensuring correct alignment. The structure must be sufficiently rigid to eliminate any deflection due to the weight of the weighfeeder and the product it's transporting.
5. Level the weighfeeder by placing a spirit level across and along the weighfeeder belt/structure. Any vertical alignment should be compensated for by using shim

material under the support structure or weighfeeder isolation blocks/mounting feet. **DO NOT "PULL UP" ANY GAPS BY USING THE MOUNTING BOLTS AS THIS MAY TWIST THE WEIGHFEEDER FRAME.** The weighfeeder should be level in both directions to $\pm 1^0$.

6. If the weighfeeder is to be bolted directly to an overhead bin, a flexible gasket should be used between the bin and weighfeeder flanges. The thickness of the gasket should be sufficient to take-up and variation in gap that may exist between the two flanges.
7. Carefully tighten the flange bolts so that the gasket is compressed and the gap is completely closed. **DO NOT OVERTIGHTEN THE CONNECTION BOLTS SO THAT THE FLANGE IS BENT**.
8. If a flexible connection is to be used, ensure that any excess in the flexible material does not create a ledge, or restrict the flow of material from the outlet of the bin.
9. Connect the outlet of the weighfeeder using the same method i.e. use a flexible gasket.
10. Locate and remove the gravity take-up transit bolt. The transit bolt head will have been painted red for easy identification. Refer to drawing "WT1200-021" or location. Carefully lower the gravity take-up roll down onto the return belt.
11. Refer to drawing "WT1200-031". This drawing will show that the load cell is fitted with an overload bolt. On belt widths up to 750mm, one load cell is used. On wider belt widths, two load cells are used (one per side). These bolts have been factory set and should not be altered. One each of these bolts there is a red transit nut. During transit, these nuts should be tightened upwards against the bottom of the load cell. Before operation these nuts should be lowered to the bottom of the overload bolts as shown on the drawing. **MAKE SURE THAT THE OVERLOAD BOLTS ARE NOT MOVED WHEN ADJUSTING THE TRANSIT NUTS.**
12. Before placing into operation, the alignment of the weigh bar should be checked. Referring to drawing "WT1200-031", locate the weigh bar position. Place a straight edge along each edge of the carry bars and check the height of the weigh bar. The weigh bar should with respect to the approach and retreat bars to a tolerance of +0.25mm/-0.00mm. If the weigh bar requires adjustment, remove the plastic plug in the end of the weigh bar and adjust the grub screw. When finished replace the plastic plugs.
13. The mechanical installation is now complete; proceed to the electrical installation section.






GRAVITY TAKE UP IN SERVICE POSITION, USE SHIPPING PIN IN THIS HOLE REFER DETAIL A
GRAVITY STREERING DEVICE IN SERVICE POSITION
GRAVITY STEERING DEVICE IN OPERATING POSITION
RETURN BELT



DETAIL A

THREADED SHIPPING PIN
RETAIN FOR FUTURE
MAINTENANCE WORK

** NOTE **

THREADED SHIPPING PINS USED TO HOLD THE GRAVITY TAKE UP MECHANISM IN PLACE DURING TRANSIT. THIS PIN MUST BE RELEASED ONLY WHEN THE BELT IS IN PLACE, CARE MUST BE TAKEN WHEN RELEASING THIS PIN AS THE TAKE UP MECHANISM IS VERY HEAVY. SUPPORT THE ROLLER PRIOR TO RELEASING THE ROLL SO AS TO AVOID IT FALLING ON TO THE BASE OF THE FEEDER.

REVISIONS

A: 24/5/95 ORIGINAL ISSUE

DRAWN	T.B.
CHECKED	L.H.
APPROVED	L.H.
DATE APP'D	–
SCALE	N.T.S.
	DO NOT SCALE IF IN DOUBT ASK

WEB-TECH AUSTRALIA PTY. LTD.
A.C.N. 010 764 431
11 ELECTRONICS STREET EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA
P.O. BOX 4006 EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA
Phone +61-7-3841 2844 Fax +61-7-3841 0005

TITLE

MODEL WT1200 WEIGHFEEDER GRAVITY TAKE-UP SHIPPING BOLT.

ALL DIMENSIONS IN MILLIMETRES UNLESS OTHERWISE SPECIFIED

SIZE	DRAWING No.	REV.
A1	WT1200-021	A

CUSTOMER

PROJECT

CAD FILE
WT1200-021

This drawing and any information or descriptive matter set out hereon are the confidential and copyright property of WEB-TECH AUSTRALIA PTY. LTD. © and must not be disclosed, loaned, copied or used for manufacturing / tendering or for any other purpose without their written permission.



** NOTE **
WEIGH PLATFORM POSITION & HEIGHT
ARE FACTORY SET
AND MUST NOT BE ALTERED WITHOUT
SPECIFIC INSTRUCTION FROM
AUTHORISED WEBTECH PERSONNEL



WEIGHFRAME SIDE ELEVATION
SHOWING WEIGH PLATFORM IN
OPERATING POSITION



OVERLOAD PROTECTION BOLT GRUB SCREW,
FACTORY PRESET, DO NOT ALTER

OVERLOAD PROTECTION BOLT
OPERATING POSITION

REVISIONS
A: 24/5/95 ORIGINAL ISSUE

DRAWN	T.B.
CHECKED	L.H.
APPROVED	L.H.
DATE APP'D	–
SCALE	N.T.S.
	DO NOT SCALE IF IN DOUBT ASK

WEB-TECH AUSTRALIA PTY. LTD.
A.C.N. 010 764 431
11 ELECTRONICS STREET EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA
P.O. BOX 4006 EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA
Phone +61-7-3841 2844 Fax +61-7-3841 0005

TITLE
MODEL WT1200 WEIGHFEEDER
LOAD CELL OVERLOAD BOLT.

SIZE	DRAWING No.	REV.
A1	NUMBER WT1200–031	A

CUSTOMER
PROJECT
CAD FILE
WT1200-031

ALL DIMENSIONS IN MILLIMETRES
UNLESS OTHERWISE SPECIFIED

This drawing and any information or descriptive matter set out hereon are the confidential and copyright property of WEB-TECH AUSTRALIA PTY. LTD. © and must not be disclosed, loaned, copied or used for manufacturing / tendering or for any other purpose without their written permission.

SECTION 4 – ELECTRICAL INSTALLATION

Electrical connection diagrams for the weighfeeder electronics, load cell and belt speed sensor junction boxes are located in the drawing section of this manual. Electrical connection diagrams for the gearmotor and variable speed drive (if applicable) are located in the appropriate manufacturer's manuals. Electrical installation comprises the following work:

1. Install and connect weighfeeder electronics to mains supply.
2. Install and connect supply to weighfeeder motor (or via VSD if supplied).
3. Install and connect cable between load cell junction box and electronics.
4. Install and connect cable between belt speed sensor junction box and electronics.
5. Install and connect cable between weighfeeder electronics and variable speed drive (if supplied).
6. Install cable between weighfeeder electronics and PLC (if required).
7. Install earth strap to weighfeeder structure (refer G.A. drawing for location). The weighfeeder structure should be earthed to eliminate static build-up from the structure.

WEIGHFEEDER ELECTRONICS

The weighfeeder may be supplied with either of the following electronics models:

- "Masterweigh 1"
- "Masterweigh 5"
- "Optimus"

The appropriate electrical connection drawing or the electronics supplied is located in the drawings section of the manual.

Enclosure Mounting

The electronics enclosure is an IP66 reinforced fibre polyester enclosure, or optionally an IP66 stainless steel enclosure.

The enclosure should be located so that:

1. Is not in direct sunlight (install sunshield if located outdoors).
2. Is not subject to direct washdown.
3. Is not installed in close proximity to high power cables, variable speed drives or vibratory feeder controllers.
4. Not more than 100 metres from the weighfeeder. The closer the electronics can be located to the weighfeeder reduces the chances of electrical interference on the cables. It also makes it easier when carrying out calibrations and fault finding.

Cables

All cables between the load cell/belt speed sensor junction boxes and the electronics should be proper screened instrumentation quality. As the signal levels from these devices are very low, any cable runs between the weighfeeder and electronics should be carried out so that these cables are not installed close to power cables. Any cable runs should not interfere with the "access" side of the weighfeeder which may interfere with belt removal.

Suggested cable type for each application is as follows:

Load Cell – 4 core overall screened, Belden type 8723 or equivalent.

Belt Speed Sensor – 3 core overall screened, Belden type 8723 or equivalent.

VSD/Motor – To suit the motor power installed.

Ensure that all cable entries into the electronics enclosure and junction boxes use the correct size waterproof glands.

Cable Terminations

Load Cell junction box – Refer to drawing "LCJB" in the drawing section of the manual.

Speed sensor junction box – Refer to drawing "SSJBOX" in the drawing section of the manual.

As the model WT1200 weighfeeder is supplied with a variety of motor/VSD

combinations, it is beyond the scope of this manual to give installation/connection here. Please refer to the manufacturer's manuals in other sections of the manual.

START UP

Prior to turning on the equipment, or starting the weighfeeder, ensure the following has been done:

1. Double check all electrical connections are correct.
2. All mechanical installation has been completed and no tools have been left on the belt or in the inlet chute.
3. The rotation of the motor has been checked and wired correctly.

Start Up Steps

When starting up the system for the first time, use the following steps.

1. Turn on the electronics, and ensure it displays the Mass Rate, Mass Total (MRMT).
2. Start the weighfeeder. If using variable speed drive, set it in local and ramp the frequency up to 50Hz.
3. Ensure the belt is tracking centrally. If the belt is not tracking centrally, turn the weighfeeder off and check that the belt sitting correctly in the guides on the tracking system.
4. The load cell output can be directly read from the electronics. Refer to the electronics manual for the appropriate menu for reading the load cell voltage. Refer to the calibration sheets at the rear of the manual and compare the factory programmed voltage (mV) to the existing value. It should be within ±0.5mV.
5. The belt speed sensor output can be read directly from the electronics. Refer to the electronics manual for the appropriate menu for reading the belt speed sensor frequency output. Run the weighfeeder, refer to the calibration sheets at the rear of the manual and compare the factory programmed frequency (Hz) to the existing value. It should be within ±1Hz.

If all readings appear correct, proceed to the Calibration section of the manual.



NOTES

REVISIONS

A: 21/11/05
ORIGINAL ISSUE

B: 21/11/06
LOAD CELL WIRING CHANGED.

UNLESS OTHERWISE STATED UNTOLERANCED DIMENSIONS TO BE WITHIN THE LIMITS SHOWN						DRAWN	L.H.
NOMINAL SIZE	UP TO 50	ABOVE 50 UP TO 150	ABOVE 150 UP TO 300	ABOVE 300 UP TO 1000	ABOVE 1000	CHECKED	L.H.
						APPROVED	L.H.
MACHINING	± 0.1	± 0.2	± 0.3	± 0.5	± 1.0	DATE APP'D	21/11/05
FABRICATION	± 0.5	± 0.5	± 0.5	± 1.0	± 2.0	SCALE	N.T.S.
ASSEMBLIES	± 0.5	± 0.5	± 0.5	± 1.0	± 2.0		DO NOT SCALE IF IN DOUBT ASK

ALL DIMENSIONS IN MILLIMETRES UNLESS OTHERWISE SPECIFIED

WEB-TECH AUSTRALIA PTY. LTD.
A.C.N. 010 764 431
11 ELECTRONICS STREET EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA
P.O. BOX 4006 EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA
Phone +61-7-3841 2844 Fax +61-7-3841 0005

TITLE

MODEL WT735/1200/1700 WEIGHFEEDER
LOAD CELL JUNCTION BOX CONNECTION DIAGRAM.

SIZE	DRAWING No.		
	NUMBER	SHT.	REV.
A1	LCJBOX	1	B

CONTRACT

PROJECT

CAD FILE

This drawing and any information or descriptive matter set out hereon are the confidential and copyright property of WEB-TECH AUSTRALIA PTY. LTD.© and must not be disclosed, loaned, copied or used for manufacturing / tendering or for any other purpose without their written permission.

SPEED SENSOR (TACHO) JUNCTION BOX



CABLE SUPPLIED BY CUSTOMER. CABLE TO BE BELDEN 3 CORE PART No. 8770 OR EQUIVALENT

CABLE INTEGRAL TO TACHO

SPEED SENSOR (TACHO)



1 THE POSITION OF THE SLIDER SWITCH HAS BEEN FACTORY ADJUSTED AND DETERMINES THE OUTPUT OF THE TACHO. THIS SETTING SHOULD BE CHECKED AGAINST THE DATA SHEET PRIOR TO COMMISSIONING.

TO OPTIMUS ELECTRONICS

"TACHO1 – SCREEN"	SCREEN
"TACHO1–GROUND"	0V (GND)
"TACHO1–SUPPLY"	+5V SUPPLY
"TACHO1–SIG/Q1"	SIGNAL

REVISIONS

A: 18/7/06 ORIGINAL ISSUE

DRAWN	L.HARTLEY
CHECKED	L.HARTLEY
APPROVED	L.HARTLEY
DATE APP'D	18/7/06
SCALE	N.T.S
	DO NOT SCALE IF IN DOUBT ASK

WEB–TECH AUSTRALIA PTY. LTD.
A.C.N. 010 764 431
11 ELECTRONICS STREET EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA
P.O. BOX 4006 EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA
Phone +61–7–3841 2844 Fax +61–7–3841 0005

SIZE	DRAWING No.	
A1	NUMBER JB010022	REV. A

TITLE: TACHO (CUP TYPE) JUNCTION BOX WIRING (WITH MULTIPLICATION), & CONNECTIONS TO OPTIMUS INTEGRATOR

CUSTOMER

PROJECT

CAD FILE JB010022

ALL DIMENSIONS IN MILLIMETRES UNLESS OTHERWISE SPECIFIED

This drawing and any information or descriptive matter set out hereon are the confidential and copyright property of WEB–TECH AUSTRALIA PTY. LTD. © and must not be disclosed, loaned, copied or used for manufacturing / tendering or for any other purpose without their written permission.

Index.

1.	General Description.	**4.**
2.	Specifications and On Site Requirements.	**5 - 6.**
3.	Enclosure Specifications	**7.**
4.	Theory of Operation.	**8.**
5.	Printed Circuit Board Description/Location.	**9.**
6.	Power and Field Wiring PCB.	**10-11.**
7.	Key Board Description.	**12.**
8.	Power Up.	**13.**
9.	Main Display MRMT Description.	**14-15.**
10.	Getting Started.	**16.**
11.	System Setup / *system configuration.*	**17-20.**
12.	System Setup */ display, time & date.*	**21-25.**
13.	System Setup / PID Loop Control / *PID overview.*	**26-27.**
14.	System Setup / PID Loop Control */ setpoint origin.*	**28-29.**
15.	System Setup / PID Loop Control */ output control / status.*	**30.**
16.	System Setup / PID Loop Control */ pid parameters.*	**31-34.**
17.	System Setup / PID Loop Control */ pid loop tuning.*	**35-36.**
18.	System Setup */* PID Loop Control / *pid mass rate filter.*	**37-38.**
19.	System Setup / PID Loop Control / *volumetric restart.*	**39-40.**
20.	System Setup / PID Loop Control / *reset integral.*	**41.**
21.	System Setup / PID Loop Control / *mass rate & pid output trend*.	**42.**
22.	System Setup / Auto Zero Tracking / *overview.*	**43.**
	System Setup / Auto Zero Tracking / *enable : disable.*	**44.**
23	System Setup / Auto Zero Tracking */ threshold.*	**45-46.**
24	System Setup / Auto Zero Tracking */ delay.*	**47.**

Index.

25	System Setup / Auto Zero Tracking / *period.*	**48.**
26	System Setup / Auto Zero Tracking / *current contribution.*	**49.**
27	System Setup / Rate Deadband .	**50.**
28	System Setup / Rate Display Filters.	**51.**
29	System Setup / Rate Display Filters */ time constant.*	**52.**
30	System Setup / Rate Display Filters */ fast track threshold.*	**53-54.**
31	System Setup / Save & Load Setup.	**55-56.**
32	System Setup / Chute Level Control.	**57-59.**
33	I/O (Input & Output) / Current Loop Inputs.	**60-67.**
34	I/O (Input & Output) / Current Loop Outputs.	**68-74.**
35	I/O (Input & Output) / Digital Inputs.	**75.**
36	I/O (Input & Output) / Digital Outputs	**76-82.**
37	I/O (Input & Output) / RS-232 Configuration.	**83-84.**
38	I/O (Input & Output) / RS-485 Configuration.	**85-86.**
39	Load Cell & Tachometer.	**87.**
40	Device Net.	**88.**
41	Theory of Operation/Steps in the Calibration Procedure.	**89-92.**
42	Calibration / Pulses per Revolution.	**93.**
43	Calibration / Manual Entry of belt revolutions & Zero Calibration	**94.**
44	Calibration / Auto Zero Tracking.	**95.**
45	Calibration / Target Weight.	**96.**
46	Calibration / Pulses per Revolution / *auto capture.*	**97-98.**
47	Calibration / Zero.	**99-100.**
48	Calibration / Span / *static weight test.*	**101-102.**
49	Calibration / Span / *empirical.*	**103-104.**

Index.

50	MRMT Screen / Trend.	**105.**
51	MRMT Screen / Clear Total.	**106.**
52	MRMT Screen / Info Screen.	**107.**
53	Notes & Firmware Updates.	**108.**
54	Electrical / Electronic Notes / *digital outputs.*	**109.**
55	Electrical / Electronic Notes / *digital inputs.*	**110.**

Optimus.
General Description.

Optimus is a powerful, microprocessor based weighbelt integrator. By design it can be used in a "stand alone" mode or slaved to a PLC or other plant supervisory system. Communication between the plant controller and Optimus being effected by one of the following Profi-Bus®, Device-Net®, TCP-IP, 4/20 mA, a range of digital inputs and outputs and relays (clean contacts). When used in the stand alone mode, control of the weighbelt feeder and associated equipment, valves, slide gates and conveyors is performed by Optimus.

The electronics are house in an IP67- NEEMA 4 rated enclosure, suitable for use in most industrial environments. However it is advisable that the package be shielded from continuous sun light and running water. The use of high pressure hoses to wash down the enclosure is not recommended. The electronics can be accessed through the accessed door which can be either latched, latched and padlocked or the latches removed and screw closed.

The Central Processing Unit (CPU) printed circuit board (PCB) is a six layers and contains all the main electronic components. In the unlikely event and Optimus fails, field fault finding is made easy as CPU, PCB is easily changed.

The Terminal PCB has been made extra thick (3mm) to provide a mechanically secure platform for the angled connectors.

The Power PCB is fitted with an auto voltage and frequency select power supply that makes Optimus suitable for use in most countries in the world. A switch and fuse provide a suitably qualified technician with a convenient method of mains power isolation and fuse checking.

All functions are made available through the front interface keypad and a (240 x 64 dot) LED back lit display. Optimus uses "state of the art" electronic components and programming techniques. It has been designed to operate with a the entire range of Web-Tech and other manufacturers weighbelt and conveyor belt scales.

At the heart of the controller is an eLAN 520, 32 bit microprocessor, running at 100mHz connected to a highly accurate and stable three channel analogue to digital converter (A/D converter). Optimus is supplied with a generous amount of 32 mbytes of SDRAM . This allows for future firmware expansion and customers specific custom software. Some of this storage is used for firmware, default variables and customer specific variables.

Should firmware upgrades be made available, Web-Tech will make the program available on Compact Flash modules, that simply plug into a socket on the CPU printed circuit board and automatically download the program. The Compact Flash module also serves as a storage device for the data logging feature incorporated in Optimus. The logged data can be sent back to Web-Tech for analyses should there be a problem with the system.

The analogue inputs from the load cells are channelled through a 24 bit analogue to digital converter specifically designed for use with load cells in an industrial environment.

Six auxiliary 12 (4096 values) bit analogue inputs, locally programmable as 4/20mA - 0/20mA - 0/25mA & 0/50mA . along with six digital outputs provide Optimus with the ability to monitor other processes associated with the feeder and process.

Five digital outputs provide voltage free contacts for use with PLC and SCADA systems.

One digital output (solid state switch) provides a means of indicating weight accumulation at low and high speed rates.

OPTIMUS OPERATIONAL MANUAL.
Specifications and Site Requirements.

Power Requirements.

240V AC +/- 10% 50/60 Hz
117V AC +/- 10% 50/60 Hz.
2amps @ 240V
4amps @ 117V

Main Board.

AMD Elan SC520 microprocessor running at 100 MHz.
8 Mb DRAM.
1 Mb soldered-down flash memory (expandable up to 4 Mb).
Compact Flash card type I or II header (supports any density CompactFlash cards).
Socket for up to 1Mb Flash or PROM BIOS (can replace soldered down flash).
Industry standard PC/104 expansion header with: 13 redirectable interrupts, 2 DMA channels and 8/16 bit I/O and memory interface.
Watchdog timer
Voltage supply brownout protection and reset generation.
Industry standard JTAG boundary scan interface for board testing & debugging.
High efficiency 3.3V and 2.5V on-board power supply for digital logic.

User Interface.

Support for up to 28 front panel keys.
¼ VGA (320 x 240 pixel) LCD screen support with digitally adjustable CCFL backlighting and screen contrast.
Internal switch for locking of calibration settings (for weights & measures laws).

Loadcell Interface.

Supports up to three independent loadcell channels.
22 bit (4.2 million values) analogue to digital converter (ADC) on each channel.
Temperature compensated / self calibrating ADC.
Fourth order digital filter attenuates interference at the sampling frequency and its harmonics by 160dB, e.g. 50 & 60Hz sampling rate negates mains power interference.
Sampling rate up to 1kHz (with slightly reduced effective resolution – 19 bits).
Ultra stable loadcell drive circuitry capable of driving 8 loadcells in parallel.
Loadcell interface is shielded in a metal can.

Current loop input and output.

Supports up to 8 0-25mA inputs (circuit presents 200 ohm load).
Supports up to 8 0-25mA outputs (drives up to 1k ohm load).
Loop input sampling rate up to 200kHz.
Loop output data rate up to 100kHz.
12 bit (4096 values) ADC resolution on both inputs and outputs.
Optically isolated from rest of circuit.

Serial Input/Output.

Optically isolated full/half duplex RS485 at up to 38400 baud.
RS232 port with RTS/CTS handshaking signals at up to 115200 baud.
Up to six optically isolated 24V digital inputs (PLC interface).
Up to eight digital output lines to drive relays on wiring board
12V relay activation supply to wiring board
Dual channel tachometer inputs

Initial Setup and debugging interface.

Four pole DIP configuration switch.
Reset pushbutton.
Four configurable LED status lights (Red).
HDD (compact flash) activity LED (Red).
Voltage rail monitor LEDs (Green).
Current loop output monitor LEDs (Orange).
Digital input monitor LEDs (Yellow).

Options.

High volume (92dB @ 10cm) full bridge driver for an internal piezo speaker
Battery backup for real-time clock and calendar – CR2032 coin cell.
1.5 Mbaud IrDA transciever.
Optically isolated half duplex RS485 at up to 38400 baud (for relay controller/expansion).
Isolated, current limited 1.5W 12V supply for relay controller/expansion power.
Temperature sensor - can be used for monitoring/alarms and for automatically changing the contrast of the LCD screen with ambient temperature variations.
256 byte EEPROM for storing configuration and setup data.

Terminal PCB.

5mm pitch screw terminations for all inputs, outputs and shields.
Clear labelling for each connection on PCB.
Support for up to eight relays for digital outputs (either 24V PLC type or 240V mains type) with 12V coil drive.
Support for up to eight relays for digital outputs (either 24V PLC type or 240V mains type) with 12V coil drive.

Power Board.

5mm pitch screw terminations for Active, Neutral & Earth.
Universal voltage supply with no voltage selection required 85VAC to 285VAC, 50/60 Hz.
Regulatory agency approvals on switch mode modules.
Input filtering.
Supplies +5V, +12V, -12V at 25W max total to main board.
Supplies +24V at 25W max to main board.

OPTIMUS OPERATIONAL MANUAL.
Enclosure Specifications.

Manufacturer.

Hoffmann.

Application.

Designed for use a an instrumentation housing enclosure, for use in highly corrosive environments including oil refineries, coal mines, chemical processing plants, waste water treatment and marine installation, electroplating plants, agricultural environments and food or animal processing plants.

Construction.

Moulded fibreglass polyester has outstanding chemical and temperature resistance and exhibits excellent weather-ability and physical properties.

Seamless foam-in-place gasket assures watertight and dust-tight seal.

Polyester mounting feet and stainless steel attachment screws.

Scratch-resistant GE LEXAN MARGARD® permanently bonded in place window.

Quick releases latches with corrosion resistant polyester latches located in corners which provides unobstructed access to enclosure.

Hinge and bail are corrosion resistant monel.

Knock out padlock provisions included in each latch.

Industry Standards.

NEMA / EEMAC (Type 4, Type 4X, Type 12 and Type 13).

UL 508 (Type 4, Type 4X, Type 12, and Type 13).

Enclosure flammability rating UL94-5V

CSA Type 4 and Type 12.

IEC 529 , **IP66**

OPTIMUS OPERATIONAL MANUAL.
Theory of Operation.

In general a weighbelt feeder consists of the following key components that are directly associated with the weighing function.

Load Cell.

Weigh Zone / (weigh deck)

Tachometer / (Encoder).

Electronic Integrator.

Optimus's primary roll is combine the weight of product carried by a conveyor belt and the speed of that belt and produce a variety of associated process control signals.

An electronic load cell is used sense the weight of product and an electronic encoder is used to provide a speed signal.

The tachometer/encoder is a device that is connected to a roll, that is contact with the belt and will rotate as the belt passes over it. The encoder shaft will then rotate and produce a series of pulses which Optimus uses to calculate the belt speed.

The load cell is situated in a position so that it able to sense the weight of the belt, product and the belt support. This position is generally referred to as the weigh area. The weight signal is usually in milli-volts and in the range of 0 mV to approximately +30 mV.

Optimus is a microprocessor based precision, high speed electronic integrator. The mV signal from the load cell is digitised by a precision, high resolution analogue to digital converter in Optimus and combined with the encoder output to produce an accurate MASS RATE. From this mass rate the total is computed as well as all other functions provided by Optimus.



LOAD CELL MOUNTED & SHOWING CONNECTION TO LOAD PICK UP ASSEMBLY



TACHOMETER/ENCODER



OPTIMUS OPERATIONAL MANUAL.
Printed Circuit Board location.

Optimus comprises three printed circuit boards (PCB). Main processor PCB, field wiring PCB and power PCB.

Main Processor PCB.

The main processor PCB is located on the door of the enclosure. Generally there is no field wiring to be connected to this board. However if a communications package is to be used, wiring will be required to be connected to the PC 104 communications PCB. This PCB is piggy backed onto the main PCB.

Field Wiring PCB.

This card is located in the main portion of the enclosure, below the main processor PCB (when the door is closed) and above the power PCB. This PCB will be loaded with connectors strips and relays that are required for the application. Any parts not loaded have been deliberately omitted. This PCB along with the power PCB has been designed to be easily removed for servicing, if required. This PCB is reasonably robust by design, it has been made from a thicker than normal fibreglass, under normal operating conditions a reasonable amount of torque can be applied to the terminal screws with out damage occurring, however damage will occur if too much force is applied.
As space within the enclosure is limited, all wiring should be neat and trimmed to suit.
See drawing at the rear of this manual for field wiring details.

Power PCB. (DANGER MAINS VOLTAGE MAY BE PRESENT)

This PCB is located under the Field Wiring PCB. A cut out in the has been provided in the Field Wiring PCB so that access to can be provided to the main supply terminal strip, the fuse and local on/off switch.

Installer / Electrician Note.

Care must be taken when cutting holes in the enclosure to provide cable access. It is recommended that the Power & Field Wiring PCB be removed prior cutting holes. Take note of cable entry with respect to PCB when re installed.
All cables should enter the enclosure via site approved cable glands.
The entry of water into this enclosure will damage the electronics and void and warranty.

OPTIMUS OPERATIONAL MANUAL.

Power & Field Wiring PCB.

Battery Seiko Cr 2032 or equivalent. This battery is used to hold up the information stored in the screen “System Information” All operating variables are stored in non volatile memory, which does not require battery power.

CPU PCB.



The 5 yellow LED’s when lit, show that the operating voltages required by Optimus and it’s sub-assemblies are all healthy.

+24V

+12V

-12v

+5V

+3.3V

Optional communications card. TCP-IP, Profibus, DeviceNet

Power & Terminal PCB.



Optional RS 232 Output

Optional RS 485 Output

Generally Digital Inputs.

Generally analogue outputs.

Generally Relay I/O

Generally Analogue Inputs.

Fuse

Load Cell Inputs Channel 1-3

Local On/Off Switch. Lower PCB.

Multi Voltage/Frequency Mains Input. Lower PCB.

OPTIMUS OPERATIONAL MANUAL.

Power & Field Wiring PCB.

Optimus can power up to eight (8) individual load cells. (350O). Generally these load cells are paralled up, in marshalling boxes in the field. However some continuous weighing systems application require that individual load cells are digitally summed in Optimus. This allows special mathematical algorithms to be applied to the load cell signals prior to integration. On occasion Optimus may be required to read the out put of a load cell that is positioned up stream of the weigh area in order that product can be accurately pre fed onto the weigh belt.

Belt weighing systems / weigh feeders usually do not employ more than one channel input.

If the load cell cable runs are long, it is possible to have a voltage drop at the load cell. Optimus provides for the reading of the supply voltage at the load cell via the load cell sense wires (where fitted). If the sense wires are connected and the jumpers are set as shown below. Any voltage drop will be corrected for.

No Sense Used



Sense Used





OPTIMUS OPERATIONAL MANUAL.

Keypad Description.



Takes the user back to MRMT & updates all entered variables

Cancels the current operation & takes the user back to MRMT.

Saves any changes and moves the screen forward one.

Cancels current action and forces display back to previous screen.

Scrolls curser up.

Scrolls curser down.

Saves any changes and moves the screen forward one.

The above function (f) keys are associated with the boxed message displayed directly above the f key.

OPTIMUS OPERATIONAL MANUAL.

Power Up.

Once Optimus has been connected up as per the drawings in the rear of this manual and with reference to the chapter *Printed Circuit Board location.* The unit can be powered up, it should be noted that Optimus has a power supply that will accept most common supply voltages and frequencies, found around the world . The unit has a local power switch located on the power PCB, this should now be moved to the on position. Optimus will now power up, load the operating software and perform a series of self diagnostic routines. During this time the Web-Tech logo will be displayed. Following a successful power up the screen display will change to the following.

Start Up Display

The screen shown below is the screen that should be displayed whilst Optimus Plus is running. We call this particular screen Mass Rate, Mass Total (**MRMT**) and is the default screen. Take time to make yourself familiar with the data that is available on this screen and how it interacts with the keypad.

See over for detailed description of functions available from this screen.

Mass Rate Mass Total (MRMT) Display



OPTIMUS OPERATIONAL MANUAL.

Main Display MRMT Description.





The above function (f) keys are associated with the boxed message displayed in the display directly above the f key. Pressing any of these keys will take you to the associated functions.

CAL. Pressing the CAL F1 key takes the user to the screens that provide for calibrating Optimus.

I/O. Pressing the I/O F2 key takes the user to the screens that provide for configuring current loops in and out. The digital inputs and out puts. The RS 232 & 485 serial communications.
The load cell entry point provides a method of easily viewing the load cell and tachometers output.

TREND. Entering the Trend F3 screen provides the user with a 2 minute trend of the instantaneous mass rate and control over the setpoint.

CLEAR. Pressing the clear F4 clears the local displays running total.

SETUP. Pressing the Setup F5 key takes the user to the menus associated with configuring Optimus.

INFO. Activating the Info F6 displays the Information screen where details of Optimus software can be viewed.

OPTIMUS OPERATIONAL MANUAL.

Main Display MRMT Description.



● ON

○ OFF

When active, feeder setpoint is generated at the key..... ● **SP Local**

When active, feeder setpoint is generated by an external device..... ○ **SP Rem**

When active, the Auto Zero Tracking is operating..... ○ **AZT On**

When active, the PID loop is Off and controlled through keyboard..... ○ **PID Man**

When active, the PID loop is On & functioning under the control algorithm.... ● **PID Auto**

☜ Discards changes made on current screen and moves back one screen.

☞ The Tick key accepts the input data. Stores the data into a working memory and returns the cursor to the main menu if data was entered in a sub menu.

ABORT Gives the user the option to discard all configuration changes they have made. Pressing 'ABORT' again discards any changes and reverts to the MRMT screen. Pressing 'HOME' will save any configuration and reverts back to MRMT screen.

ENTER The 'ENTER' key is used to enter menu's and scroll through preset menu's.

HOME Gives the user the option to save all configuration changes they have made. Pressing 'HOME' again will save changes and revert to MRMT screen. Pressing 'ABORT' will discard any changes made and revert to MRMT screen.

OPTIMUS OPERATIONAL MANUAL.
Getting Started.

Optimus is generally termed an integrator. It has been designed to work with most conveyor belt scales, weighfeeder's and various "in motion weighing mechanisms".

Prior to operating Optimus it has to be setup and calibrated. Web-Tech advise that these operations be performed by qualified technicians who have been trained in the operation of Optimus and the weighfeeder. Web-Tech can't warrant the accuracy and operation of our equipment if the system is incorrectly installed.

The procedure is as follows-

1. **Setup**
2. **Define the required I/O**
3. **Calibrate**
4. **Setup and tune the PID algorithm and control loop.**

The **Setup** procedure customises the electronics to suit your application.

Defining the Input/Output allocates relays analogue outputs etc to Optimus functions.

The **Calibration** procedure is required to force Optimus to convert the instrument's raw data (i. e. milli volts from the load cell/cells & tachometer frequency) into the physical units (i.e. Tons/ hour kg/hr and their corresponding totalised values).

Setting up the PID is required so that the mathematical algorithm (PID) is loaded with variables that produce the required mass rate control response.

SETUP (Configuring Optimus).

Prior to calibrating Optimus, the instrument must be configured to suit the application. Units selected and the input and output functions defined.

Following power up, Press SETUP (F5) key .The display will change to that shown below.
SYSTEM CONFIGURATION SCREEN



Select “System Configuration” by pushing the “ENTER” key.

The display will change to that shown below.

Units of measurement = kg/min
Belt capacity = 100.0 kg/min
Resolution = 0.1
Belt length = 2.915 meters
Maximum belt loading = 10.0 kg/meter

The arrow shaped cursor will point to the **Units of Measurement.**

The units of measurement can be set by pushing the “ENTER” key. There are 7 sets of predefined units of mass rate. All of which can be accessed by pressing the “ENTER” key and scrolling through the list using the “ENTER” key.

The following units are available :-

Tonnes per hour.
Kg per minute.
Kg per hour.
Pounds per minute.
Pounds per hour.
Tons per hour.

Belt Capacity.

Advance the cursor to belt capacity entry point by using the right or left arrow keys. Pressing the "ENTER" key here will display a dedicated input menu, where the max design capacity of the feeder, should be entered. This data can be found in the design data sheet supplied by Web Tech during the feeder/belt scale design phase. The value entered is captured by Optimus following the pressing of either the "ENTER" or tick F3 key.

This variable is used to scale the analogue outputs.


Units of measurement = kg/min
Belt capacity = 60.0 kg/min
Resolution = 0.1
Belt length = 2.915 meters
Maximum belt loading = 10.0 kg/meter

Press the "ENTER" key when the cursor is pointing at the "Belt capacity" and the screen will change to the Belt Capacity entry screen. Enter the feeders maximum capacity here. Press the tick key to force Optimus to read the entered value.

Using either the left or right arrow keys, go to the entry point for "**Resolution**".

Units of measurement = kg/min
Belt capacity = 100.0 kg/min
Resolution = 0.1
Belt length = 2.915 meters
Maximum belt loading = 10.0 kg/meter

The resolution can be changed to one of the preset precision values. The values offered here are based on the capacity that was previously entered and can be accessed by pressing the "ENTER" key until the required value is found from the list. The value entered here will be reflected in the MRMT screen's precision.

Belt Length.

Use the left or right arrow keys to move the cursor to the 'Belt Length' entry point. Optimus needs to accurately know the belt length in order to perform the Span and Zero routines.
Note :The belt length is not used by Optimus to calculate the Mass Rate and Mass Total. The belt length can be found in the design data sheet.


Units of measurement = kg/min
Belt capacity = 100.0 kg/min
Resolution = 0.1
Belt length = 2.915 meters
Maximum belt loading = 10.0 kg/meter

Press the 'ENTER' key to access the 'Belt Length' entry routine. Enter the belt length here and press the tick key to force Optimus to read in the value.



Belt Length Units.

Use the left or right arrow keys to move the cursor to the 'Belt Length Units' entry point. Press the 'ENTER' key to scroll through the available units.

Units of measurement = kg/min
Belt capacity = 100.0 kg/min
Resolution = 0.1
Belt length = 2.915 meters
Maximum belt loading = 10.0 kg/meter

Maximum Belt Loading.

This data entry point sets up an analogue output to reflect the instantaneous belt loading, if required. Generally Optimus will perform all the calculations required to successfully set up the instrument. However this requires user input and calculation. See below for calculation details. Use the left or right arrow keys to move the cursor to the 'Maximum Belt Loading' entry point. Press the 'ENTER' key to access the data entry screen. The data entered here has to be calculated by the user. See below.


Units of measurement = kg/min
Belt capacity = 100.0 kg/min
Resolution = 0.1
Belt length = 2.915 meters
Maximum belt loading = 10.0 kg/meter

Maximum Belt Loading 'Data Calculating'.

Optimus needs to know the maximum expected belt loading in the units shown in the screen below. So that the 20mA point can be scaled against the belt loading 4/20mA output signal.



Use the following to calculate the Maximum Belt Loading.

From the conveyor design data document. Obtain the following :-

Maximum Belt Capacity. (units to be in those previously selected)

Belt Speed. (BS). (m/S)

$$\text{Belt Loading} = \frac{\text{Belt Capacity}}{\text{BS} \times \text{(Use 60 if mass rate is displayed in Units/minute) (Use 3600 if mass rate is displayed in Units/hour)}}$$

E.g.

$$\frac{\text{Capacity } 60 \text{ kg/minute}}{\text{Belt Speed. } 0.25 \text{m/S}}$$

$$\text{Belt Loading} = \frac{60}{0.25 \times 60} \quad \underline{4}\text{ kg/metre} \quad \text{(enter this, into data entry screen).}$$

OPTIMUS OPERATIONAL MANUAL.
System Setup / *display, time & date.*

Backlight.
Optimus is supplied with a Liquid Crystal, Light Emitting Diode (LED) back lit screen. The use of back lighting is essential, if the screen is to be viewed in low light conditions. Use the scroll forward key to position the cursor along side the "Display and Time/Date screen entry point.



System Configuration Screen.



Press the "ENTER" key to access the display setup screen.

Use the "ENTER" key to scroll through the predefined list of timed / un-timed Backlight settings.
Always On; Off after 2 mins; Off after 5 mins; Off after 10 mins; Off after 30 mins; Off after 60mins; Always off.

It should be noted that Optimus electronics package has been fitted into a closed environment. The back light draws considerable power from the power supply. The longer the back light is on for any given brightness the greater the heat given off from the power supply module.
When the ambient temperatures are high Optimus may not be able to conduct this heat away as efficiently as required. We suggest that the back light be set to "Off" after 2 or 5 minutes. The back light will re-activate on pressing any key if any of the timed off settings are used.

Brightness.

Scroll to Brightness and select the value that best suites the working environment. Pressing the "ENTER" key here will toggle the selection of fixed values of display back-lighting.



Contrast.

LCD displays have a limited viewing angle. The angle can be adjusted up or down as required. To adjust the viewing angle scroll to Contrast input routine and use the "Enter" key to select the value that best suites the working environment and the position of the enclosure.



Date Entry.

The date and time, if required are entered using a standard format. Scroll the cursor down until it points to the data entry point for the day. Press "ENTER" to gain access to the data entry screen, enter the date. Press the ENTER or tick key to write date to memory and move on. Scroll onto the month entry point and use the "ENTER" to scroll through the months. Select the current month and move onto the year using the scroll right key. Press "ENTER" to gain access to the year entry. Type in either the whole year or just the last two digits of the year



Press the "ENTER" key to access the Day setup screen.

Press the "ENTER" key to access the Day entry screen.



Press the "ENTER" or tick key to lock in the day. Forward scroll to the month entry point use the "ENTER" key to scroll through the month selection. Press the scroll forward to access the year entry screen.



Select the month and scroll on to year entry position.



Press the "ENTER" key to access the data entry screen and enter the year. Press the tick key to lock in the year data and return to .

Scroll forward to the time (hour) entry position and press the "ENTER" key to access the hour entry screen.



Select the month and scroll on to year entry position.



Enter the current hour (24 hour clock) format. Press the tick key to lock in the data. Scroll on to the minute entry point and press the "ENTER" key to access the minute entry screen



Enter the current minute and press the tick key to lock in the data and return to the time/ date entry screen.



Enter the current seconds and press the tick key to lock in the data and return to the time/date entry screen.



Press "ENTER" or the tick key to return to the "SETUP" screen.



Scroll on to the "PID Loop Control". Read the following pages of this manual before proceeding.



PID Parameters.

Generally weighfeeders are used primarily to set and control the flow of bulk solids into a process. The flow control should be automatic, without user intervention. If the bulk density or flow characteristics change, the feeder must be able to correct the flow. The correction should be as smooth and quick as possible or to a predefined action. Weigh belt weighfeeders generally can only increase or decrease the belt speed in order to increase or decrease the mass rate. The speed control is usually done by a variable speed drive unit connected to the drive motor. By judicial use of the variables introduced into the Proportional, Integral, Derivative (PID) algorithm. An effective automatic control output to the variable motor speed controller can be produced. This manual does not cover the theory behind PID control or the methodology used in setting up the algorithm. It is assumed that the user is well versed in this area of industrial control. Generally the values preset in Optimus will provide reasonable control response, however tuning will improve the overall control action.

Optimus uses a PID algorithm modified to suit belt weighfeeders, to control the operation of the feeder in gravimetric mode.

Expressed in analogue form, the PID algorithm used by the Optimus is:

$$OP(t) = OS + FF \cdot SP(t) \cdot \frac{100}{PB}\left[E(t) + RR \cdot \int_0^t E(s)ds + K_D \frac{dE(t)}{dt}\right] \quad (1)$$

where $E(t) = SP(t) - MR(t)$

and *SP(t)* is the setpoint, *MR(t)* is the mass rate, E(t) is the deviation, *OP(t)* is the PID output, *OS* is the output offset, *FF* is the feed-forward term, *PB* is the proportional band, *RR* is the reset rate, K_D is the derivative gain and *t* is time.

Equation (1) is expressed as a function of continuous time. The Optimus Plus implements this equation in discretized form:

with

$$OP(t_k) = OS + FF \cdot SP(t_k) \cdot \frac{100}{PB}\left[E(t_k) + RR \cdot \sum_{i=0}^{k} E(t_i) \cdot \Delta t + K_D \frac{E(t_k) - E(t_{k-1})}{\Delta t}\right] \quad (2)$$

where Δt is the sampling interval, and $X(t_k)$ is the value of signal *X(t)* at the *k*-th sample time.

Proportional Gain.

The contribution of the proportional term to the PID output is determined by the proportional band *PB*. Decreasing *PB* increases the contribution of the proportional term. Increasing *PB* decreases the contribution of the proportional term. *PB* is expressed in units of %. When *PB*=100%, the effective gain applied to the error term is 1.

Decreasing *PB* will result in faster response and reduce the error signal (so that the mass rate more closely matches the set point signal), but will simultaneously increase the system's tendency to overshoot, hunt and even oscillate.

Integral Gain.

The contribution of the integral term to the PID output is determined by the reset rate *RR*. The reset rate has units of resets/sec. Increasing *RR* increases the contribution of the integral error term. Decreasing *RR* decreases the contribution of the integral error term.

Decreasing *RR* will cause the PID loop to reduce the offset error (the difference between the mass rate and the set point) to near zero. The smaller *RR*, the more rapidly the PID loop will reduce an offset error to zero. Decreasing *RR* to very small values will in-

Integral Lower Limit.

The integral lower limit specifies the maximum negative value the integral term may reach. If the calculated integral term is less than the integral lower limit, it is replaced with the integral lower limit in computations of the PID output.

Derivative Gain.

The contribution of the derivative term to the PID output is determined by the derivative gain K_D. The derivative gain has units of seconds. Increasing K_D increases the contribution of the derivative error term. Decreasing K_D decreases the contribution of the derivative error term.
Increasing K_D reduces the hunting and tendency to oscillate which results from decreasing *PB*. K_D does not act to correct offset error.

Output Offset.

The output offset, *OO*, is defined as the percentage offset to add onto the control output, and has units of percent.

Feed Forward Gain.

The feed-forward gain, *FF*, is defined as the percentage of the setpoint to add on to the control output, and has units of percent.

OPTIMUS OPERATIONAL MANUAL.

System Setup / PID Loop Control / setpoint origin.

PID Loop Control.

For Optimus to effectively control the feed rate of material travelling over the weigh area. A three term control algorithm is used (PID). This algorithm has to be loaded with variables that satisfy the process. Entering this menu provide s data input screens, where variables for the PID algorithm can be entered, changed and monitored.



On selecting Menu 3 PID Loop Control the screen changes to that shown below.



The "SETUP" (F3) key takes the user back to the main setup menu.

With the cursor positioned as shown, the setpoint source can be toggled between "LOCAL" & "REMOTE" using the "ENTER" key.
If Local is selected, the set point can be changed either by adjusting the percentage of set point as shown below. Or by scrolling right and setting it as an absolute value. When in the local mode the remote setpoint (if any) is suppressed.

Use the "ENTER" key to access the data entry screen where the local setpoint can be adjusted as a %. Or an absolute mass rate.



Use the tick key to accept the entered data.
If setpoint data needs to be entered as an absolute mass rate scroll the cursor once more until the cursor is positioned as show below.



From this point access the data entry screen and enter the mass rate required.



Press the tick key to lock in the data and return to the setup screen.

OPTIMUS OPERATIONAL MANUAL.

System Setup / PID Loop Control / Output control / status.

Output Control & Status.

Optimus's analogue output whilst in the Automatic mode can be viewed from the menu shown below. When in the Manual mode the analogue output can be forced from the keypad.



On selecting Menu 2 Output Control & Status screen changes to that shown below. The PID loop can be toggled between "manual" & "remote". This feature allows the user to set the belt speed to assist in calibration or fault finding.



The PID loop output, when set to the manual mode will be forced to the value entered in this menu under manual as a percentage of inverter speed. . Press the scroll key to position the cursor along side either the entry point required and then press enter to gain access to the data entry screen.



Pressing the "ENTER" key at this point brings up the inverter speed input screen. Press tick to lock in the entered data.



OPTIMUS OPERATIONAL MANUAL.
System Setup / PID Loop Control / pid parameters.

The screens and menu entry points associated with the "PID Parameters" allow suitably qualified personnel to load the PID algorithm with variables that best suit the operation of the feeder. It should be noted that a *good understanding of process control loops* is required for successful tuning of a weighbelt feeder.

Press the "ENTER" key to access the PID variable adjust screen.



On selecting Menu 3, PID Parameters, the screen changes to that shown below.


Prop band =200.0% Reset rate = +0.100 resets/s
Integral lower limit =-50.0% Upper limit = +50.0%
Derivative time= =+0.00s
Feed forward =1.00 Output offset = +0.00



Enter the value required for the Proportional screen and press the Tick key to accept and return to the PID screen.

Use the scroll keys to access the Integral (reset rate) data entry point.


Prop band =200.0% Reset rate = +0.100 resets/s
Integral lower limit =-50.0% Upper limit = +50.0%
Derivative time= =+0.00s
Feed forward =1.00 Output offset = +0.00

Use the “ENTER” key to access “I” (reset rate) data entry screen.

Use the “ENTER” key to access the Integral Lower Limit data entry screen.

Prop band =200.0% Reset rate = +0.100 resets/s
Integral lower limit =-50.0% Upper limit = +50.0%
Derivative time= =+0.00s
Feed forward =1.00 Output offset = +0.00

In many applications it is often beneficial if the PID integral is restrained. As the working “integral” can be either positive or minus value. The limits can be set in the following data entry screens. Note the F5 key is now configured as a sign entry key.



Use the Tick key to lock in the Integral Lower Limit.

Use the scroll keys to access the Integral Lower Limit.

Prop band =200.0% Reset rate = +0.100 resets/s
Integral lower limit =-50.0% Upper limit = +50.0%
Derivative time= =+0.00s
Feed forward =1.00 Output offset = +0.00

Use the "ENTER" key to access the Integral Upper Limit data entry screen.



Scroll to the Derivative using the scroll keys.

Prop band =200.0% Reset rate = +0.100 resets/s
Integral lower limit =-50.0% Upper limit = +50.0%
Derivative time= =+0.00s
Feed forward =1.00 Output offset = +0.00

Use the "ENTER" key to gain access to the Derivative time data entry screen.



Use the "ENTER" key to lock in the derivative time data and return to PID screen.

Use the scroll keys to access the Feed forward term.

Prop band =200.0% Reset rate = +0.100 resets/s
Integral lower limit =-50.0% Upper limit = +50.0%
Derivative time= =+0.00s
Feed forward =1.00 Output offset = +0.00

Use the "ENTER" key to access the Feed Forward term.



Use the "ENTER" key to lock in the feed Forward term data and return to PID screen.

Prop band =200.0% Reset rate = +0.100 resets/s
Integral lower limit =-50.0% Upper limit = +50.0%
Derivative time= =+0.00s
Feed forward =1.00 Output offset = +0.00

With the cursor pointing at the "Output offset" press the "ENTER" key to gain access to the data input screen.



Press the tick key to lock in the data. The display will then return to the main PID setup screen

PID Loop Tuning.

Following the loading of the PID algorithm with the required variables. Optimus provides the user with a convenient method of adjusting and viewing the PID algorithm. Scroll to the PID Loop Tuning menu and press the "ENTER" key to gain access.



On selecting Menu 4 PID Loop Tuning the screen changes to that shown below.



PID Loop Tuning Screen.

From this screen the user can tune the PID loop without having to change screens. All variables associated with the control loop are accessible from this screen as are the outputs from the load cell and tachometer. The cursor under control of the (F1 & F2) keys will take the user to all the changeable variables. All other data displayed is for viewing only.

1	SP	Set Point. (As a percentage of belt capacity).
2	FF	Feed Forward Term.
3	OS	PID Output Offset Term.
4	OP	PID Analogue Output.
5	IL	PID Integral Lower Limit.
6	IU	PID Integral Upper Limit.
7	PB	PID Proportional Term.
8	RR	PID Integral Term.
9	DT	PID Derivative Term.
10	PC	Proportional contribution.
11	IC	Integral contribution.
12	DC	derivative contribution.
13	LC	Load Cell output in milli-volts.
14	TC	Tachometer output in hertz.

PID Loop Tuning. (Continued)

PLOT (F5) **Pressing the PLOT (F5) key provides the user with a plot screen the Mass Rate and PID out being plotted.**

LOC (F6) set **Pressing the LOCAL (F6) toggles Optimus between the setpoint being remotely or locally.**



Select "PLOT" to go to the TREND screen where the set point can be ramped up and down and the feeder response viewed..



OPTIMUS OPERATIONAL MANUAL.

System Setup / PID Loop Control / pid mass rate filter.

PID Mass Rate Filter.

This filter is applied to the PID analogue output. The filter comprises a regular time average filter enhanced with a fast track multiplier. The level of filtering is specified by a constant which may be in the range of 1 second to 120 seconds. A time constant of 1 second is the equivalent to no filter being applied.

When active the fast-track filter multiplier restrains the PID analogue output from changing until the change exceeds the percentage set in the "Fast track threshold". By the judicial use of this feature the weighfeeder system can be restrained from reacting to anomalies in belt loading caused by irregular prefeed or lumpy feed.

Note The Filter can be disabled (not running), enabled (running) and filter running without the fast track multiplier running.

Set the "Threshold" to between 1% & 99% to enable the fast track filter. Set the "Threshold" to 0% to disable the filter and 100% to disable fast track yet keep the standard filter running.



On selecting Menu 5 PID Mass Rate Filter the screen changes to that shown below. The "Time constant is entered by pressing the "ENTER" key.





The value entered in the above data entry screen is locked in by pressing "ENTER"

To adjust the "Fast track threshold" scroll the selector arrow to the "Fast track threshold entry point and press "ENTER". The screen will change to the data entry screen.



The "Fast track threshold" data entry screen.



Enter the value required. Note a value of zero or 100% will render the "Fast track feature inoperable. Press the tick key to return to the main PID setup screen.

Volumetric Restart.

In applications where the weighfeeder is constantly stopping and starting. It is advantageous in terms of feeder control, to freeze the control algorithm when the feeder is halted by a supervisory system or operator. The Volumetric Restart feature allows the user to freeze the PID control action at the point when the stop is initiated and hold it for a predetermined time on restart. The hold time is variable and is combined with a mass rate threshold. The mass rate threshold allows the user to switch out the timed function when a selected mass rate is achieved.



On selecting Menu 6 Volumetric Restart the screen changes to that shown below. The "Volumetric restart" feature can be enabled or disabled by pressing the "ENTER" key when the selector arrow is in the position shown.



The "Volumetric restart" feature can be loaded with variables whether or not the feature is enabled or not. Scroll the selector arrow to the "Volumetric restart period and press "ENTER"



OPTIMUS OPERATIONAL MANUAL.

System Setup / PID Loop Control / volumetric restart.

The value entered in the "Volumetric restart period" screen. Is the time period that Optimus will use to time out the freezing of the PID algorithm, prior to recalculating the new process variable and out putting the signal to the analogue PID output.



Following the entry of the required delay, press the "ENTER" key to lock in the data. Scroll on the selector arrow to the "Volumetric restart threshold" and press "ENTER" to gain access.



The "Volumetric restart threshold" acts in conjunction with the "Volumetric restart period". It will override the volumetric restart period, if enabled and the mass rate is calculated as being within percentage set in this menu. This provides for a fast response from the PID algorithm should the mass rate come up to set point prior to the volumetric restart period timing out after a belt stoppage. The values in this menu should be entered after observing the system in normal field operation.



Press the "TICK" key to lock in the selected value.

OPTIMUS OPERATIONAL MANUAL.

System Setup / PID Loop Control / reset the integral contribution.

Reset Integral Contribution.

When tuning a feeder it is often advantageous to be able to manually reset the integral contribution to the PID loop output. Pressing the "ENTER" key when the selector arrow is opposite the Reset Integral Contribution when force the integral to be reset.



OPTIMUS OPERATIONAL MANUAL.

System Setup / PID Loop Control / mass rate & pid output trends.

Mass Rate / PID Trend.

This screen allows the user to view the relationship between the mass rate and the control function output. With the selector arrow opposite the MR-PID trend press "ENTER" to access the trend screen.



On selecting Menu 8 changes to that shown below. There are two traces, Mass Rate (MR) and PID output (PID). To exit this menu use the F1 key (BACK) to clear the trace use the F2 key (CLEAR). The F3 key (⇂ SP) reduces the setpoint, the F4 key (⇂ SP) increases the setpoint. The arrow attached to the vertical cursor depicts the set point.



When finished with this screen press the F1 key "BACK" to return to the PID Loop.



To return to the "SETUP" menu's press the F3 "SETUP key. Scroll the cursor on to Auto Zero Tracking (AZT). Prior to entering data in this menu read the AZT explanation on following page.



OPTIMUS OPERATIONAL MANUAL.
System Setup / Auto Zero Tracking / overview.

Prior to describing the use of the Auto Zero Tracking (AZT) function, the user should be familiar with certain terminology.
Manual Zero is the belt zeroing which is invoked by an operator. The function is automatic but has to be manually invoked. As distinct from the AZT function which is performed automatically without user intervention.

Auto Zero Tracking. (This function should be set up after the scale has be calibrated)
The weight of the weigh belt and the weigh area can change with time. The weight changes can be generally attributed to, wear and tear, product build upon the belt and product build up on the weigh area. If the scale was a static system weighing in batches for instance, the scale could be automatically zeroed each time the previous load was removed. The action being triggered by the output of the load cell dropping to a pre-programmed value.
Continuous weighing systems are more complex and require more conditions to be satisfied prior to an AZ being performed. The function can be enabled or disabled by toggling the 'ENTER' key when the sect arrow is along side the field.
Optimus allows the user to select a load cell output below which the AZ function will be invoked (Threshold). It is important this load cell output is carefully selected. It can only be accurately selected after the system has been manually zeroed, calibrated and the mass rate observed over a minimum of one whole belt revolution. The Auto Zero Threshold level should be set to approximately 5% higher than the highest value displayed when the belt is running empty.
The delay value is provided so that the AZ function will only be invoked after the delay has timed out. This function is used when the process is subject to constant no flow conditions. The period allows the user to select the number of whole belt revolution that the zero will performed over. A good knowledge of the process is necessary to enter a value here.
E.g. If the no flow condition is available for a period of greater than one belt revolution but less than two belt revolution, use one revolution here and so on.
The value shown in the "Current Contribution" field display the offset that Optimus has applied to the manual zero found during the manual zero process. It is reset after each manual zero has been performed.


Mass Rate as % or absolute value.
The Mass rate that has to be <= the set value prior to the AZT starting.
Average Zero.
Whole belt revolution
Whole belt revolution
Whole belt revolution
Whole belt revolution
Whole belt revolution
Delay implemented after the threshold has been satisfied

Toggling the "ENTER" key here will either enable or disable the Auto Zero Tracking function (AZT).



Use the scroll key to access the Threshold setting screen. The Threshold can be set as a percentage of the belt capacity or as a mass rate. The user should be aware of result of the AZT threshold being set too high or too low. If it is set too high Optimus could invoke the Auto zero routine and zero out the belt with material on it, or never completely perform an AZT because the dead weight effect of the belt switches out the function before a full belt revolution can be completed. Use an input that means something to you and observe the process prior to setting up this screen.



Press the "ENTER" key to adjust the AZT Threshold.



Press the tick key to lock in the new threshold level

The Threshold is the point at which Optimus will perform an AZT assuming that the Delay period has been satisfied. The threshold can be set either as a % of the of maximum mass rate (as specified in the setup). Or as an absolute value, in the specified units. Use the scroll keys to access the Threshold and press "ENTER" key to gain access to data entry screen for either % or units.



Pressing the "ENTER" key here will bring up the threshold percent data entry screen.



Press the tick key to accept and exit to the previous screen. Or the Cross key to exit to the previous screen

As with the previous screen the AZT threshold can be set by scrolling to the absolute value entry point as shown below. Pressing the "ENTER" key will gain access to the data entry field.



Pressing the "ENTER" key here will bring up the threshold percent data entry screen.



Press the tick key to accept and exit to the previous screen. Or the Cross key to exit to the previous screen.

OPTIMUS OPERATIONAL MANUAL.
System Setup / Auto Zero Tracking / delay.

Some processes are cyclic and the belt can be running empty (below the threshold) the AZT will activate only to be halted when more material is presented to the belt. The delay allows the user who has a knowledge of the process to suppress the start of an AZT until the threshold has been active longer than any normal cyclic process.



Press the "ENTER" key with the cursor opposite the delay to gain access to the delay data input screen.



Press the tick key to accept the new value for the delay of the AZT feature

A user initiated Zero will be performed over the number of belt revolutions that were defined during the calibration process. When a AZT is initiated the number of belt revolutions that the user wishes to have the AZT performed over can be more or less than the number defined in the calibration process. This is allowed in order that a zero can be completed within a "widow" of opportunity. A knowledge of the process is required prior to selecting the "PERIOD". Scroll the cursor to the "PERIOD" data entry point and press "ENTER".



Enter the number of belt revolutions that the AZT should use to update the current average zero



Press the tick key to accept and exit to the previous screen. Or the Cross key to exit to the previous screen

OPTIMUS OPERATIONAL MANUAL.

System Setup / Auto Zero Tracking / current contribution.

Over time the AZT contribution to the average zero may drift out of limits that can be termed normal. This value will be different for all systems and depends on the working environment, feeder design, product and belt wear. In order that the user can monitor performance of the AZT routine Optimus has been provide with a viewing port, where the AZT calculated zero can be reviewed and reset. Note this value is automatically reset each time an operator initiated zero is performed.

Press the "RESET" key (F5). To gain access to the AZT reset.






Mass rate deadband = 0.2% of belt capacity
= 1.2 kg/hour
Mass rate = 350 kg/hour
Maximum mass rate = 600 kg/hour
CLEAR


Rate deadband (in kg/min)
1.8
New value
DEL
CLEAR


Mass rate deadband = 0.2% of belt capacity
= 1.2 kg/hour
Mass rate = 350 kg/hour
Maximum mass rate = 600 kg/hour
CLEAR


1. System Configuration
2. Display and Time/Date
3. PID Loop Control
4. Auto Zero Tracking
5. Rate Deadband
6. Rate Display Filters
7. Save/Load Setup
8. Chute Level Control


Mass rate deadband = 0.2% of belt capacity
= 1.2 kg/hour
Mass rate = 350 kg/hour
Maximum mass rate = 600 kg/hour
CLEAR


Rate deadband (as % of belt capacity)
2.0
New value
DEL
CLEAR

OPTIMUS OPERATIONAL MANUAL.
System Setup / Rate Display Filters / time constant.

The analogue Mass Rate output signal can be filtered. Scroll to Rate Display Filter and press "ENTER" to show the menu for mass Rate Filtering.



Press the "ENTER" key to gain access to the Mass Rate Filter menu.


Mass rate display filter enabled (fast track active)
Time constant = 20s Fast track threshold = 20%
Mass rate trend filter enabled (fast track active)
Time constant = 10s Fast track threshold = 20%

Press the "ENTER" key to gain access to the Mass Rate data entry screen.



Enter the value required for the time constant in the above screen and press the Tick key to accept and return to the PID screen.

OPTIMUS OPERATIONAL MANUAL.
System Setup / Rate Display Filters / fast track threshold & time.

The Mass Rate Filter.

This feature allows the user to dampen the Mass Rate analogue output. Mass rate filter has fast tracking facility associated with it. The filter can be switched off by Setting the "Threshold" to 0% . If the filter is required without the fast track feature, set the "Threshold" to 100%.


Mass rate display filter enabled (fast track active)
Time constant = 20s Fast track threshold = 20%
Mass rate trend filter enabled (fast track active)
Time constant = 10s Fast track threshold = 20%




Mass rate display filter enabled (fast track active)
Time constant = 20s Fast track threshold = 20%
Mass rate trend filter enabled (fast track active)
Time constant = 10s Fast track threshold = 20%


Mass rate display filter enabled (fast track active)
Time constant = 20s Fast track threshold = 20%
Mass rate trend filter enabled (fast track active)
Time constant = 10s Fast track threshold = 20%


Trend filter fast track threshold
20
New value
DEL
CLEAR

Save/Load Setup.

Optimus can be fitted with an optional compact "Flash Card" (32 MB). The card fits into a flash card carrier on the main pcb. The flash card is used to install software (firmware) updates and store Optimus setup and configuration data. The card can accepts 8 setup and configuration data sets. This data can be used to setup Optimus quickly and accurately should the main pcb fail.



Scroll on to save/Load Setup.

The screen will change to the one shown below. This screen shows the compact flash memory is empty (8 dotted lines). The cursor is positioned next to the first entry File 00. Press the F3 "SAVE" key to load flash card memory with the configuration and setup data.



Optimus will now save the data to the next available file. In this case File 00, there will be a small delay between pressing F3 "SAVE" and the screen shown below presenting.

Press "ENTER" to lock in the data to the compact flash memory.

OPTIMUS OPERATIONAL MANUAL.
System Setup / Save / Load Setup.

The card has been loaded with setup and configuration data, which can be used later or sent to Web-Tech for evaluation if there setup is a problem.



To down load previously stored data, select the file required by placing the cursor along side the file and press the F4 “LOAD” key.

When the screen indicates that the file has loaded press “ENTER” to update Optimus.

<u>To Erase Files</u>, select the file to erase by placing the cursor along side it. Then Press F5 “ERASE” it.

OPTIMUS OPERATIONAL MANUAL.
System Setup / Chute Level Control.

Some processes require that the weighfeeder be pre-fed by means other than a choked supply (overhead bin or silo). Generally a volumetric screw feeder is used. This type feeder is unable to control the rate at which product is supplied to a regular weighfeeder inlet chute. A standard weighfeeder inlet chute will have little volumetric capacity and therefore will be subject to the vagaries of the plant demand. As a weighfeeder can only adjust the feed rate by means of belt speed variation, any abnormal deviations from set-point can result in over supply or under supply to the feeder. This will result in the weigh-feeder being either being under supplied or over supplied and the feeder being able to supply a stable mass rate. By increasing the volume of the inlet chute in the horizontal sense and measuring the volume in the extended horizontal chute, Optimus can vary the speed of the pre-feed device. Web-tech manufacture feeder's that have an extended horizontal inlet chutes fitted with material sensing probes. These probes provide Optimus with a map of the volume of product in the inlet chute and therefore the ability to control the rate of product supply to the feeder. By setting up the following menu correctly, Optimus can provide a control signal to control the pre-feed device.
Chute level control is an optional extra and is suitable for use with feeders manufactured with a custom designed material inlet chute.



Scroll to Chute Level Control, press ENTER to set up and modify the chute level control action. At this point assigned probes can be associated with a output speed function. Generally the weighfeeder will have been fitted with three probes prior to despatch. They are referred to as Low, Mid, High. The Low probe is the probe nearest the inlet chute, the High probe is the probe nearest to the shear gate on the feeder and the Mid probe is situated in between the High and Low. None refers to no probe active, all probes out of product. The Ratio refers to the percentage output from the assigned current loop on activation of that probe.
In the following example with no probe active, the current loop driving the prefeed inverter will be driven to 20mA, 100% output. With just the Low probe active and the inlet chute approximately 1/3 full the current loop will be driven to 18.4 mA. When the Low & Mid probes are on the current loop out put will be 16.0 mA and with all three probes on the out put will be 12 mA.



Pressing ENTER will provide the user with an input screen where each probe can be assigned with an output ratio function.



Observe the process and assign a mA output to the assigned current loop that best satisfies the process requirement, when the chute has become empty. Press the tick key to lock in the data and return to the probe assignment screen.



Scroll on to the "Low" probe and assign an output to the current loop.



Scroll on to the "Mid" probe and assign an output to the current loop.



Assign a current output to the activation of the “Mid” probe.



Press the tick key to lock in the data and move back to the probe assignment screen.



Scroll on to the “High” probe current output assignment and press the “ENTER” key gain access to the data entry screen.



Enter the current output required when the chute probe “High” is on and press the tick key to lock in the data and return to the probe assignment screen.

OPTIMUS OPERATIONAL MANUAL.
I/O (Input/Output) / *Current Loop Inputs.*

Optimus provides six for (6) analogue input circuits. One is reserved or the Remote Rate Input. The remaining five are re-assignable. Optimus's analogue inputs are current and can be configured to be one of the following.

4/20mA - 20/4mA - 0/20mA - 20/0mA - 5/25mA - 25/5mA - 0/25mA - 25/0

From the MRMT screen select the Input / Output (I/O) F2 key



Press the "ENTER" key to gain access to the Current Loop Inputs.



Press the "ENTER" key to gain access to the Current Loop 1 Setup screens.



Loop 1 Setup

Note Current Loop Input 1 is reserved for the remote Setpoint input. This is indicated by selection cursor changing from a filled cursor to an outline of a cursor.
The Input display shows the current input signal.



Use the scroll key to advance the cursor to "Type is" Press "ENTER" to gain access to the pre-defined input types. Scroll through the six types of current inputs until you find the one that suites the device that is generating the remote setpoint.



Scroll on to the "Parameters"



OPTIMUS OPERATIONAL MANUAL.
I/O (Input/Output) / *Current Loop Inputs.*

A number of Optimus units can, if required act as a stand alone ratio controllers. The units can be linked via their individual analogue input and output current loops and provide a master slave ratio control over the resultant output from a number of feeders. The following screen provides the user with the means to set up the feeder ratios. In the example below the feeder will produce 60 kg/min at 20mA.









Use the scroll forward key to move the cursor on to the Filtering entry point.



Press the "ENTER" key to gain access to the current loop input filtering, reserved for remote setpoint ("REM SET" as shown on the connection pcb). Scroll on to "Time Constant"



Press "ENTER" to gain access to the data input screen.



Enter the time filtering constant required and press the tick key to lock in the data and return to the loop filter setup screen. Press the scroll forward key to access the Fast Track Threshold.



The “Fast Track Threshold” can be activated by entering a value greater than zero into the screen. The “Fast Track Threshold” works by limiting the filter to working in a band that has been established around the current input. If the input current moves up or down by a value which exceeds the “Fast Track Threshold” the filter time constant will be switched out until a new threshold can be established.



Press the “ENTER” key to gain access to the “Fast Track Filter” data entry screen.



Press the tick key to lock in the data and return to the loop filter setup screen.


Loop input 1 is Remote Setpoint Input = 4.00mA
Type is 4-20 mA Parameters Filtering
Calibrate 0% Current 0% 20.00mA
Calibrate 100% Current 100% 0.00mA

All I/O supplied with Optimus is calibrated by the factory. However the current loop inputs may have to be field calibrated. Scroll on to the “Calibrate 0%” and press the “ENTER” key.


Loop input 1 is Remote Setpoint Input = 4.00mA
Type is 4-20 mA Parameters Filtering
Calibrate 0% Current 0% 20.00mA
Calibrate 100% Current 100% 0.00mA

At this point the current sending device should be forced to send 4 mA. When the loop is set to 4 mA, pressing the “ENTER” key will signal Optimus to calibrate zero.



Scroll on to “Current 0%” . This input screen allows the user to enter the “zero” current as a percentage.



Press the “ENTER” key to access the data entry screen. Using a DVM or other accurate current measuring device read the current flowing in the circuit when at 0 (4mA) and enter it into the screen.

Press the tick key to lock in the data and return to the “Current Loop Setup” screen.
Scroll on to “Calibrate 100%” and press “E NTER” to gain access.



At this point the current loop should be forced to 20mA.



When the current has been forced to 20mA. Press the “ENTER” key to calibrate the 20mA point



Press the tick key to the calibration constant and return to the current loop setup screen.



Scroll on to the “Current 100%”. At this point the current flowing in the loop should be measured using an accurate DVM and the reading entered into the screen.

Pressing the “ENTER” key locks in the calibration constant and returns the user to the loop setup screen.

The remaining 5 analogue input circuits are setup as Loop 1 Remote Setpoint. However the remaining loops can be assigned to pre-assigned labels. Scroll forward to loop 2 and press “ENTER” to gain access to the setup screen for “Loop 2”



On entering the “Loop 2” setup screen press “ENTER” key to gain access to the range of pre-assigned labels. Inclinometer, Temperature, Ratio.



Press the tick key to lock in the data. Continue to set up the remainder of the current loop input as previously shown

OPTIMUS OPERATIONAL MANUAL.
I/O (Input/Output) / *Current Loop Outputs.*

Optimus provides six (6) analogue output signals.

Channel 1 is pre-assigned to Mass Rate.
Channel 2 is pre-assigned to PID Output.
Channel 3 is assignable.
Channel 4 is assignable.
Channel 5 is assignable.
Channel 6 is assignable.



To begin assigning current output loops position the cursor along side Current Loop Outputs.



Loop one is permanently assigned to the Mass Rate. Press “ENTER” to access loop parameters.



The de-highlighted cursor arrow as seen above indicates that associated parameter is inaccessible. Scroll on to the select type of analogue output.

With the cursor pointing at the loop type press the **"ENTER"** key to change the loop to one of the pre-assigned. **(4-20mA : 20-4mA : 0-20mA : 20-0mA : 5-25mA : 25-5mA : 0-25mA : 25-0mA)**



Scroll on to the parameters. Parameters are not editable and therefore the cursor is de-highlighted and the screen is unavailable.



Scroll the cursor on to "Filtering where filters can be applied to the selected loop.



Select the "Time constant" input screen.



Enter the filter time constant required. The value entered here will generally have been selected after observing the process and the response of rate monitoring instrumentation.



Press the tick key to lock in the data and return to the main filter parameter selection screen. Scroll forward to the “Fast Track Threshold” entry point and press the “ENTER” key to gain access.



The “Fast Track Threshold” when active removes the time average filter from the current loop output, when the output current exceeds the “Fast Track Threshold” value.
Assume that the feeder has a capacity of 60 kg/min and the feeder is running at a steady rate of 30 kg/min. If the rate is increased to 45 kg/min. The Mass Rate current output will exceed the 8% threshold. (8% of 60 kg/min = 4.8 kg/min) The filter on the current loop output will be cancelled and the output will immediately rise to 16 mA. (45 kg/min). When Optimus receives two consecutive readings that fall within 10% of each other, the “Fast Track Threshold” will be switched on again.



Enter the “Fast Track Threshold” value required and press the tick key to lock in the data and return to the current loop output setup screen.

OPTIMUS OPERATIONAL MANUAL.
I/O (Input/Output) / *Current Loop Outputs.*

At the time of manufacture and testing all Optimus's input and output facilities are tested against our bench test equipment. Should it become necessary the output current loops can be calibrated. With the cursor opposite "Select calibrate 0%" press "ENTER" to select the "Calibrate 0%" screen.



With suitable test equipment connected across the loop output terminals. Use either the F1 or F2 keys to increase or decrease the output of the circuit until the desired output is achieved. The output will increment or decrement by 0.006 mA per key stroke.



Following the completion of the test press the "ENTER" key to update the working memory and return to the loop parameters. Pushing the cursor's advance key will position the cursor along side the "Current 0%" Use the data entry screen associated with this screen to enter the absolute milliamp value required.



Press the "ENTER" key to access the data entry screen or the + or - key to vary the analogue output in 0.005 mA steps.

From this screen the absolute value for the required output can be entered rather than the predefined steps provided in previous menu's. Type in the value required and press the tick key to lock the data in. The data will only be locked in when the "HOME" key is pressed.



Press the tick key to lock in the data and scroll forward.



Following the setting of the low side of the current loop. Press the Scroll forward key to access the high end of the current loop. The procedure associated with incrementing and decrementing the output of the high end is the same as decrementing the low end.



If the predefined steps do not suit the application requirements then use the screen shown below to adjust the top end using absolute units.



Press the “ENTER” key to access the data entry screen and typing the required value.

Use the tick key lock in the data and return the display to the rate setup screen.



Following the setting up of the **Rate** Loop parameters the **PID** Loop parameters can be set up. Only the Rate signal and PID out puts are permanently assigned to Rate O/P & PID O/P as marked on the connection pcb (Analogue Outputs 1 & 2). The PID loop and the non pre-assigned loops are set up in the same manner as the rate. Press the tick key to go to the Loop Select screen.

All the remaining current loops are setup in the same way as the Rate. Use the scroll keys to access the loops. Loops 3, 4, 5, & 6 can be assigned from 8 pre-assigned labels.

Mass Rate.
PID.
Belt Speed.
Belt Loading.
Chute PID.
Hopper Weight.
Ratio Out.
Manual.



OPTIMUS OPERATIONAL MANUAL.
I/O (Input/Output) / *Digital Inputs.*

Digital Inputs.

Optimus has 6 digital inputs. Each of which can be assigned to a pre-assigned label. The digital inputs have a working voltage of 12-60 VDC. The primary function of these inputs is route weighfeeder status to the optional data network. eg Optional belt drift switch. Generally these inputs are used in conjunction with an optional field bus systems. (Device-Net, Profi-Bus, or Either-Net).

Each of the six digital inputs can be assigned a label. From the factory the labels are pre-assigned as follows:-

Input 1	Feeder Stop
Input 2	Reset Total
Input 3	Low Probe
Input 4	Mid Probe
Input 5	High Probe
Input 6	Not Used.

The interconnect PCB uses the notation “DIG IP1” / “DIG IP6”



The digital Inputs can be assigned names, from a built in pre assigned selection.


Radio button active, filled button.
Radio button in-active, button open.
Input 1 Feeder Stop
Input 2 Low Probe
Input 3 Mid Probe
Input 4 High Probe
Input 5 not used
Input 6 not used

Use the “ENTER” key to assign the digital input with one of the pre-assigned labels. The radio buttons when filled indicate an active input. In the above screen digital Input 1 Feeder Stop is active.

OPTIMUS OPERATIONAL MANUAL.
I/O (Input/Output) / *Digital outputs.*

Optimus has been fitted with 6 digital outputs. Each of which has been pre-assigned a label. The labels are interchangeable. However output one and two are permanently assigned to the "Totaliser" and "System Healthy" function.
From the factory the labels are:-

1	Totaliser.	(Activated on totaliser output.)
2	System Healthy	(Activated on electronic fault detected)
3	Load Cell Alarm.	(Activated on load cell output)
4	Deviation Alarm.	(Activated depending on mass flow)
5	Chute Alarm.	(Activated on inlet chute condition)
6	Rate Alarm.	(Activated on rate condition)

These outputs must be configured as follows prior to correct operation.



Scroll to "Digital Outputs" and press the "ENTER" key to access the output configuration screens. Relay 1 has been pre-assigned to the Totaliser. Relay 2 has been pre-assigned to the "System Healthy"





Press the “ENTER” key to enable or disable the Totaliser output function.



With the function enabled press the scroll forward down to “Emit pulse” function. There are preset output’s.

100
10
1
0.1
0.01
0.001



Scroll on to the “Pulse Width” selection screen to access the preset pulse widths. There are 10 pulse widths to choose from 100m/S - 1000m/S. Choose the pulse width that best suites the application.

Consideration should be given to the response time of the receiver unit (PLC) and the ability of Optimus to output the signal in real time. During the configuration of the outputs Optimus will compute the maximum mass rate achievable for any configuration of Optimus. The reslt being shown on the line **“Maximum mass rate = XXXX kg/min”**



Use the scroll forward screen to access the relay output polarity. The “ENTER” key is used to set the polarity, use the setting that suites your application. Normally Open / Normally Closed

There is no access to this relay. It is energised on power up and is de-energised on power down or an electronic fault condition.

Relay 1 Totaliser
Relay 2 System Healthy
Relay 3 Rate Alarm
Relay 4 Deviation Alarm
Relay 5 Speed Alarm
Relay 6 Load Cell Alarm

Relay's Nº 3-6 can be configured against preset labels. Scroll to Relay Nº3 and press the "ENTER" key to enter the screens.

Relay 1 Totaliser
Relay 2 System Healthy
Relay 3 Not used
Relay 4 Deviation Alarm
Relay 5 Speed Alarm
Relay 6 Load Cell Alarm

Scroll through the predefined labels to select the one that fits the application. Each label has different parameters associated with it. Scroll to Type and select Rate Alarm.

Relay 1 Totaliser
Relay 2 System Healthy
Relay 3 Rate Alarm
Relay 4 Deviation Alarm
Relay 5 Speed Alarm
Relay 6 Load Cell Alarm

Scroll on to the parameters entry point.



Scroll on to the parameters entry point.

On entering the parameters screen. The function can be enabled or disabled using the "ENTER" key. Select enabled and scroll on to the delay set up.



Observe the process and apply the filter time that best suites the application.



Observe the process and apply the filter time that best suites the application. Press "ENTER" key to access the data entry screen



Type in the filter delay required and press the tick key to lock in the value. On returning to the parameters screen scroll on to the level.



On entering the parameters screen. The function can be enabled or disabled using the "ENTER" key. Select enabled and scroll on to the delay set up.



Use the tick key to lock in the entry and return to the parameters screen. Optimus will now calculate and display the mass rate level at which the relay will operate.



Use the tick key to lock in the parameters and return to the relay select screen. Scroll on to relay 4 and allocate it to "Deviation Alarm"

Relay 1 Totaliser
Relay 2 System Healthy
Relay 3 Rate Alarm
Relay 4 Deviation Alarm
Relay 5 Speed Alarm
Relay 6 Load Cell Alarm

Use the "ENTER" key to scroll through relay allocation labels. Select Deviation Alarm, then scroll on to the "Parameters" screen select entry point.



On entry to relay 4 parameters screen enable the alarm, using the “ENTER” key to select the enable label.



Scroll onto the delay before relay operation setting. Observe the process and select the operation delay to suit the application.



Scroll onto the delay before relay operation setting. Observe the process and select the operation delay to suit the application.



Scroll on to the deviation entry point and enter the screen.



Enter the value that suites the application. Press the tick key to lock in the selected value.



Following the entry of a deviation value, the display will return to the parameter entry screen. The deviation value will be shown and directly below this display, Optimus will display the mass rate deviation in the selected units.



Press the tick key to return to relay Nº4 input screen. Scroll on to the polarity and set the polarity required. Use the “ENTER” key to select either Energised outside band or energise inside band.



When done press the tick key to lock in the data and return to the main relay setup screen.

Relay 1 Totaliser
Relay 2 System Healthy
Relay 3 Rate Alarm
Relay 4 Deviation Alarm
Relay 5 Speed Alarm
Relay 6 Load Cell Alarm


1. Current Loop Inputs
2. Current Loop Outputs
3. Digital Inputs
4. Digital Outputs
5. RS-232 Configuration
6. RS-485 Configuration
7. Load cell and tacho
8. DeviceNet


Baud rate 9600 Handshake RTS/CTS
Data Bits 8
Parity none
Stop bits 1


Baud rate 9600 Handshake RTS/CTS
Data Bits 8
Parity none
Stop bits 1


Baud rate 9600 Handshake RTS/CTS
Data Bits 8
Parity none
Stop bits 1


Baud rate 9600 Handshake RTS/CTS
Data Bits 8
Parity none
Stop bits 1


Baud rate 9600 Handshake RTS/CTS
Data Bits 8
Parity none
Stop bits 1

OPTIMUS OPERATIONAL MANUAL.
I/O (Input/Output) / *RS-485 Configuration.*

RS 485 is an optional output. Generally Web-Tech will supply special firmware to support the customers requirements. To set up the link scroll onto the “RS-485 Configuration” data entry point and press the “ENTER” key.



Press the “ENTER” key to select the required baud rate from pre-assigned values.



Scroll on to the “Data Bits” entry point and use the “ENTER” key to select the required data bits from the two values available. (7 & 8)



Scroll onto the “Parity” selection entry point and use the “ENTER” key to select either none or even.



Use the “ENTER” key to select either 1 or 2 stop bits.



Scroll onto the “Handshake” setting entry point. Use the “ENTER” key to scroll between “full duplex or half duplex”.



Following the completion of the setup for the RS-485 specification. Press the tick key to lock in the data and return to the main I/O screen selection.

OPTIMUS OPERATIONAL MANUAL.
I/O (Input/Output) / *Load Cell and Tachometer.*

The “Load Cell and Tacho” screen allows the user to view the output of the load cell and tachometer/encoder. This screen is for viewing and there are no data entry points.



This screen is used as an aid in maintenance. The load cell output and input are shown along with the encoder. The data should be compared with that shown on the system data sheet shipped with the feeder.



OPTIMUS OPERATIONAL MANUAL.
I/O (Input/Output) / *DeviceNet.*

Device Net. **(Optional Supply)**
If Optimus has been supplied with a DeviceNet Card (optional extra) then the following data input screen is used to set up Optimus to communicate over the network. Prior to setting up Optimus to sit on your DeviceNet, network. It is assumed that the installer has a good working knowledge of the DeviceNet protocol and the physical structure of the network.



Press ENTER to access the DeviceNet setup screens.



Pressing the ENTER key will toggle the baud rate between 125 kHz / 250 kHz / 500 kHz
Pressing the either of the two direction arrows will allow the user to select a Mac ID.



A DeviceNet network may have up to 64 (0-63) Media Access Control Identifiers or Mac IDs (node addresses). Each node can support an infinite number of I/O. The user should assign an ID that suits the plant network The ID can be typed directly into the screen. Pressing the tick key locks in the ID selection. Optimus is shipped with a default Mac ID of 63.

OPTIMUS OPERATIONAL MANUAL.
Theory of Operation/ Steps in the Calibration Procedure.

Prior to calibrating Optimus it is suggested that the (I/O & Setup) procedures be completed.

Calibration of Optimus

1) Enter the number of belt revolutions that Optimus will perform the “manual zero” & span over.
2) Perform a manual Zero
3) Apply roller Calibration Chain / Static Bar Weight and perform span.
4) On completion Optimus is calibrated.

OPTIMUS OPERATIONAL MANUAL.
Theory of Operation/ Steps in the Calibration Procedure.

When calibrating a continuous weighing system it should be remembered that the procedure must always be conducted over whole belt revolutions and that the same number of belt revolutions are always used when performing a zero (operator initiated) or span.
To make sure the Zero and Span calibration functions are performed over whole belt revolutions, it is necessary at the time of commissioning to enter the number of revolutions that the procedures require. Generally Web-Tech will enter this data into Optimus for you. However some systems may need to be set up in the field by our customers, the following procedures describe what needs to be taken into consideration before entering the belt revolutions. Generally Web-Tech recommend that the following guide be used for selecting the belt revolutions.

The Zero and Span functions work at their optimum, when the process takes 5 minutes or longer, or a minimum of 5 belt revolutions are used. We therefore recommend that the belt speed be set to the normal operating speed. (Set the inverter to 50 Hz if variable speed is used) Count the belt revolutions that occur within a 5 minute period and if the belt is part way through a whole belt revolution include this revolution. If the number of belt revolution do not add to 5 then wait and use 5 belt revolutions.
These revolutions will be used by Optimus, when ever a Zero or Span is carried out. The number or revolutions entered here should also be used when an empirical test be performed.

Note: A stop watch is required to execute the following procedure.



The diagram above shows the load cell output over 5 belt revolutions. Optimus computes the average zero over the 5 belt revolutions. This format also provides a convenient bases for computing the span. Note that the 5 minute period occurred during the 5th belt revolution and therefore the timed period has been extended by the remainder of the belt revolution.
When a manual Zero is initiated, Optimus gathers load cell data points (one every 5mS) over the number of belt revolutions selected. At the completion of the assigned belt revolutions Optimus will compute the average zero.

OPTIMUS OPERATIONAL MANUAL.

Theory of Operation/ Steps in the Calibration Procedure.

Following the zero computation, Optimus will require calibrating. If Web-tech has supplied the mechanical components of the package, a calibration weight or calibration chain will have been provided. The calibration weight/chain will have been sized to suit the application. Generally the calibration device will have been sized to between 30% & 70% of the maximum mass rate that the feeder was designed for.

Optimus allows for three methods of calibrating. Roller chain with various numbers of strands, anchored over the belt and weigh area during calibration. Static weights in the form of flat or round bar fitted to the weigh deck, under the belt. Or Empirical, where product passing over the feeder is compared with an accurate 'static scale'. A method of calibration will have been selected by Web-Tech technical staff that best suits the application.

To successfully calibrate Optimus using a calibration roller chain or static weight. A target weight has to be calculated for the feeder. The method of calculating this target weight for both roller chain and static weight are shown below.

TARGET WEIGHT CALCULATION FOR WEIGHFEEDERS USING CALIBRATION CHAIN.

Chain weight (kg/m) X N° of Belt Revs X Belt length (m)

TARGET WEIGHT CALCULATION FOR WEIGHFEEDERS USING CALIBRATION WEIGHTS.

Weigh area length (m) X weight (kg) X Belt Length (m) X N° Belt Revolutions






Load Cell Output with the calibration weight in place.
13.0
12.0
11.0
10.0
9.0
8.0
7.0
6.0
5.0
4.0
3.0
2.0
1.0
Load Cell Output in millivolts (indicative)
Load Cell & Tacho integrated to produce total over the prescribed belt revolutions
Average Zero. Computed by Optimus
Whole belt revolution No1
Whole belt revolution No2
Whole belt revolution No3
Whole belt revolution No4
Whole belt revolution No5
5 Minutes
Time taken to complete final whole belt rev.
Zero & Span duration

OPTIMUS OPERATIONAL MANUAL.
Calibration / *Pulses per Revolution.*

Prior to entering the pulses per revolution and the number of revolutions that the Zero and Span will be working over, (see Steps in the **"Calibration Procedure")** preceding this page and familiarise yourself with the concepts. Optimus provides two methods for acquiring the pulses per revolution. An **automatic** method and a **manual** method. The automatic method should be used where possible. To proceeded press the CAL key (F1)



The **manual** procedure for entering the pulses per revolution, has been provided, to provide flexibility that technicians may require when changing electronic parts. Or should the memory become corrupted and the main pcb needs replacing. If the user has maintained the calibration records associated with Optimus, the manual data entry provides a quick method of bring the replacement part on line. Press the CAL button (F1) and the screen will change to the one shown below. Scroll the cursor to the "Pulses per rev" and press the "ENTER" key to access the data input screen. The pulses per revolution can now be entered. Press the tick key to lock in the data and move the cursor on.



Press ENTER to gain access to the screen where pulses per revolution can be entered.



The data entered here must have come from a previous calibration.
Note Incorrect data entry here can invalidate previous calibration!

OPTIMUS OPERATIONAL MANUAL.

Calibration / *Manual Entry of belt revolutions & Zero Calibration.*

Scroll on to the manual belt revolution entry and enter the data entry screen by pressing the "ENTER" key.



Press "ENTER" to access the manual data entry screen.



The data entered here must have come from a previous calibration.
Note Incorrect data entry here can invalidate previous calibration!



Scroll on to the Zero calibration entry and enter the data entry screen by pressing the "ENTER" key. Enter the average zero during the last automatic calibration or use previous data. If this is not available, perform an automatic calibration. This value can't be found any other way other than Optimus computing it.



Scroll on to the AZT (Auto Zero Tracking) entry and enter the data entry screen by pressing the "ENTER" key.





The data entered here must have come from a previous calibration.
Note Incorrect data entry here can invalidate previous calibration!



Scroll on to the span calibration entry point and press the "ENTER" key to enter the manual entry screen and routine.



OPTIMUS OPERATIONAL MANUAL.
Calibration / *Target Weight.*

The calibration target weight should be entered here. Web-Tech will normally supply the target weight along with the static weights or calibration chain required to produce a target weight. The target weight is that weight that that Optimus should equate to when the belt is run over the prescribed number of belt revolution with either a static weight or calibration chain. See "*Theory of Operation/ Steps in the Calibration Procedure.*"



To enter the target weight modify screen, press the "ENTER" key when the selector arrow is along side the entry point.



At this point enter the new target weight and press the tick key to lock in the value.



No access is provided to the speed display. As the belt speed is a derived variable.

Automatic Capture of Pulses per Revolution.

(Note Web-Tech will have done the following prior to delivery)

At this point the user who is calibrating the system should identify or make a easy to see mark on the belt. The mark in conjunction with a fixed reference point on the weigher will be used as a visual aid in determining the point where Optimus will be commanded to start counting pulses This pulses come from the encoder/tachometer. The mark passing the static reference point



Press the “LENGTH” F3 key to go to the pulse acquisition routine. The screen will change to the one shown below.

This calibration is carried out with the belt moving. The number of complete belt revolutions over a time period are counted by the operator, and the Optimus counts the pulses returned from the speed sensor device the number or belt revolutions being entered in an other screen. The screen below is a pause screen allowing the operator to ready before starting the routine.



Press the “START” button, the F1 key, when the mark on the belt coincides with the stationary reference point. The display will change to the one shown below and Optimus will be capturing pulses. When the belt has travelled at least 5 belt revolutions with a minimum time of 5 minutes. Stop the count when the mark on the belt coincides with the static reference.



OPTIMUS OPERATIONAL MANUAL.
Calibration / *Pulses per Revolution / auto capture.*

After using the STOP key (F1) the screen will change to the one shown below. The screen shows all the relevant data relating to the pulse input and provides the link to the entry Pressing the “ENTER”


Tachometer calibration is now complete!
Belt revolutions = 20
Belt revolutions = 20
Calibration time = 300s
Pulses per rev = 5400

At this point the number of belt revolutions over which Optimus captured the pulses must be entered.
Note Only whole belt revolutions must be used and the exact number of revolutions must be entered. Press the tick key to proceed.



At this point Optimus has the data required in order to perform a “manual zero and span”

OPTIMUS OPERATIONAL MANUAL.
Calibration / *Zero.*

Calibration Zero
At this point pressing the F4 key located under the “LENGTH”, will take the user to the screen where the weigher can be readied for zeroing.



Enter the “Zero” screen by pressing the “ZERO” (F4) button.


Press START to begin zero calibration.
Press BACK to return to calibration menu.
Belt must be empty during zero calibration.
Load cell = 3.856
Rate = 0.189kg/min
START
BACK

The zero function will not start until the F1 key located under the “START”
The Zero will now be calculated over the number of belt revolutions previously entered.
The Number of belt revolutions performed, the percentage of the test completed , the load cell output and calculated rate is displayed during the test.


Press BACK to return to the calibration menu.
Make sure there is no material on the belt during test.
Belt revolutions = x.x
Calibration x% complete
Load cell = x.xx mV
Rate x.xxkg/hour
BACK
Number of revs Completed.
Instantaneous Loadcell output
Percent Cal Completed.
Mass rate before zero cal is complete

When the test is complete, at the end of the prescribed number of belt revolutions the display will stop updating.

OPTIMUS OPERATIONAL MANUAL.
Calibration / *Zero.*

Following the completion of the zero test. The screen will change to the one shown below. The three top lines of text will be alternating. If for any reason the test was deemed to be invalid (material falling onto the belt during test etc) pressing the cross button will cancel the result.
On pressing the tick key thee alternating. If for any reason the test was deemed to be invalid (material falling onto the belt during test etc) pressing the cross button will cancel the result.

Load Cell Zero Cal is now complete.
Press ☞ to save new calibration.
Press ☞ to discard new data.
Totaliser Error = x.xxx kg
Zero Cal = xx.xx mV.
AZT Contribution = xx.xx mV.

CALIBRATION SCREEN.



OPTIMUS OPERATIONAL MANUAL.
Calibration / *Span Static Weight Test.*

Enter the "SPAN" screen by pressing the "ZERO" (F5) button.



The screen will change the one shown below. The test will not start until the "START" (F1) key has been pressed. Prior to starting the test the belt must be running and the weight positioned on the weigher. At this point Optimus provides for two methods of spanning. An empirical method or simulated load (fixed weight or calibration chain). Select either by pressing the "START" (F1) key for fixed weight or "EMP" for empirical. The following explains simulated load, (fixed weight / roller calibration chain).


Place calibration weights in position.
Press BACK to return to return to calibration menu.
Press EMP to perform material calibration.
Press START to begin span calibration.
Calibration period = 25 revs
Calibration target = xx.xxkg.
Mass rate = xx.xxkg/min.
START
BACK
EMP

Press the "START" (F1) key to start the test, if the simulated load, (fixed weight / roller calibration chain), static weight test is to be performed.

The screen will change to the one shown below.

The screen displays the current mass rate, the number of belt revolutions completed, the % of the test completed. The total achieved in real time and the total that the test should achieve (Target Weight). On completion of the test Optimus will change the screen.

OPTIMUS OPERATIONAL MANUAL.
Calibration / *Span Static Weight Test.*

Following the completion of the span test the display will change to that shown below.


Press ☞ to save new calibration.
Press ☞ to discard new data.
Span calibration is now complete.
Belt revolutions = aaa
Error = X.XX%
Calibration total = bbb
Calibration target = ccc
Span calibration = dddd

At this screen the calibration can be cancelled by pressing the cross key. Or accepted by pressing the tick key.

aaa = the number of revolutions the test was performed over. (Which must be the number of revolutions entered in the calibration screen.

bbb = the totalised value of the static weight / roller calibration chain achieved during the test.

ccc = the target weight as entered in the first screen of the calibration set up. (usually supplied by Web-Tech).

dddd = the change in span calibration.

X.XXX% = the calculated percentage error between the target weight and achieved total from the test.

Following the completion of the test the result and the acceptance of the test by pressing the tick key the screen will return to the calibration screen.



OPTIMUS OPERATIONAL MANUAL.
Calibration / *Span Empirical.*

The “EMPIRICAL” span test allows the user to run material over the belt and adjust the span against the actual weight passed. The preferred methodology is to pass material over the belt and collect it for weighing on an accurate static scale. This weight “total from an other source” is entered in Optimus


Place calibration weights in position.
Press BACK to return to return to calibration menu.
Press EMP to perform material calibration.
Press START to begin span calibration.
Calibration period = 25 revs
Calibration target = xx.xxkg.
Mass rate = xx.xxkg/min.
START
BACK
EMP

Press the F3 “EMP” key which will open the screen shown below.


Enter total from an other source then press NEXT
Press PREV to return to previous screen.
Total from other source = xxx.xx kg
PREV
NEXT

Press the “ENTER” key in the above screen to enter the data input screen.



At this screen enter the weight that passed over the weigher and that was weighed on an accurate static weigher. (bench scale/weigh bridge etc). Press the tick key to proceed. Optimus will return to the screen shown below. Press the F2 “NEXT” key to go to the data entry point. Where the total obtained by Optimus is to be entered.


Enter total from an other source then press NEXT
Press PREV to return to previous screen.
Total from other source = xxx.xx kg
PREV
NEXT

Press the “ENTER” key to go to the data entry screen where the total obtained by Optimus can be entered.


Enter total from an other source then press NEXT
Press PREV to return to previous screen.
Total from Optimus = xxx.xx kg
PREV
NEXT

In the screen shown below enter the total obtained by Optimus

Press the tick key to lock in the data and move to the previous screen.



At this point a new span needs to be generated. Press the F2 “NEXT” key to generate the new span and move on to the screen shown below.

Empirical span now complete !
Press “☞” to save new calibration data.
Press “☞” to discard new calibration data.
Old span calibration = xx.xxx
New span calibration = yy.yyy
PREV

The above screen shows the new and old spans and allows for the acceptance or rejection of the data. On pressing the tick key Optimus goes back to the calibration screen. The EMPIRICAL span is now complete. Press the “HOME” key to transfer the data to working memory.

OPTIMUS OPERATIONAL MANUAL.
MRMT SCREEN / *Trend.*

Optimus provides the user with a graphical view of the mass rate for the last two minutes. To view the last two minutes of material flow press the “TREND” (F3) key to access the viewing



On entering the mass rate trend screen the last two minutes trend can be cleared by pressing the “CLEAR” (F1) key.



Pressing the “HOME” key will return Optimus to MRMT.

OPTIMUS OPERATIONAL MANUAL.
MRMT SCREEN / *Clear Total.*

The running total can be reset by pressing the “CLEAR” (F4) key.



Prior to clearing the total Optimus will ask for confirmation, prior to acting on the clear command. Press “ENTER” to continue and clear the total. Or press the “ABORT” key if the total should not be cleared.



OPTIMUS OPERATIONAL MANUAL.
MRMT SCREEN / *Info Screen.*

The Optimus firmware (operating software) is under constant review. As the firmware is upgraded it's build number is updated along with the date that it was completed. It may be necessary to view this data from time to time. Press the "INFO" (F6) key to access the information screen.



The screen bellow shows that the firmware release number was 125, dated 21 September 2003



Pressing the "RESET" (F1) from this screen will bring up the following screen. This screen displays the number of times Optimus has had the power removed since the data was last cleared. This is a useful tool if a faulty power supply (mains power) is suspected.
The reset display the number of times the reset button on the main CPU pcb has been activated. Generally this button is used if the Optimus firmware has locked up, owing to a noise spike or other severe transients. Pressing the reset will restart the firmware and increment this counter.
If a "flash memory" card has been purchased and the firmware requires upgrading. The default variables that were established during the calibration and setup can be stored in the flash card and uploaded following the successful firmware upgrade.



The internal temperature is not the ambient air temperature in the cabinet. It is the temperature at the core of the Central Processing Unit (CPU) / computer. The absolute max temp for this device is 55°C. Do not exceed this temperature. Move the enclosure to a cooler environment.

OPTIMUS OPERATIONAL MANUAL.
Electrical / Electronic Notes/ *digital outputs.*

SSR Relay.
The Solid State Relay (SSR) is permanently assigned to the “Totaliser” output. The relay can be physically configured to output +5VDC / +24VDC. The voltage is selected by means of jumpers located at the bottom right hand corner of the “Terminal pcb (JP4) . The use of a solid state relay provides for high frequency counts. However consideration should be given to the receivers ability to handle high frequency counts.





Electro-mechanical Relays. (RLY2 - 5)
Relays 2-6 are assigned via the keyboard (I/O / 4 Digital Outputs). When active the local red LED will illuminated.
The relays can be used as “clean contacts” or supplied with on board +24VDC. Link between +24V and COM. The return is to be terminated on GND.



OPTIMUS OPERATIONAL MANUAL.
Electrical / Electronic Notes *digital inputs.*

Digital Inputs.
Optimus has 6 general purpose digital inputs. They can be assigned to a range of pre– assigned labels ((I/O) 3-Digital inputs). There electrical status can also be observed there also. The applied voltage should not exceed 60VDC and the minimum switching voltage is 5 VDC. These inputs are generally used for monitoring the status of the feeder.

The basic circuit along with an example of a typical connection is shown below.



- +5 - 48 VDC
  Optimus 24VDC
- Is available



REVISIONS	
A: 15/6/06	ISSUED FOR REFERENCE

UNLESS OTHERWISE STATED UNTOLERANCED DIMENSIONS TO BE WITHIN THE LIMITS SHOWN

NOMINAL SIZE	UP TO 50	ABOVE 50 UP TO 150	ABOVE 150 UP TO 300	ABOVE 300 UP TO 1000	ABOVE 1000
MACHINING	± 0.1	± 0.2	± 0.3	± 0.5	± 1.0
FABRICATION	± 0.5	± 0.5	± 0.5	± 1.0	± 2.0
ASSEMBLIES	± 0.5	± 0.5	± 0.5	± 1.0	± 2.0

DRAWN	L.H.
CHECKED	L.H.
APPROVED	L.H.
DATE APP'D	15/6/06
SCALE	N.T.S.

DO NOT SCALE IF IN DOUBT ASK

WEB–TECH AUSTRALIA PTY. LTD.
A.C.N. 010 764 431
11 ELECTRONICS STREET EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA
P.O. BOX 4006 EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA
Phone +61–7–3841 2844 Fax +61–7–3841 0005

TITLE
OPTIMUS POWER BOARD TERMINATION LAYOUT – AC MAINS SUPPLY.

ALL DIMENSIONS IN MILLIMETRES UNLESS OTHERWISE SPECIFIED

This drawing and any information or descriptive matter set out hereon are the confidential and copyright property of WEB–TECH AUSTRALIA PTY. LTD.© and must not be disclosed, loaned, copied or used for manufacturing / tendering or for any other purpose without their written permission.

SIZE	DRAWING No.	
	NUMBER	REV.
A1	WFOPTIMUS03	A

CUSTOMER

PROJECT

CAD FILE
WFOPTIMUS03



TB11



TB12



TB16

(SEE NOTE 4.)



TB17



TB18



TB19





NOTES

1. SPARE ANALOG OUTPUTS MAY BE PROGRAMMED FOR ONE OF THE FOLLOWING: MASS RATE / PID / BELT LOADING
2. SPARE DIGITAL OUTPUTS MAY BE PROGRAMMED FOR ONE OF THE FOLLOWING: RATE ALARM / DEVIATION ALARM / TOTALISER / SPEED ALARM / LOAD CELL ALARM CHUTE ALARM.
3. DIGITAL INPUTS MAY BE PROGRAMMED FOR ONE OF THE FOLLOWING: FEEDER STOP / RESET TOTAL / LOW PROBE / MID PROBE / HIGH PROBE. SIGNAL TO BE HIGH (24VDC) TO OPERATE.
4. SET SENSE LINKS TO "LOCAL" WHEN USING 4 WIRE LOAD CELLS. SET LINKS TO "REMOTE" WHEN USING 6 WIRE LOAD CELLS. UNUSED LOAD CELL CHANNELS SHOULD BE SET TO "LOCAL".

REVISIONS

A: 15/6/06 ISSUED FOR REFERENCE

UNLESS OTHERWISE STATED UNTOLERANCED DIMENSIONS TO BE WITHIN THE LIMITS SHOWN						
NOMINAL SIZE	UP TO 50	ABOVE 50 UP TO 150	ABOVE 150 UP TO 300	ABOVE 300 UP TO 1000	ABOVE 1000	
MACHINING	± 0.1	± 0.2	± 0.3	± 0.5	± 1.0	
FABRICATION	± 0.5	± 0.5	± 0.5	± 1.0	± 2.0	
ASSEMBLIES	± 0.5	± 0.5	± 0.5	± 1.0	± 2.0	

DRAWN	L.H.
CHECKED	L.H.
APPROVED	L.H.
DATE APP'D	15/6/06
SCALE	NTS
	DO NOT SCALE IF IN DOUBT ASK

WEB-TECH AUSTRALIA PTY. LTD.
A.C.N. 010 764 431
11 ELECTRONICS STREET EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA
P.O. BOX 4006 EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA
Phone +61-7-3841 2844 Fax +61-7-3841 0005

SIZE	DRAWING No.	
A1	NUMBER WFOPTIMUS02	REV. A

TITLE: OPTIMUS INTERCONNECTION BOARD – ELECTRICAL CONNECTION DIAGRAM FOR WEIGH BELT FEEDERS.

CUSTOMER

PROJECT

CAD FILE WFOPTIMUS02

ALL DIMENSIONS IN MILLIMETRES UNLESS OTHERWISE SPECIFIED

This drawing and any information or descriptive matter set out hereon are the confidential and copyright property of WEB-TECH AUSTRALIA PTY. LTD.© and must not be disclosed, loaned, copied or used for manufacturing / tendering or for any other purpose without their written permission.



INTERCONNECTION BOARD



POWER SUPPLY BOARD

REVISIONS	
A:	15/6/06
	ISSUED FOR REFERENCE

UNLESS OTHERWISE STATED UNTOLERANCED DIMENSIONS TO BE WITHIN THE LIMITS SHOWN					
NOMINAL SIZE	UP TO 50	ABOVE 50 UP TO 150	ABOVE 150 UP TO 300	ABOVE 300 UP TO 1000	ABOVE 1000
MACHINING	± 0.1	± 0.2	± 0.3	± 0.5	± 1.0
FABRICATION	± 0.5	± 0.5	± 0.5	± 1.0	± 2.0
ASSEMBLIES	± 0.5	± 0.5	± 0.5	± 1.0	± 2.0

DRAWN	L.H.
CHECKED	L.H.
APPROVED	L.H.
DATE APP'D	15/6/06
SCALE	N.T.S.
	DO NOT SCALE IF IN DOUBT ASK

WEB-TECH AUSTRALIA PTY. LTD.
A.C.N. 010 764 431
11 ELECTRONICS STREET EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA
P.O. BOX 4006 EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA
Phone +61-7-3841 2844 Fax +61-7-3841 0005

TITLE: OPTIMUS INTERCONNECT & POWER BOARD TERMINATION LAYOUT- AC MAINS SUPPLY.

ALL DIMENSIONS IN MILLIMETRES UNLESS OTHERWISE SPECIFIED

This drawing and any information or descriptive matter set out hereon are the confidential and copyright property of WEB-TECH AUSTRALIA PTY. LTD.© and must not be disclosed, loaned, copied or used for manufacturing / tendering or for any other purpose without their written permission.

SIZE	DRAWING No.	
A1	NUMBER WFOPTIMUS01	REV. A
	CUSTOMER	
	PROJECT	
	CAD FILE WFOPTIMUS01	



REVISIONS	
A: 15/6/06	ISSUED FOR REFERENCE

UNLESS OTHERWISE STATED UNTOLERANCED DIMENSIONS TO BE WITHIN THE LIMITS SHOWN

NOMINAL SIZE	UP TO 50	ABOVE 50 UP TO 150	ABOVE 150 UP TO 300	ABOVE 300 UP TO 1000	ABOVE 1000
MACHINING	± 0.1	± 0.2	± 0.3	± 0.5	± 1.0
FABRICATION	± 0.5	± 0.5	± 0.5	± 1.0	± 2.0
ASSEMBLIES	± 0.5	± 0.5	± 0.5	± 1.0	± 2.0

DRAWN	L.H.
CHECKED	
APPROVED	
DATE APP'D	
SCALE	

DO NOT SCALE IF IN DOUBT ASK

WEB-TECH AUSTRALIA PTY. LTD.
A.C.N. 010 764 431
11 ELECTRONICS STREET EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA
P.O. BOX 4006 EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA
Phone +61-7-3841 2844 Fax +61-7-3841 0005

TITLE
OPTIMUS POWER BOARD TERMINATION
LAYOUT – 24VDC SUPPLY.

ALL DIMENSIONS IN MILLIMETRES UNLESS OTHERWISE SPECIFIED

This drawing and any information or descriptive matter set out hereon are the confidential and copyright property of WEB-TECH AUSTRALIA PTY. LTD.© and must not be disclosed, loaned, copied or used for manufacturing / tendering or for any other purpose without their written permission.

SIZE	DRAWING No.	
A1	NUMBER WFOPTIMUS05	REV. A
	CUSTOMER	
	PROJECT	
	CAD FILE WFOPTIMUS05	



INTERCONNECTION BOARD



POWER SUPPLY BOARD

REVISIONS	
A: 15/6/06	ISSUED FOR REFERENCE

UNLESS OTHERWISE STATED UNTOLERANCED DIMENSIONS TO BE WITHIN THE LIMITS SHOWN

NOMINAL SIZE	UP TO 50	ABOVE 50 UP TO 150	ABOVE 150 UP TO 300	ABOVE 300 UP TO 1000	ABOVE 1000
MACHINING	± 0.1	± 0.2	± 0.3	± 0.5	± 1.0
FABRICATION	± 0.5	± 0.5	± 0.5	± 1.0	± 2.0
ASSEMBLIES	± 0.5	± 0.5	± 0.5	± 1.0	± 2.0

DRAWN	L.H.
CHECKED	L.H.
APPROVED	L.H.
DATE APP'D	15/6/06
SCALE	N.T.S.
	DO NOT SCALE IF IN DOUBT ASK

WEB-TECH AUSTRALIA PTY. LTD.
A.C.N. 010 764 431
11 ELECTRONICS STREET EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA
P.O. BOX 4006 EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA
Phone +61-7-3841 2844 Fax +61-7-3841 0005

SIZE	DRAWING No.	
A1	NUMBER WFOPTIMUS04	REV. A

TITLE: OPTIMUS INTERCONNECT & POWER BOARD TERMINATION LAYOUT – 24VDC SUPPLY.

CUSTOMER

PROJECT

CAD FILE WFOPTIMUS04

ALL DIMENSIONS IN MILLIMETRES UNLESS OTHERWISE SPECIFIED

This drawing and any information or descriptive matter set out hereon are the confidential and copyright property of WEB-TECH AUSTRALIA PTY. LTD.© and must not be disclosed, loaned, copied or used for manufacturing / tendering or for any other purpose without their written permission.



TB11



TB12



TB16

(SEE NOTE 4.)





TB17



TB18



TB19



NOTES

1. SPARE ANALOG OUTPUTS MAY BE PROGRAMMED FOR ONE OF THE FOLLOWING: MASS RATE / PID / BELT LOADING
2. SPARE DIGITAL OUTPUTS MAY BE PROGRAMMED FOR ONE OF THE FOLLOWING: RATE ALARM / DEVIATION ALARM / TOTALISER / SPEED ALARM / LOAD CELL ALARM CHUTE ALARM.
3. DIGITAL INPUTS MAY BE PROGRAMMED FOR ONE OF THE FOLLOWING: FEEDER STOP / RESET TOTAL / LOW PROBE / MID PROBE / HIGH PROBE. SIGNAL TO BE HIGH (24VDC) TO OPERATE.
4. SET SENSE LINKS TO "LOCAL" WHEN USING 4 WIRE LOAD CELLS. SET LINKS TO "REMOTE" WHEN USING 6 WIRE LOAD CELLS. UNUSED LOAD CELL CHANNELS SHOULD BE SET TO "LOCAL".

REVISIONS

A: 15/6/06 ISSUED FOR REFERENCE

UNLESS OTHERWISE STATED UNTOLERANCED DIMENSIONS TO BE WITHIN THE LIMITS SHOWN

NOMINAL SIZE	UP TO 50	ABOVE 50 UP TO 150	ABOVE 150 UP TO 300	ABOVE 300 UP TO 1000	ABOVE 1000
MACHINING	± 0.1	± 0.2	± 0.3	± 0.5	± 1.0
FABRICATION	± 0.5	± 0.5	± 0.5	± 1.0	± 2.0
ASSEMBLIES	± 0.5	± 0.5	± 0.5	± 1.0	± 2.0

DRAWN	L.H.
CHECKED	L.H.
APPROVED	L.H.
DATE APP'D	15/6/06
SCALE	NTS
	DO NOT SCALE IF IN DOUBT ASK

WEB-TECH AUSTRALIA PTY. LTD.

A.C.N. 010 764 431

11 ELECTRONICS STREET EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA

P.O. BOX 4006 EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA

Phone +61-7-3841 2844 Fax +61-7-3841 0005

TITLE OPTIMUS INTERCONNECTION BOARD – ELECTRICAL CONNECTION DIAGRAM FOR WEIGH BELT FEEDERS WITH CHUTE CONTROL LEVEL PROBES.

ALL DIMENSIONS IN MILLIMETRES UNLESS OTHERWISE SPECIFIED

This drawing and any information or descriptive matter set out hereon are the confidential and copyright property of WEB-TECH AUSTRALIA PTY. LTD.© and must not be disclosed, loaned, copied or used for manufacturing / tendering or for any other purpose without their written permission.

SIZE	DRAWING No. NUMBER	REV.
A1	WFOPTIMUS02LEVEL	A

CUSTOMER

PROJECT

CAD FILE WFOPTIMUS02LEVEL

DEVICENET CARD OPTION



DEVICENET NOTES

1. PLEASE NOTE THE ORIENTATION OF THE TERMINATIONS.
2. YOU MUST ENSURE THAT 120 OHM, 0.5W TERMINATION RESISTORS ARE INSTALLED BETWEEN "CAN HI" & "CAN LO" AT THE TWO ENDS OF THE DEVICENET NETWORK. IF THE OPTIMUS IS THE LAST DEVICE ON THE NETWORK, INSTALL THE TERMINATION RESISTOR DIRECTLY INTO THE PLUG.
3. CONFIGURE THE DEVICENET MAC-ID AND BAUD RATE BY ENTERING THE "SETUP" MENU.
4. THE MAC-ID CAN BE SET TO ANY NUMBER BETWEEN 1 AND 23. EACH DEVICE ON THE NETWORK MUST BE ASSIGNED A UNIQUE MAC-ID.
5. THE BAUD RATE MAY BE SET TO A SPEED OF 125kHz, 250kHz OR 500kHz. ALL DEVICES ON THE NETWORK MUST BE CONFIGURED TO USE THE SAME BAUD RATE. THE BAUD RATE CHOSEN WILL DEPEND ON CABLE LENGTH AND QUALITY.
6. IF YOU CHANGE EITHER THE MAC-ID OR BAUD RATE, YOU MUST PRESS THE "CONFIG" BUTTON IN ORDER TO WRITE YOUR CHANGES TO THE OPTIMUS DEVICENET MODULE. PRESSING "TICK" OR "HOME" WILL NOT SAVE THESE SETTINGS. ONCE CONFIGURED, THE SETTINGS WILL BE RETAINED BETWEEN POWERUPS.

PROFIBUS CARD OPTION



PIN DESIGNATION
1 – NOT USED
2 – NOT USED
3 – RXD/TXD-P (LINE B RED)
4 – NOT USED
5 – DGND
6 – VP (+5V)
7 – NOT USED
8 – RXD/TXD-N (LINE A GREEN)

PROFIBUS NOTES

1. PLEASE NOTE THE ORIENTATION OF THE TERMINATIONS.
2. YOU MUST ENSURE THAT 220 OHM, 0.5W TERMINATION RESISTORS ARE INSTALLED BETWEEN "LINE A" & "LINE B" AND 390 OHMS BETWEEN "VP" & "LINE B", AND "DGND" & "LINE B". AT THE TWO ENDS OF THE DEVICENET NETWORK. IF THE OPTIMUS IS THE LAST DEVICE ON THE NETWORK, INSTALL THE TERMINATION RESISTORS USING THE LINKS ON THE PROFIBUS BOARD.
3. CONFIGURE THE PROFIBUS DEVICE ID AND BAUD RATE BY ENTERING THE "SETUP" MENU.
4. THE ID CAN BE SET TO ANY NUMBER BETWEEN 0 AND 125. EACH DEVICE ON THE NETWORK MUST BE ASSIGNED A UNIQUE ID.
5. THE BAUD RATE MAY BE SET TO A SPEED OF BETWEEN 9600 Hz TO 12 MHz. ALL DEVICES ON THE NETWORK MUST BE CONFIGURED TO USE THE SAME BAUD RATE. THE BAUD RATE CHOSEN WILL DEPEND ON CABLE LENGTH AND QUALITY.
6. IF YOU CHANGE EITHER THE ID OR BAUD RATE, YOU MUST PRESS THE "CONFIG" BUTTON IN ORDER TO WRITE YOUR CHANGES TO THE OPTIMUS PROFIBUS MODULE. PRESSING "TICK" OR "HOME" WILL NOT SAVE THESE SETTINGS. ONCE CONFIGURED, THE SETTINGS WILL BE RETAINED BETWEEN POWERUPS.

REVISIONS
A: 19/12/06 ORIGINAL ISSUE

DRAWN	L.H.
CHECKED	L.H.
APPROVED	M.W.
DATE APP'D	20/12/06
SCALE	N.T.S.
	DO NOT SCALE IF IN DOUBT ASK

WEB-TECH AUSTRALIA PTY. LTD.
A.C.N. 010 764 431
11 ELECTRONICS STREET EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA
P.O. BOX 4006 EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA
Phone +61-7-3841 2844 Fax +61-7-3841 0005

TITLE: OPTIMUS ELECTRONICS – DEVICENET AND PROFIBUS CARDS – TERMINATION DETAILS AND NOTES.

SIZE	DRAWING No.	REV.
A1	OPTIMUS11	A

CUSTOMER
PROJECT
CAD FILE: OPTIMUS11

ALL DIMENSIONS IN MILLIMETRES UNLESS OTHERWISE SPECIFIED

This drawing and any information or descriptive matter set out hereon are the confidential and copyright property of WEB-TECH AUSTRALIA PTY. LTD. © and must not be disclosed, loaned, copied or used for manufacturing / tendering or for any other purpose without their written permission.

SECTION 6 - CALIBRATION

The weighfeeder has been programmed and calibrated at the factory. However, due to changes that may have occurred during transit and installation, the weighfeeder calibration should be checked. The calibrations once initiated are automatic and only require the pressing of acceptance key(s).

The two basic calibration steps are the “Zero” calibration and the “Span” calibration.

Zero Calibration

The zero calibration is established by running the weighfeeder empty of a programmed number of belt revolutions and calculating the average load cell output during this period. The weighfeeder electronics will automatically calculate the zero value when the test has been initiated and completed. Refer to the electronics manual supplied with your WT1200 (Masterweigh 1/Masterweigh 5 or Optimus) for the section called “Load Zero Calibration” for the procedure. The weighfeeder must be able to be run empty during this test, and the number of belt revolutions programmed for its duration can be found on the calibration sheets at the end of this manual.

Span Calibration

The span calibration is generally carried out on a model WT1200 weighfeeder with the use of calibration “chains”. The calibration chain consists of one or more strands of roller chain attached to a restraining bracket. The size of the chain and number of strands has been calculated by us to simulate approximately 75% of the maximum capacity. The calibration chain is placed on the belt and attached to the inlet chute (or rear wall for horseshoe inlet). The weighfeeder is run and the test is carried out over the same number of belt revolutions as the zero test. The result is compared to a value (Target Weight) calculated by us at the time of factory commissioning. The procedure for carrying out the test can be found in the “Fixed Weight Calibrate” menu of the electronics manual. The “Target Weight” can be found on the calibration sheets in this manual.

Material Test

We strongly suggest that a material test be carried out where possible. A material test involves weighing product on an accurate static scale prior to, or after it has passed over the weighfeeder. When carrying out a material test, the following should be considered:

1. The amount of material required for the test(s) must be proportional to the weighfeeder capacity. A rule of thumb quantity would be a minimum of 3 minutes of running time at maximum capacity e.g. if the capacity is 10 tph, the amount of material would be 10 0000 kg/60 x 3 = 500 kg. A smaller amount could be used, however it must be understood that the accuracy achievable may be diminished due to the resolution used.
2. It must be guaranteed that all of the material used in the test is collected, or have passed over the weighfeeder.
3. The material feed over the weighfeeder must be continuous and consistent.

When the test(s) have been carried out any correction to the calibration can be carried out in the “Emperical Calibration” menu of the electronics (refer to the electronics manual section).

Any changes to the calibration should be recorded on the calibration sheets for future reference.

Allen-Bradley

PowerFlex®

70 & 700 Adjustable Frequency AC Drive

70 Firmware Versions
Standard Control xxx.x - 2.001
Enhanced Control xxx.x - 2.xxx

700 Firmware Versions
Standard Control xxx.x - 3.001
Vector Control xxx.x - 3.001

Reference Manual

Rockwell Automation

Important User Information

Solid state equipment has operational characteristics differing from those of electromechanical equipment. *Safety Guidelines for the Application, Installation and Maintenance of Solid State Controls* (Publication SGI-1.1 available from your local Rockwell Automation sales office or **www.rockwellautomation.com/literature**) describes some important differences between solid state equipment and hard-wired electromechanical devices. Because of this difference, and also because of the wide variety of uses for solid state equipment, all persons responsible for applying this equipment must satisfy themselves that each intended application of this equipment is acceptable.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc. is prohibited.

Throughout this manual we use notes to make you aware of safety considerations.

WARNING: Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.

Important: Identifies information that is critical for successful application and understanding of the product.

ATTENTION: Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you:

- identify a hazard
- avoid the hazard
- recognize the consequences

Shock Hazard labels may be located on or inside the drive to alert people that dangerous voltage may be present.

Burn Hazard labels may be located on or inside the drive to alert people that surfaces may be at dangerous temperatures.

Manual Conventions

Standard = Indicates that the information presented is specific to the Standard Control Option.

Vector = This information only applies to PowerFlex 700 drives with the Vector Control option.

Vector FV = Applies to PowerFlex 700 drives with [Motor Cntl Sel] set to "FVC Vector."

E C = Indicates that the information presented is specific to the PowerFlex 70 Enhanced Control Option.

DriveExplorer, DriveExecutive and SCANport are trademarks of Rockwell Automation, Inc.
PowerFlex and PLC are registered trademarks of Rockwell Automation, Inc.
ControlNet is a trademark of ControlNet International, Ltd.
DeviceNet is a trademark of the Open DeviceNet Vendor Association.

The information below summarizes the changes to the PowerFlex 70/700 Reference Manual, publication PFLEX-RM001 since the last release.

Change	Page
PowerFlex 700 60 HP, 600V Derate added	1-6
PowerFlex 70 dimensions updated	1-7
PowerFlex 700 Frame 4 dimensions updated	1-14
Analog Input Cable Selection updated	2-18
PowerFlex 700 Analog Output info added for firmware 3.001 & later	2-24
“Bus Regulation” section updated	2-49 - 2-51
Digital Input Cable Selection updated	2-61
PowerFlex 700 Digital Output info added for firmware 3.001 & later	2-82
Fuse & Circuit Breaker tables updated	2-101 - 2-106
Bypass Contactor Attention statement added	2-121
PowerFlex 700 Process PI info added for firmware 3.001 & later	2-150
Scale Blocks sections added	2-157
PowerFlex 700 Torque Reference info added for firmware 3.001 & later	2-209
Dynamic Brake Selection Guide updated	A-1

Notes:

Chapter 1 Specifications & Dimensions

PowerFlex 70/700 Specifications 1-1
Input/Output Ratings 1-3
Heat Dissipation 1-3
Derating Guidelines 1-3
PowerFlex 70 Dimensions 1-7
PowerFlex 700 Dimensions 1-13

Chapter 2 Detailed Drive Operation

Accel Time 2-1
Advanced Tuning 2-2
Alarms 2-5
Analog Inputs 2-9
Analog Outputs. 2-21
Auto/Manual. 2-27
Auto Restart (Reset/Run) 2-29
Autotune 2-31
Block Diagrams 2-34
Bus Regulation 2-46
Cable, Control 2-51
Cable, Motor Lengths. 2-51
Cable, Power. 2-51
CabIe Trays and Conduit 2-51
Carrier (PWM) Frequency 2-52
CE Conformity 2-53
Copy Cat. 2-55
Current Limit 2-56
Datalinks. 2-58
DC Bus Voltage / Memory 2-60
Decel Time 2-60
Digital Inputs 2-61
Digital Outputs 2-78
Direction Control 2-82
DPI 2-83
Drive Overload 2-86
Drive Ratings (kW, Amps, Volts) 2-90
Droop 2-90
Economizer (Auto-Economizer) 2-91
Efficiency 2-91
Fan Curve 2-92
Fan 2-92
Faults 2-93
Flux Braking. 2-96
Flux Up. 2-97
Flying Start. 2-98
Fuses and Circuit Breakers. 2-100
Grounding, General 2-107
HIM Memory 2-107
HIM Operations 2-107
Input Devices 2-108
Input Modes 2-109
Input Power Conditioning 2-110
Jog 2-110
Language 2-111
Linking Parameters. 2-112
Masks 2-114
MOP 2-115

Motor Control 2-116
Motor Nameplate 2-117
Motor Overload 2-118
Motor Start/Stop Precautions 2-121
Mounting 2-122
Notch Filter 2-122
Output Current 2-124
Output Devices 2-124
Output Frequency 2-125
Output Power 2-125
Output Voltage 2-125
Overspeed Limit 2-126
Owners 2-127
Parameter Access Level 2-129
PET 2-129
Power Loss 2-130
Preset Frequency 2-137
Process PI Loop 2-137
Reflected Wave 2-152
Regen Power Limit 2-154
Reset Meters 2-154
Reset Run 2-154
RFI Filter Grounding 2-154
S Curve 2-154
Scale Blocks 2-157
Shear Pin Fault 2-160
Skip Frequency 2-161
Sleep Mode 2-163
Speed Control, Mode, Regulation & Vector Speed Feedback 2-166
Speed Feedback Filter 2-170
Speed Reference 2-171
Speed Regulator 2-176
Speed/Torque Select 2-177
Speed Units 2-180
Start Inhibits 2-180
Start Permissives 2-180
Start-Up 2-181
Stop Modes 2-201
Test Points 2-204
Thermal Regulator 2-204
Torque Limits 2-204
Torque Performance Modes 2-205
Torque Reference 2-208
Troubleshooting 2-209
Unbalanced or Ungrounded Distribution Systems 2-210
User Sets 2-210
Voltage Class 2-211
Voltage Tolerance 2-212
Watts Loss 2-213

Appendix A Dynamic Brake Selection Guide

Table of Contents

Section 1

Understanding How Dynamic Braking Works 1-1
Dynamic Brake Components 1-2

Section 2

Determining Dynamic Brake Requirements 2-1
How to Determine Dynamic Brake Requirements 2-1
Determine Values of Equation Variables 2-4
Example Calculation 2-9

Section 3

Evaluating the Internal Resistor 3-1
Evaluating the Capability of the Internal Dynamic Brake Resistor 3-1
PowerFlex 70 Power Curves 3-4
PowerFlex 700 Power Curves 3-8

Section 4

Selecting An External Resistor. 4-1
How to Select an External Dynamic Brake Resistor 4-1

Index

Specifications & Dimensions

PowerFlex 70/700 Specifications

Category	Specification					
Agency Certification	PF70			PF700		
	Type 1, IP 30	*Flange Type*	*Type 4X/ 12, IP 66*	*All*	Description	
	✔	✔	✔	✔	c UL us	Listed to UL508C and CAN/CSA-C2.2 No. 14-M91.
		✔				Listed to UL508C for plenums (Rear heatsink only)
	✔	✔	✔	✔	CE	Marked for all applicable European Directives(1) EMC Directive (89/336/EEC) EN 61800-3 Adjustable Speed electrical power drive systems Low Voltage Directive (73/23/EEC) EN 50178 Electronic Equipment for use in Power Installations
	✔	✔	✔	✔	C N223	Certified to AS/NZS, 1997 Group 1, Class A.
			✔		NSF	Certified to Criteria C-2, 1983.
	The drive is also designed to meet the following specifications: NFPA 70 - US National Electrical Code NEMA ICS 3.1 - Safety standards for Construction and Guide for Selection, Installation and Operation of Adjustable Speed Drive Systems. IEC 146 - International Electrical Code.					

(1) Applied noise impulses may be counted in addition to the standard pulse train causing erroneously high [Pulse Freq] readings.

Category	Specification						
Protection	**PowerFlex 70 Drive**	**200-208V Drive**	**240V Drive**	**380/400 Drive**	**480V Drive**	**600V Drive**	**690V Drive**
	AC Input Overvoltage Trip:	247VAC	285VAC	475VAC	570VAC	690VAC	
	AC Input Undervoltage Trip:	120VAC	138VAC	233VAC	280VAC	345VAC	
	Bus Overvoltage Trip:	405VDC	405VDC	810VDC	810VDC	1013VDC	
	Bus Undervoltage Output Shutoff:	204VDC	204VDC	407VDC	407VDC	508VDC	
	Bus Undervoltage Fault Level:	160VDC	160VDC	300VDC	300VDC	375VDC	
	Nominal Bus Voltage:	281VDC	324VDC	540VDC	648VDC	810VDC	
	PowerFlex 700						
	AC Input Overvoltage Trip:	See PowerFlex 70 above					
	AC Input Undervoltage Trip:						
	Bus Overvoltage Trip:						
	Bus Undervoltage Shutoff & Fault:	153VDC	153VDC	305VDC	305VDC	381VDC	
	Nominal Bus Voltage:	See PowerFlex 70 above					
	All Drives						
	Heat Sink Thermistor:	Monitored by microprocessor overtemp trip					
	Drive Overcurrent Trip Software Overcurrent Trip: Hardware Overcurrent Trip:	 200% of rated current (typical) 220-300% of rated current (dependent on drive rating)					
	Line transients:	up to 6000 volts peak per IEEE C62.41-1991					
	Control Logic Noise Immunity:	Showering arc transients up to 1500V peak					
	Power Ride-Thru:	15 milliseconds at full load					
	Logic Control Ride-Thru:	0.5 seconds minimum, 2 seconds typical					
	Ground Fault Trip:	Phase-to-ground on drive output					
	Short Circuit Trip:	Phase-to-phase on drive output					

Category	Specification	
Environment	Altitude:	1000 m (3300 ft) max. without derating
	Maximum Surrounding Air Temperature without Derating: **PowerFlex 70** IP20, NEMA Type 1: Flange Mount: IP66, NEMA Type 4X/12: **PowerFlex 700** IP20, NEMA Type 1:	 0 to 50 degrees C (32 to 122 degrees F) 0 to 50 degrees C (32 to 122 degrees F) 0 to 40 degrees C (32 to 104 degrees F) 0 to 50 degrees C (32 to 122 degrees F)
	Storage Temperature (all const.):	–40 to 70 degrees C (–40 to 158 degrees F)
	Atmosphere	**Important:** Drive **must not** be installed in an area where the ambient atmosphere contains volatile or corrosive gas, vapors or dust. If the drive is not going to be installed for a period of time, it must be stored in an area where it will not be exposed to a corrosive atmosphere.
	Relative Humidity:	5 to 95% non-condensing
	Shock:	15G peak for 11ms duration (±1.0 ms)
	Vibration:	0.152 mm (0.006 in.) displacement, 1G peak
Electrical	Voltage Tolerance:	See Voltage Tolerance on page 2-212
	Frequency Tolerance:	47-63 Hz.
	Input Phases:	Three-phase input provides full rating for all drives. Single-phase operation provides 50% of rated current.
	Displacement Power Factor All Drives:	 0.98 across entire speed range.
	Efficiency:	97.5% at rated amps, nominal line volts.
	Maximum Short Circuit Rating:	200,000 Amps symmetrical.
	Actual Short Circuit Rating:	Determined by AIC rating of installed fuse/circuit breaker.
Control	Method:	Sine coded PWM with programmable carrier frequency. Ratings apply to all drives (refer to the *Derating Guidelines* on page 1-3). The drive can be supplied as 6 pulse or 12 pulse in a configured package.
	Carrier Frequency PF70: PF700:	Drive rating based on 4 kHz 2, 4, 8 & 10 kHz Standard; 2, 4, 8 & 12 kHz E C 2, 4, 8 & 10 kHz
	Output Voltage Range:	0 to rated motor voltage
	Output Frequency Range: PF70: PF700:	 0 to 400 Hz Standard, 0 to 500 Hz E C 0 to 400 Hz Standard, 0 to 420 Hz Vector
	Frequency Accuracy Digital Input: Analog Input:	 Within ±0.01% of set output frequency. Within ±0.4% of maximum output frequency.
	Frequency Control	Speed Regulation - w/Slip Compensation (Volts per Hertz Mode) Standard Vector 0.5% of base speed across 40:1 speed range 40:1 operating range 10 rad/sec bandwidth
		Speed Regulation - w/Slip Compensation (Sensorless Vector Mode) Standard Vector 0.5% of base speed across 80:1 speed range 80:1 operating range 20 rad/sec bandwidth
		Speed Regulation - w/Feedback (Sensorless Vector Mode) Vector 0.1% of base speed across 80:1 speed range 80:1 operating range 20 rad/sec bandwidth
	Speed Control	Speed Regulation - w/o Feedback (Vector Control Mode) Vector 0.1% of base speed across 120:1speed range 120:1 operating range 50 rad/sec bandwidth
		Speed Regulation - w/Feedback (Vector Control Mode) Vector 0.001% of base speed across 120:1 speed range 1000:1 operating range 250 rad/sec bandwidth

Category	Specification	
Control *(continued)*	Torque Regulation	Torque Regulation - without feedback ±10%, 600 rad/sec bandwidth **Vector**
		Torque Regulation - with feedback ±5%, 2500 rad/sec bandwidth **Vector**
	Selectable Motor Control:	Sensorless Vector with full tuning. Standard V/Hz with full custom capability. PF700 adds Vector Control.
	Stop Modes:	Multiple programmable stop modes including - Ramp, Coast, DC-Brake, Ramp-to-Hold and S-curve.
	Accel/Decel:	Two independently programmable accel and decel times. Each time may be programmed from 0 - 3600 seconds in 0.1 second increments.
	Intermittent Overload:	110% Overload capability for up to 1 minute 150% Overload capability for up to 3 seconds
	Current Limit Capability:	Proactive Current Limit programmable from 20 to 160% of rated output current. Independently programmable proportional and integral gain.
	Electronic Motor Overload Protection	Class 10 protection with speed sensitive response. Investigated by U.L. to comply with N.E.C. Article 430. U.L. File E59272, volume 12.
Encoder *PowerFlex 700 Only*	Type:	Incremental, dual channel
	Supply:	12V, 500 mA. 12V, 10 mA minimum inputs isolated with differential transmitter, 250 kHz maximum.
	Quadrature:	90°, ±27 degrees at 25 degrees C.
	Duty Cycle:	50%, +10%
	Requirements:	Encoders must be line driver type, quadrature (dual channel) or pulse (single channel), 8-15V DC output, single-ended or differential and capable of supplying a minimum of 10 mA per channel. Maximum input frequency is 250 kHz. The Encoder Interface Board accepts 12V DC square-wave with a minimum high state voltage of 7.0V DC (12 volt encoder). Maximum low state voltage is 0.4V DC.

Input/Output Ratings

Each PowerFlex Drive has normal and heavy duty torque capabilities. The listings can be found in Tables 2.M through 2.W.

Heat Dissipation

See Watts Loss on page 2-213.

Derating Guidelines

PowerFlex 70 & 700 Altitude and Efficiency

Frame	Type	Derate
All	Altitude	
	Efficiency (typical)	

PowerFlex 70 Ambient Temperature/Load

Frame	Class	Enclosure	Frequency	Derate
A	400V	Open, NEMA Type 1, IP20, Flange	2-10 kHz	None
B	400V	Open, NEMA Type 1, IP20, Flange	2-10 kHz	None
C	400V	NEMA Type 1, Flange	2-8 kHz	None
			10 kHz	
D	400V	NEMA Type 1, Flange	2-6 kHz	None
			8-10 kHz	
E	400V	NEMA Type 1, Flange	2-6 kHz	None
			8-10 kHz	

PowerFlex 700 Ambient Temperature/Load

Frame	Voltage	ND Rating	Enclosure	Frequency (1)	Derate
0	400V	5.5 kW	Open, NEMA Type 1, IP20	2-10 kHz	None
	460V	7.5 HP	Open, NEMA Type 1, IP20	2-10 kHz	None
1	400V	11 kW	Open, NEMA Type 1, IP20	2-6 kHz	

Frame	Voltage	ND Rating	Enclosure	Frequency[1]	Derate
1 *cont.*	460V	15 HP	Open, NEMA Type 1, IP20	2-6 kHz	
2	400V	15 kW	Open, NEMA Type 1, IP20	8-10 kHz	
	460V	20 HP	Open, NEMA Type 1, IP20	10 kHz	
		25 HP	Open, NEMA Type 1, IP20	6-10 kHz	
3	400V	18.5 kW	Open, NEMA Type 1, IP20	6-10 kHz	
		22 kW	Open, NEMA Type 1, IP20	2-10 kHz	None
		30 kW	Open, NEMA Type 1, IP20	6-10 kHz	

Frame	Voltage	ND Rating	Enclosure	Frequency (1)	Derate
3 *cont.*	400V	37 kW	Open, NEMA Type 1, IP20	4-10 kHz	
	460V	30 HP	Open, NEMA Type 1, IP20	2-10 kHz	None
		40 HP	Open, NEMA Type 1, IP20	6-10 kHz	
		50 HP	Open, NEMA Type 1, IP20	6-10 kHz	
4	600V	60 HP	Open, NEMA Type 1, IP20	2-4 kHz	
5	400V	55 kW	Open, NEMA Type 1, IP20	2-8 kHz	None
	460V	75 HP	Open, NEMA Type 1, IP20	2-8 kHz	None
		100 HP	Open, NEMA Type 1, IP20	4 kHz	None
				6-8 kHz	

(1) Consult the factory for further derate information at other frequencies.

PowerFlex 70 Dimensions

Table 1.A PowerFlex 70 Frames

Output Power		Frame Size								
		208-240V AC Input			400-480V AC Input			600V AC Input		
kW ND (HD)	HP ND (HD)	Not Filtered	Filtered	IP66 (4X/12)	Not Filtered	Filtered	IP66 (4X/12)	Not Filtered	Filtered	IP66 (4X/12)
0.37 (0.25)	0.5 (0.33)	A	B	B	A	B	B	A	–	B
0.75 (0.55)	1 (0.75)	A	B	B	A	B	B	A	–	B
1.5 (1.1)	2 (1.5)	B	B	B	A	B	B	A	–	B
2.2 (1.5)	3 (2)	B	B	B	B	B	B	B	–	B
4 (3)	5 (3)	–	C	D	B	B	B	B	–	B
5.5 (4)	7.5 (5)	–	D	D	–	C	D	C	–	D
7.5 (5.5)	10 (7.5)	–	D	D	–	C	D	C	–	D
11 (7.5)	15 (10)	–	–	–	–	D	D	D	–	D
15 (11)	20 (15)	–	–	–	–	D	D	D	–	D
18.5 (15)	25 (20)	–	–	–	–	D	D	–	–	–
22 (18.5)	30 (25)	–	–	–	–	D	D	–	–	–

Figure 1.1 PowerFlex 70 Frames A-D

IP20/66 (NEMA Type 1/4X/12) **Flange Mount**



Dimensions are in millimeters and (inches).

Frame	A	B	C	D	E	Weight (1) *kg (lbs.)*
IP20 / NEMA Type 1						
A	122.4 (4.82)	225.7 (8.89)	179.8 (7.08)	94.2 (3.71)	211.6 (8.33)	2.71 (6.0)
B	171.7 (6.76)	234.6 (9.24)	179.8 (7.08)	122.7 (4.83)	220.2 (8.67)	3.60 (7.9)
C	185.0 (7.28)	300.0 (11.81)	179.8 (7.08)	137.6 (5.42)	285.6 (11.25)	6.89 (15.2)
D	219.9 (8.66)	350.0 (13.78)	179.8 (7.08)	169.0 (6.65)	335.6 (13.21)	9.25 (20.4)
IP66 / NEMA Type 4X/12						
B	171.7 (6.76)	239.8 (9.44)	203.3 (8.00)	122.7 (4.83)	220.2 (8.67)	3.61 (8.0)
D	219.9 (8.66)	350.0 (13.78)	210.7 (8.29)	169.0 (6.65)	335.6 (13.21)	9.13 (20.1)
Flange Mount						
A	156.0 (6.14)	225.8 (8.89)	178.6 (7.03)	–	–	2.71 (6.0)
B	205.2 (8.08)	234.6 (9.24)	178.6 (7.03)	–	–	3.60 (7.9)
C	219.0 (8.62)	300.0 (11.81)	178.6 (7.03)	–	–	6.89 (15.2)
D	248.4 (9.78)	350.0 (13.78)	178.6 (7.03)	–	–	9.25 (20.4)

(1) Weights include HIM and Standard I/O.

Figure 1.2 PowerFlex 70 IP20/NEMA Type 1 Bottom View Dimensions

Frame	Dimensions in millimeters and (inches)
A	
B	
C	
D	

Figure 1.3 PowerFlex 70 IP66 (NEMA Type 4X/12) Bottom View Dimensions

Frame	Dimensions in millimeters and (inches)
B	
D	

Figure 1.4 PowerFlex 70 Flange Mount Bottom View Dimensions

Frame	Dimensions in millimeters and (inches)
A	
B	
C	
D	

Figure 1.5 PowerFlex 70 Cutout Dimensions

Frame	Dimensions in millimeters and (inches)
A	
B	

Frame	Dimensions in millimeters and (inches)
C	
D	

Figure 1.6 Flange Mounting



Dimensions are in millimeters and (inches)

PowerFlex 700 Dimensions

Table 1.B PowerFlex 700 Frames

	AC Input								DC Input			
	208/240		400V		480V		600V		540V		650V	
Frame	ND HP	HD HP	ND kW	HD kW	ND HP	HD HP	ND HP	HD HP	ND HP	HD HP	ND HP	HD HP
0	0.5	0.33	0.37	0.25	0.5	0.33	–	–	0.37	0.25	0.5	0.33
	1	0.75	0.75	0.55	1	0.75	–	–	0.75	0.55	1	0.75
	–	–	1.5	0.75	2	1.5	–	–	1.5	0.75	2	1.5
	–	–	2.2	1.5	3	2	–	–	2.2	1.5	3	2
	–	–	4	2.2	5	3	–	–	4	2.2	5	3
	–	–	5.5	4	7.5	5	–	–	5.5	4	7.5	5
1	2	1.5	7.5	5.5	10	7.5	10	7.5	7.5	5.5	10	7.5
	3	2	11	7.5	15	10	15	10	11	7.5	15	10
	5	3	–	–	–	–	–	–	–	–	–	–
	7.5	5	–	–	–	–	–	–	–	–	–	–
2	10	7.5	15	11	20	15	20	15	15	11	20	15
	–	–	18.5	15	25	20	25	20	18.5	15	25	20
3	15	10	22	18.5	30	25	30	25	22	18.5	30	25
	20	15	30	22	40	30	40	30	30	22	40	30
	–	–	37	30	50	40	50	40	37	30	50	40
4	25	20	45	37	60	50	60	50	45	37	60	50
	30	25	–	–	–	–	–	–	–	–	–	–
5	40	30	55	45	75	60	75	60	55	45	75	60
	50	40	–	–	100	75	100	75	–	–	100	75
6	60	50	75	55	125	100	–	–	75	55	125	100
	75	60	90	75	150	125	–	–	90	75	150	125
	–	–	110	90	–	–	–	–	110	90	–	–

Figure 1.7 PowerFlex 700 Frames 0-3 *(0 Frame Shown)*



Dimensions are in millimeters and (inches)

Frame (1)	A	B	C	D	E	Weight (2) *kg (lbs.)*	
						Drive	Drive & Packaging
0	110.0 (4.33)	336.0 (13.23)	200.0 (7.87)	80.0 (3.15)	320.0 (12.60)	5.22 (11.5)	8.16 (18)
1	135.0 (5.31)	336.0 (13.23)	200.0 (7.87)	105.0 (4.13)	320.0 (12.60)	7.03 (15.5)	9.98 (22)
2	222.0 (8.74)	342.5 (13.48)	200.0 (7.87)	192.0 (7.56)	320.0 (12.60)	12.52 (27.6)	15.20 (33.5)
3	222.0 (8.74)	517.5 (20.37)	200.0 (7.87)	192.0 (7.56)	500.0 (19.69)	18.55 (40.9)	22.68 (50)

(1) Refer to Table 1.B for frame information.

(2) Weights include HIM and Standard I/O.

Figure 1.8 PowerFlex 700 Frame 4



Dimensions are in millimeters and (inches)

Frame[1]	A *(Max.)*	B	C *(Max.)*	D	E	Approx. Weight[2] *kg (lbs.)*	
						Drive	Drive & Packaging
4	220.0 (8.66)	758.8 (29.87)	201.7 (7.94)	192.0 (7.56)	738.2 (29.06)	24.49 (54.0)	29.03 (64.0)

(1) Refer to Table 1.B for frame information.

(2) Weights include HIM and Standard I/O.

Figure 1.9 PowerFlex 700 Frame 5



Dimensions are in millimeters and (inches).

Frame[1]	A *(Max.)*	B	C *(Max.)*	D	E	Approx. Weight[3] *kg (lbs.)*	
						Drive	Drive & Packaging
5	308.9 (12.16)	644.5 (25.37)[2]	275.4 (10.84)	225.0 (8.86)	625.0 (24.61)	37.19 (82.0)	42.18 (93.0)

(1) Refer to Table 1.B for frame information.

(2) When using the supplied junction box (100 HP drives Only), add an additional 45.1 mm (1.78 in.) to this dimension.

(3) Weights include HIM and Standard I/O.

Figure 1.10 PowerFlex 700 Frame 6



Dimensions are in millimeters and (inches)

Frame[1]	**A** *(Max.)*	**B**	**C** *(Max.)*	**D**	**E**	**Approx. Weight**[2] *kg (lbs.)*	
						Drive	**Drive & Packaging**
6	403.9 (15.90)	850.0 (33.46)	275.5 (10.85)	300.0 (11.81)	825.0 (32.48)	71.44 (157.5)	91.85 (202.5)

(1) Refer to Table 1.B for frame information.

(2) Weights include HIM and Standard I/O.

Figure 1.11 PowerFlex 700 Bottom View Dimensions

Frame	Rating	Dimensions in millimeters and (inches)
0	All	
1	All	
2	All	

Frame	Rating	Dimensions in millimeters and (inches)
3	All *except* 50 HP, 480V (37 kW, 400V)	
	50 HP, 480V (37 kW, 400V) Normal Duty Drive	
4	All	

Frame	Rating	Dimensions in millimeters and (inches)
5	75 HP, 480V (55kW, 400V) Normal Duty Drive	
	100 HP, 480V Normal Duty Drive	
6	All	

Notes:

Detailed Drive Operation

This chapter explains PowerFlex drive functions in detail. Explanations are organized alphabetically by topic. Refer to the Table of Contents for a listing of topics.

Accel Time

[Accel Time 1, 2]

The Accel Time parameters set the rate at which the drive ramps up its output frequency after a Start command or during an increase in command frequency (speed **change**). The rate established is the result of the programmed Accel Time and the Minimum and Maximum Frequency, as follows:

$$\frac{\text{Maximum Speed}}{\text{Accel Time}} = \text{Accel Rate (Hz./sec.)}$$

Two accel times exist to allow the user to change acceleration rates “on the fly” via PLC command or digital input. The selection is made by programming [Accel Time 1] & [Accel Time 2] and then using one of the digital inputs ([Digital Inx Sel]) programmed as “Accel 2” (see Table 2.I for further information). However, if a PLC is used, manipulate the bits of the command word as shown below.



0	0	0	1	Accel 1
0	0	1	0	Accel 2
0	1	0	0	Decel 1
1	0	0	0	Decel 2

The effectiveness of these bits or digital inputs can be affected by [Accel Mask]. See Masks on page 2-114 for more information.

Times are adjustable in 0.1 second increments from 0.0 seconds to 3600.0 seconds.

In its factory default condition, when no accel select inputs are closed and no accel time bits are “1,” the default acceleration time is Accel Time 1 and the rate is determined as above.

Advanced Tuning

Advanced Tuning Parameters – PF700 Vector Control Only

ATTENTION: To guard against unstable or unpredictable operation, the following parameters must only be changed by qualified service personnel.

The following parameters can only be viewed when "2, Unused" is selected in parameter 196, [Param Access Lvl].

File	Group	No.	Parameter Name & Description	Values	Related
UTILITY	Diag-Motor Cntl	500	**[KI Current Limit]** Current Limit Integral gain. This gain is applied to the current limit error signal to eliminate steady state current limit error. A larger value increases overshoot during a step of motor current/load.	Default: 1500 Min/Max: 0/10000 Units: 1	
		501	**[KD Current Limit]** Current Limit Derivative gain. This gain is applied to the sensed motor current to anticipate a current limit condition. A larger value reduces overshoot of the current relative to the current limit value.	Default: 500 Min/Max: 0/10000 Units: 1	
		502	**[Bus Reg ACR Kp]** This proportional gain, in conjunction with P160, adjusts the output frequency of the drive during a bus limit or inertia ride through condition. The output frequency is adjusted in response to an error in the active, or torque producing, current to maintain the active bus limit, or inertia ride through bus reference. A larger value of gain reduces the dynamic error of the active current.	Default: 450 Min/Max: 0/10000 Units: 1	
		503	**[Jerk]** This parameter allows you to adjust the amount of S-Curve, or "Jerk" applied to the Acc/Dec rate. To enable the Jerk feature, bit 1 of P56 must be set high.	Default: 900 Min/Max: 2/30000 Units: 1	
		504	**[Kp Ln Ls Bus Reg]** This proportional gain adjusts the active current command during an inertia-ride through condition, in response to a bus error. A larger value of gain reduces the dynamic error of the bus voltage as compared to the bus voltage reference.	Default: 500 Min/Max: 0/10000 Units: 1	

File	Group	No.	Parameter Name & Description	Values	Related
UTILITY	Diag-Motor Cntl	505	**[Kd Ln Ls Bus Reg]** Line Loss Bus Reg Kd is a derivative gain, which is applied to the sensed bus voltage to anticipate dynamic changes and minimize them. A larger value reduces overshoot of the bus voltage relative to the inertia-ride through bus voltage reference.	Default: 500 Min/Max: 0/10000 Units: 1	
		506	**[Angl Stblty Gain]** Angle Stability Gain adjusts the electrical angle to maintain stable motor operation. An increase in the value increases the angle adjustment.	Default: 51 Min/Max: 0/32767 Units: 1	
		507	**[Volt Stblty Gain]** Adjusts the output voltage to maintain stable motor operation. An increase in the value increases the output voltage adjustment.	Default: 93 Min/Max: 0/32767 Units: 1	
		508	**[Stability Filter]** The Stability Filter coefficient is used to adjust the bandwidth of a low pass filter. The smaller the value of this coefficient, the lower the bandwidth of the filter.	Default: 3250 Min/Max: 0/32767 Units: 1	
		509	**[Lo Freq Reg Kpld]** This proportional gain adjusts the output voltage at very low frequency in response to the reactive, or d-axis, motor current. A larger value increases the output voltage change.	Default: 64 Min/Max: 0/32767 Units: 1	
		510	**[Lo Freq Reg Kplq]** The proportional gain adjusts the output voltage at very low frequency in response to the active, or q-axis, motor current. A larger value increases the output voltage change.	Default: 64 Min/Max: 0/32767 Units: 1	
		511	**[Ki Cur Reg]** This integral gain adjusts the output voltage in response to the q and d axis motor currents. A larger value increases the output voltage change.	Default: 44 Min/Max: 0/32767 Units: 1	
		512	**[Kp Cur Reg]** This proportional gain adjusts the output voltage in response to the q and d axis motor currents. A larger value increases the output voltage change.	Default: 1600 Min/Max: 0/32767 Units: 1	
		523	**[Bus Utilization]** This value sets the drive output voltage limit as a percentage of the fundamental output voltage when operating in 6 step mode. Values above 95% increase harmonic content and jeopardize control stability. This output voltage limit is strictly a function of input line and resulting bus voltage.	Default: 95.0% Min/Max: 85.0/100.0% Units: 0.1%	
		524	**[PWM Type Sel]** Allows selection of the active PWM type. A value of 0 is default, and results in a change of PWM method at approximately 2/3 of rated motor frequency. If this is unacceptable for harmonic or audible reasons, a value of 1 disables the change.	Default: 0 Min/Max: 0/1 Units: 1	
		536	**[Ki Flux Braking]** Proportional gain for the Flux Regulator	Default: 100 Min/Max: 0/32767 Units: 1	
		537	**[Kp Flux Braking]** Integral gain for the Flux Regulator	Default: 500 Min/Max: 0/32767 Units: 1	

File	Group	No.	Parameter Name & Description	Values	Related
UTILITY	Diag-DACs	538	**[Rec Delay Time]** TBD	Default: 1000 Min/Max: 1/30000 Units: 1	
		513	**[PWM DAC Enable]** Reserved. Do Not Adjust	Default: 0 Min/Max: 0/1 Units: 1	
		514 515 516 517	**[DAC47-A]** **[DAC47-B]** **[DAC47-C]** **[DAC47-D]** Reserved. Do Not Adjust	Default: 0 Min/Max: 0/7432 Units: 1	
		518	**[Host DAC Enable]** Reserved. Do Not Adjust	Default: 0 Min/Max: 0/1 Units: 1	
		519 520 521 522	**[DAC55-A]** **[DAC55-B]** **[DAC55-C]** **[DAC55-D]** Reserved. Do Not Adjust	Default: 0 Min/Max: 0/7432 Units: 1	
	Diag-Vector Cnt	525	**[Torq Adapt Speed]** Selects the operating frequency/speed at which the adaptive torque control regulators become active as a percent of motor nameplate frequency.	Default: 10.0% Min/Max: 0.0/100.0% Units: 0.1%	
		526	**[Torq Reg Enable]** Enables or disables the torque regulator	Default: 1 Min/Max: 0/1 Units: 1	
		527	**[Kp Torq Reg]** Proportional gain for the torque regulator	Default: 32 Min/Max: 0/32767 Units: 1	
		528	**[Ki Torq Reg]** Integral gain for the torque regulator	Default: 128 Min/Max: 0/32767 Units: 1	
		529	**[Torq Reg Trim]** Torque Regulator trim gain. A larger value increases the developed torque. Typically used to compensate for losses between developed and shaft torque.	Default: 1.0 Min/Max: 0.5/1.5 Units: 0.1	
		530	**[Slip Reg Enable]** Enables or disables the slip frequency regulator.	Default: 1 Min/Max: 0/1 Units: 1	
		531	**[Kp Slip Reg]** Proportional gain for the slip frequency regulator.	Default: 256 Min/Max: 0/32767 Units: 1	
		532	**[Ki Slip Reg]** Integral gain for the slip frequency regulator.	Default: 64 Min/Max: 0/32767 Units: 1	
		533	**[Flux Reg Enable]** Enables or disables the flux regulator.	Default: 1 Min/Max: 0/1 Units: 1	
		534	**[Kp Flux Reg]** Proportional gain for the flux regulator.	Default: 64 Min/Max: 0/32767 Units: 1	
		535	**[Ki Flux Reg]** Integral gain for the flux regulator.	Default: 32 Min/Max: 0/32767 Units: 1	
		539	**[Freq Reg Ki]** Integral gain for the Frequency Regulator	Default: 450 Min/Max: 0/32767 Units: 1	

File	Group	No.	Parameter Name & Description	Values	Related
UTILITY	Diag-Vector Cnt	540	**[Freq Reg Kp]** Proportional gain for the Frequency Regulator.	Default: 2000 Min/Max: 0/32767 Units: 1	
		541	**[Encdlss Ang Comp]** TBD	Default: 0 Min/Max: –1023/1023 Units: 1	
		542	**[Encdlss Vlt Comp]** TBD	Default: 6.1 Min/Max: 0/115 Units: 1	
		544	**[Excitation Kp]** TBD	Default: 1800 Min/Max: 0/32767 Units: 1	

Alarms

Alarms are indications of situations that are occurring within the drive or application that should be annunciated to the user. These situations may affect the drive operation or application performance. Conditions such as Power Loss or Analog input signal loss can be detected and displayed to the user for drive or operator action.

There are two types of alarms:

- **Type 1 Alarms** are conditions that occur in the drive or application that may require alerting the operator. These conditions, by themselves, do not cause the drive to “trip” or shut down, but they may be an indication that, if the condition persists, it may lead to a drive fault.
- **Type 2 Alarms** are conditions that are caused by improper programming and they prevent the user from Starting the drive until the improper programming is corrected. An example would be programming one digital input for a 2-wire type control (Run Forward) and another digital input for a 3-wire type control (Start). These are mutually exclusive operations, since the drive could not determine how to properly issue a “Run” command. Because the programming conflicts, the drive will issue a type 2 alarm and prevent Starting until the conflict is resolved.

Alarm Status Indication

[Drive Alarm 1]
[Drive Alarm 2]

Two 16 bit Drive Alarm parameters are available to indicate the status of any alarm conditions. Both Type 1 and Type 2 alarms are indicated.

A “1” in the bit indicates the presence of the alarm and a “0” indicates no alarm is present

Configuration

In order for a drive alarm to be annunciated to the “outside” world, it must first be “configured” or activated. Configuration parameters contain a configuration bit for each Type 1 alarm. Type 2 alarms are permanently configured to annunciate. The configuration word is a mirror image of the

Drive Alarm word; that is, the same bits in both the Drive Alarm Word and the Alarm Configuration Word represent the same alarm.



The configuration bits act as a mask to block or pass through the alarm condition to the active condition. An active alarm will be indicated on the LCD HIM and will cause the drive alarm status bit to go high (“1”) in the Drive Status word (Bit 6, parameter 209). This bit can then be linked to a digital output for external annunciation. As default, all configuration bits are high (“1”). Note that setting a configuration bit to “0” to “mask” an alarm does not affect the status bit in the Drive Alarm parameter, only its ability to annunciate the condition.

Application

A process is being controlled by a PowerFlex drive. The speed reference to the drive is a 4-20 mA analog signal from a sensor wired to Analog Input 1.

The input is configured for mA by setting the corresponding bit in [Anlg In Config] to “1”


320
[Anlg In Config]
Selects the mode for the analog inputs.
322
325
323
326
An2 0=V 1=mA
An1 0=V 1=mA
x x x x x x x x x x x x x x 0 0
15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0
1 = Current
0 = Voltage
x = Reserved
Bit #
Factory Default Bit Values

Analog In Config

														0	1

The input is scaled for 4-20 mA by setting [Analog In 1 Lo] to “4” mA and [Analog In 1 Hi] to “20” mA.

The signal is designated as the active speed reference by setting [Speed Ref A Sel] to its factory default value of “1”

Speed References	090	**[Speed Ref A Sel]** Selects the source of the speed reference to the drive unless [Speed Ref B Sel] or [Preset Speed 1-7] is selected. (1) See User Manual for DPI port locations.	Default: Options:	2 1 2 3-6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22	“Analog In 2” “Analog In 1” “Analog In 2” “Reserved” “Pulse In” “Encoder” “MOP Level” “Reserved” “Preset Spd1” “Preset Spd2” “Preset Spd3” “Preset Spd4” “Preset Spd5” “Preset Spd6” “Preset Spd7” “DPI Port 1”(1) “DPI Port 2”(1) “DPI Port 3”(1) “DPI Port 4”(1) “DPI Port 5”(1)	002 091 thru 093 101 thru 107 117 thru 120 192 thru 194 213 272 273 320 361 thru 366

By setting Speed Ref A Hi to 60 Hz and Speed ref A Lo to 0 Hz, the speed reference is scaled to the application needs. Because of the Input scaling and link to the speed reference, 4 mA represents minimum frequency (0 Hz.) and 20 mA represents Maximum Frequency (60 Hz.)

Scale Block

P322 20mA	P091 60 Hz
P323 4mA	P092 0 HZ

The input is configured to recognize a loss of signal and react accordingly to the programming.

	324 327	**[Analog In 1 Loss]** **[Analog In 2 Loss]** Selects drive action when an analog signal loss is detected. Signal loss is defined as an analog signal less than 1V or 2mA. The signal loss event ends and normal operation resumes when the input signal level is greater than or equal to 1.5V or 3mA.	Default: Options:	0 0 0 1 2 3 4 5 6	“Disabled” “Disabled” “Disabled” “Fault” “Hold Input” “Set Input Lo” “Set Input Hi” “Goto Preset1” “Hold OutFreq”	091 092

The loss action is chosen as Hold Input, meaning that the last received signal will be maintained as the speed reference.

Finally, a Digital Output relay is configured to annunciate an alarm by turning on a flashing yellow light mounted on the operator panel of the process control area.

INPUTS & OUTPUTS	Digital Outputs	380 384 388	**[Digital Out1 Sel]** **[Digital Out2 Sel]** **Vector** **[Digital Out3 Sel]**	Default: Options:	1 4 4 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21- 26 27 28 29	“Fault” “Run” “Run” “Fault”(1) “Alarm”(1) “Ready” “Run” “Forward Run” “Reverse Run” “Auto Restart” “Powerup Run” “At Speed” “At Freq” “At Current” “At Torque” “At Temp” “At Bus Volts” “At PI Error” “DC Braking” “Curr Limit” “Economize” “Motor Overld” “Power Loss” “Input 1-6 Link” “PI Enable”(2) “PI Hold”(2) “PI Reset”(2)	381 385 382 386 383 002 001 003 004 218 012 137 157 147 053 048 184
			Selects the drive status that will energize a (CRx) output relay. (1)Contacts shown in User Manual are in drive powered state with condition present. Refer to “Fault” and “Alarm” information. (2)Vector Control Option Only.				

While the process is normal and running from the analog input, everything proceeds normally. However, if the wire for the analog input should be severed or the sensor malfunction so that the 4-20mA signal is lost, the following sequence occurs:

1. The drive will sense the signal loss.
2. An active Type 1 Alarm is created and the last signal value is maintained as the speed reference.
3. The alarm activates the digital output relay to light the alarm light for the operator.
4. The operator uses the HIM to switch the drive to Manual Control (see Auto/Manual).
5. The operator manually brings the process to a controlled stop until the signal loss is repaired.

Alarm Queue (PowerFlex 700 Only)

A queue of 8 parameters exists that capture the drive alarms as they occur. A sequential record of the alarm occurrences allows the user to view the history of the eight most recent events.

UTILITY	Alarms	262 **[Alarm 1 Code]** 263 **[Alarm 2 Code]** 264 **[Alarm 3 Code]** 265 **[Alarm 4 Code]** 266 **[Alarm 5 Code]** 267 **[Alarm 6 Code]** 268 **[Alarm 7 Code]** 269 **[Alarm 8 Code]** A code that represents a drive alarm. The codes will appear in the order they occur (first 4 alarms in – first 4 out alarm queue). A time stamp is not available with alarms.	Default: Read Only Min/Max: 0/256 Display: 1		261

Analog Inputs

Possible Uses of Analog Inputs

The analog inputs provide data that can be used for the following purposes:

- Provide a value to [Speed Ref A] or [Speed Ref B].
- Provide a trim signal to [Speed Ref A] or [Speed Ref B].
- Provide a reference when the terminal block has assumed manual control of the reference
- Provide the reference and feedback for the PI loop. See Process PI Loop on page 2-137.
- Provide an external and adjustable value for the current limit and DC braking level
- Enter and exit sleep mode.
- Vector FV Provide a value to [Torque Ref A] or [Torque Ref B].

Analog Input Configuration

[Anlg In Config]

[Current Lmt Sel] allows an analog input to control the set point while [DC Brk Levl Sel] allows an analog input to define the DC hold level used when Ramp-to-Stop, Ramp-to-Hold, or Brake-to-Stop is active.

To provide local adjustment of a master command signal or to provide improved resolution the input to analog channel 1 or 2 can be defined as a trim input. Setting [Trim In Select] allows the selected channel to modify the commanded frequency by ±10%. The speed command will be reduced by 10% when the input level is at [Anlg In x Lo] with it linearly increasing to 10% above command at [Anlg In xHi].

Feedback can be used to control an operation using the “Process PI” (proportional-integral) feature of the control. In this case one signal, defined using [PI Reference Sel], provides a reference command and a second, defined using [PI Feedback Sel], provides a feedback signal for frequency compensation. Please refer to the Process PI Loop on page 2-137 for details on this mode of operation.


Input/Output
Parameter
Processing
Selection/Control
Analog In 1 Lo
Analog In 1 Hi
Analog Input 1 Scale
Volts or mA
Cal Analog 1
Analog In 2 Lo
Analog In 2 Hi
Analog Input 2 Scale
Volts or mA
Cal Analog 2
Speed Ref A Sel
Speed Ref B Sel
Trim In Select
TB Man Ref Sel
PI Reference Sel
PI Feedback Sel
Current Lmt Sel
DC Brk Levl Sel
Sleep-Wake Ref
Torque Ref A Sel
Torque Ref B Sel
Speed Ref A Lo
Speed Ref A Hi
Ref A Scale/Limit
Speed Ref B Lo
Speed Ref B Hi
Ref B Scale/Limit
Trim Lo
Trim Hi
Trim Scale/Limit
Hz
Trim Out Sel
TB Manual Scale/Limit
PI Reference Scale/Limit
PI Feedback Scale/Limit
Current Limit Scale/Limit
Brake Level Scale/Limit
Sleep Level
Wake Level
Sleep Level Compare
Torque Ref A Lo
Torque Ref A Hi
Torque Ref A Div
Torque Ref B Lo
Torque Ref B Hi
Torque Ref B Mult
+
+
Hz
Hz
Hz
%
%
% Rated Current
% Rated Current
Sleep/ Wake
%
%
Reference A
Reference B
TB Manual
PI Reference
PI Feedback
Current Limit
DC Brake
Sleep/Wake
Torque Ref A
Torque Ref B


Input/Output
Parameter
Processing
Selection/Control
Anlg In Config
Anlg In 1 Loss
Anlg In Sqr Root
Analog 1 Voltage
Analog 1 Current
ADC
0-10v
0-20mA
Unipolar Cal 1
Current Cal 1
Loss Detect
Loss Detect
Limit 0-10V
Limit 4-20mA
Square Root
Cal Analog 1
Analog In1 Value
Note: If either of these parameters is < 0, input will go into bipolar mode, otherwise unipolar.
Anlg In Config
Analog In 2 Lo
Analog In 2 Hi
Anlg In 2 Loss
Anlg In Sqr Root
Analog 2 Unipolar
Analog 2 Bipolar
Analog 2 Current
ADC
(voltage)
(current)
0-10v
-10v - +10v
0-20mA
Unipolar Cal 2
Bipolar Cal 2
Current Cal 2
Loss Detect
Loss Detect
Limit 0-10V
Limit -10V to 10V
Limit 4-20mA
Square Root
Cal Analog 2
Analog In2 Value

Analog Scaling

[Analog In Hi]
[Analog In Lo]

A scaling operation is performed on the value read from an analog input in order to convert it to units usable for some particular purpose. The user controls the scaling by setting parameters that associate a low and high point in the input range (i.e. in volts or mA) with a low and high point in the target range (e.g. reference frequency).

Two sets of numbers may be used to specify the analog input scaling. One set (called the “input scaling points”) defines low and high points in terms of the units read by the input hardware, i.e. volts or mA.

The second set of numbers (called the “output scaling points”) used in the analog input scaling defines the same low and high points in units appropriate for the desired use of the input. For instance, if the input is to be used as a frequency reference, this second set of numbers would be entered in terms of Hz. For many features the second set of numbers is fixed. The user sets the second set for speed and reference trim.

An analog input or output signal can represent a number of different commands. Typically an analog input is used to control output frequency, but it could control frequency trim, current limit or act as a PI loop input. An analog output typically is a frequency indication, but it could represent output current, voltage, or power. For this reason this document defines an analog signal level as providing a “command” value rather than a “frequency.” However when viewing a command value it is presented as a frequency based on the [Minimum Speed] and [Maximum Freq] settings.

The 0-10 volt input scaling can be adjusted using the following parameters:

- [Analog In x Lo]
- [Analog In x Hi]

Configuration #1:

- [Anlg In Config], bit 0 = “0” (Voltage)
- [Speed Ref A Sel] = “Analog In 1”
- [Speed Ref A Hi] = 60 Hz
- [Speed Ref A Lo] = 0 Hz
- [Analog In 1 Hi] = 10V
- [Analog In 1 Lo] = 0V

This is the default setting, where minimum input (0 volts) represents 0 Hz and maximum input (10 volts) represents 60 Hz (it provides 6 Hz change per input volt).



Analog Scaling

[Speed Reference A Sel] = “Analog In 1”	
[Analog In 1 Hi] 10V	[Speed Ref A Hi] 60 Hz
[Analog In 1 Lo] 0V	[Speed Ref A Lo] 0 Hz

Configuration #2:

- [Anlg In Config], bit 0 = “0” (Voltage)
- [Speed Ref A Sel] = “Analog In 1”
- [Speed Ref A Hi] = 30 Hz
- [Speed Ref A Lo] = 0 Hz
- [Analog In 1 Hi] = 10V
- [Analog In 1 Lo] = 0V

This is an application that only requires 30 Hz as a maximum output frequency, but is still configured for full 10 volt input. The result is that the resolution of the input has been doubled, providing only 3 Hz change per input volt (Configuration #1 is 6 Hz/Volt).



Analog Scaling

[Speed Reference A Sel] = “Analog In 1”	
[Analog In 1 Hi] 10V	[Speed Ref A Hi] 30 Hz
[Analog In 1 Lo] 0V	[Speed Ref A Lo] 0 Hz

Configuration #3:

- [Anlg In Config], bit 0 = “1” (Current)
- [Speed Ref A Sel] = “Analog In 1”
- [Speed Ref A Hi] = 60 Hz
- [Speed Ref A Lo] = 0 Hz
- [Analog In 1 Hi] = 20 mA
- [Analog In 1 Lo] = 4 mA

This configuration is referred to as offset. In this case, a 4-20 mA input signal provides 0-60 Hz output, providing a 4 mA offset in the speed command.

Analog Scaling

[Speed Reference A Sel] = “Analog In 1”	
[Analog In 1 Hi] 20 mA	[Speed Ref A Hi] 60 Hz
[Analog In 1 Lo] 4 mA	[Speed Ref A Lo] 0 Hz



Configuration #4:

- [Anlg In Config], bit 0 = “0” (Voltage)
- [Speed Ref A Sel] = “Analog In 1”
- [Speed Ref A Hi] = 0 Hz
- [Speed Ref A Lo] = 60 Hz
- [Analog In 1 Hi] = 10V
- [Analog In 1 Lo] = 0V

This configuration is used to invert the operation of the input signal. Here, maximum input (10 Volts) represents 0 Hz and minimum input (0 Volts) represents 60 Hz.



Analog Scaling

[Speed Reference A Sel] = "Analog In 1"	
[Analog In 1 Hi] 10V	[Speed Ref A Hi] 0 Hz
[Analog In 1 Lo] 0V	[Speed Ref A Lo] 60 Hz

Configuration #5:

- [Anlg In Config], bit 0 = "0" (Voltage)
- [Speed Ref A Sel] = "Analog In 1"
- [Speed Ref A Hi] = 60 Hz
- [Speed Ref A Lo] = 0 Hz
- [Analog In 1 Hi] = 5V
- [Analog In 1 Lo] = 0V

This configuration is used when the input signal is 0-5 volts. Here, minimum input (0 Volts) represents 0 Hz and maximum input (5 Volts) represents 60 Hz. This allows full scale operation from a 0-5 volt source.



Analog Scaling

[Speed Reference A Sel] = "Analog In 1"	
[Analog In 1 Hi] 5V	[Speed Ref A Hi] 60 Hz
[Analog In 1 Lo] 0V	[Speed Ref A Lo] 0Hz

Vector FV Configuration #6 – Torque Ref:

- [Anlg In Config], bit 0 = “0” (Voltage)
- [Torque Ref A Sel] = “Analog In 1”
- [Torque Ref A Hi] = 200%
- [Torque Ref A Lo] = 0%
- [Torque Ref A Div] = 1

This configuration is used when the input signal is 0-10 volts. The minimum input of 0 volts represents a torque reference of 0% and maximum input of 10 volts represents a torque reference of 200%.



Analog Scaling

[Torque Ref A Sel] = “Analog In 1”	
[Analog In 1 Hi] 10V	[Torque Ref A Hi] 200%
[Analog In 1 Lo] 0V	[Torque Ref A Lo] 0%

Square Root

[Anlg In Sqr Root]

For both analog inputs, the user can enable a square root function for an analog input through the use of [Analog In Sq Root]. The function should be set to enabled if the input signal varies with the square of the quantity (i.e. drive speed) being monitored.

If the mode of the input is bipolar voltage (–10v to 10v), then the square root function will return 0 for all negative voltages.

The square root function is scaled such that the input range is the same as the output range. For example, if the input is set up as a unipolar voltage input, then the input and output ranges of the square root function will be 0 to 10 volts, as shown in figure below.



Signal Loss

[Analog In 1, 2 Loss]

Signal loss detection can be enabled for each analog input. The [Analog In x Loss] parameters control whether signal loss detection is enabled for each input and defines what action the drive will take when loss of any analog input signal occurs.

One of the selections for reaction to signal loss is a drive fault, which will stop the drive. All other choices make it possible for the input signal to return to a usable level while the drive is still running.

- Hold input
- Set input Lo
- Set input Hi
- Goto Preset 1
- Hold Output Frequency

Value	Action on Signal Loss
0	Disabled (default)
1	Fault
2	Hold input (continue to use last frequency command.)
3	Set Input Hi - use [Minimum Speed] as frequency command.
4	Set Input Lo - use [Maximum Speed] as frequency command.
5	use [Preset 1] as frequency command.
6	Hold Out Freq (maintain last output frequency)

If the input is in current mode, 4 mA is the normal minimum usable input value. Any value below 3.2 mA will be interpreted by the drive as a signal loss, and a value of 3.8 mA will be required on the input in order for the signal loss condition to end.



If the input is in unipolar voltage mode, 2V is the normal minimum usable input value. Any value below 1.6 volts will be interpreted by the drive as a signal loss, and a value of 1.9 volts will be required on the input in order for the signal loss condition to end.

No signal loss detection is possible while an input is in bipolar voltage mode. The signal loss condition will never occur even if signal loss detection is enabled.



Trim

An analog input can be used to trim the active speed reference (Speed Reference A/B). If analog is chosen as a trim input, two scale parameters are provide to scale the trim reference. The trim is a +/- value which is summed with the current speed reference. See also Speed Reference on page 2-171.

- [Trim In Select]
- [Trim Out Select]
- [Trim Hi]
- [Trim Lo]

Value Display

Parameters are available in the Monitoring Group to view the actual value of an analog input regardless of its use in the application. Whether it is a current limit adjustment, speed reference or trim function, the incoming value can be read via these parameters.

The value displayed includes the input value plus any factory hardware calibration value, but does not include scaling information programmed by the user (i.e. [Analog In 1 Hi/Lo]). The units displayed are determined by the associated configuration bit (Volts or mA)

	Metering	016 017	**[Analog In1 Value]** **[Analog In2 Value]** Value of the signal at the analog inputs.	Default: Min/Max: Display:	Read Only 0.000/20.000 mA –/+10.000V 0.001 mA 0.001 Volt

Cable Selection

Refer to "*Wiring and Grounding Guidelines for Pulse Width Modulated (PWM) AC Drives*," publication DRIVES-IN001 for detailed information on Cable Selection.

Terminal Designations & Wiring Examples

Refer to the appropriate PowerFlex User Manual or "*Wiring and Grounding Guidelines for Pulse Width Modulated (PWM) AC Drives*," publication DRIVES-IN001 for I/O terminal designations and wiring examples.

How [Analog Inx Hi/Lo] & [Speed Ref A Hi/Lo] Scales the Frequency Command Slope with [Minimum/Maximum Speed]

Example 1:

Consider the following setup:

- [Anlg In Config], bit 0 = “0” (voltage)
- [Speed Ref A Sel] = “Analog In 1”
- [Analog In1 Hi] = 10V
- [Analog In1 Lo] = 0V
- [Speed Ref A Hi] = 60 Hz
- [Speed Ref A Lo] = 0 Hz
- [Maximum Speed] = 45 Hz
- [Minimum Speed] = 15 Hz

This operation is similar to the 0-10 volts creating a 0-60 Hz signal until the minimum and maximum speeds are added. [Minimum Speed] and [Maximum Speed] limits will create a command frequency deadband.



This deadband, as it relates to the analog input, can be calculated as follows:

1. The ratio of analog input volts to frequency (Volts/Hz) needs to be calculated. The voltage span on the analog input is 10 volts. The frequency span is 60 Hz.

   10 Volts/60 Hz = 0.16667 Volts/Hz

2. Determine the frequency span between the Minimum and Maximum Speed limits and Speed Ref A Hi and Lo.

   [Speed Ref A Hi] – [Maximum Speed] = 60 – 45 = 15 Hz and . . .
   [Minimum Speed] – [Speed Ref A Lo] = 15 – 0 = 15 Hz.

3. Multiply by the Volts/Hertz ratio

   15 Hz x 0.16667 Volts/Hz = 2.5 Volts

Therefore the command frequency from 0 to 2.5 volts on the analog input will be 15 Hz. After 2.5 volts, the frequency will increase at a rate of 0.16667 volts per hertz to 7.5 volts. After 7.5 volts on the analog input the frequency command will remain at 45 Hertz.

Example 2:

Consider the following setup:

- [Anlg In Config], bit 0 = “0” (voltage)
- [Speed Ref A Sel] = “Analog In 1”
- [Analog In1 Hi] = 10V
- [Analog In1 Lo] = 0V
- [Speed Ref A Hi] = 50hz
- [Speed Ref A Lo] = 0hz
- [Maximum Speed] = 45hz
- [Minimum Speed] = 15hz

The only change from Example 1 is the [Speed Ref A Hi] is changed to 50 Hz.



The deadband, as it relates to the analog input, can be calculated as follows:

1. The ratio of analog input volts to frequency (Volts/Hertz) needs to be calculated. The voltage span on the analog input is 10 volts. The frequency span is 60 Hz.

10 Volts/50 Hz = 0.2 Volts/Hz

2. Determine the frequency span between the minimum and maximum speed limits and the Speed Ref A Hi and Lo.

[Speed Ref A Hi] – [Maximum Speed] = 50 – 45 = 5 Hz and . . .
[Minimum Speed] – [Speed Ref A Lo] = 15 – 0 = 15 Hz

3. Multiply by the volts/hertz ratio

5 Hz x 0.2 Volts/Hz = 1 Volt
15 Hz x 0.2 Volts/Hz = 3 Volts

Here, the deadband is “shifted” due to the 50 Hz limitation. The command frequency from 0 to 3 volts on the analog input will be 15 Hz. After 3 volts, the frequency will increase at a rate of 0.2 volts per hertz up to 9 volts. After 9 volts on the analog input the frequency command will remain at 45 Hz.

Analog Outputs

Explanation

Each drive has one or more analog outputs that can be used to annunciate a wide variety of drive operating conditions and values.

The user selects the analog output source by setting [Analog Out Sel].

INPUTS & OUTPUTS / Analog Outputs

342
345

[Analog Out1 Sel]
Vector **[Analog Out2 Sel]**

Selects the source of the value that drives the analog output.

Default: 0 "Output Freq"
Options: See Table

001
002
003
004
005
007
006
012
135
136
137
138
220
219
377
378

Options		[Analog Out1 Lo] Value		[Analog Out1 Hi] Value
		Param. 341 = Signed	*Param. 341 = Absolute*	
0	"Output Freq"	–[Maximum Speed]	0 Hz	+[Maximum Speed]
1	"Command Freq"	–[Maximum Speed]	0 Hz	+[Maximum Speed]
1*	"Command Spd"	–[Maximum Speed]	0 Hz/RPM	+[Maximum Speed]
2	"Output Amps"	0 Amps	0 Amps	200% Rated
3	"Torque Amps"	–200% Rated	0 Amps	200% Rated
4	"Flux Amps"	0 Amps	0 Amps	200% Rated
5	"Output Power"	0 kW	0 kW	200% Rated
6	"Output Volts"	0 Volts	0 Volts	120% Rated Input Volts
7	"DC Bus Volts"	0 Volts	0 Volts	200% Rated Input Volts
8	"PI Reference" (1)	–100%	0%	100%
9	"PI Feedback"	–100%	0%	100%
10	"PI Error"	–100%	0%	100%
11	"PI Output"	–100%	0%	100%
12	"%Motor OL"	0%	0%	100%
13	"%Drive OL"	0%	0%	100%
14*	"CommandedTrq"	–800% Rated	0%	800% Rated
15*	"MtrTrqCurRef" (1)	–200% Rated	0%	200% Rated
16*	"Speed Ref"	–[Maximum Speed]	0 Hz/RPM	+[Maximum Speed]
17*	"Speed Fdbk"	–[Maximum Speed]	0 Hz/RPM	+[Maximum Speed]
18*	"Pulse In Ref" (1)	–25200.0 RPM	0 Hz/RPM	+[Maximum Speed]
19*	"Torque Est" (1)	–800%	0%	+800%
20-23**	"Scale Block1-4" (1)			
24**	"Param Cntl" (1)			

* Vector Control Option Only **Vector firmware 3.001 & later
(1) Refer to Option Definitions in User Manual..

Configuration

The PowerFlex 70 standard I/O analog output is permanently configured as a 0-10 volt output. The output has 10 bits of resolution yielding 1024 steps. The analog output circuit has a maximum 1.3% gain error and a maximum 7 mV offset error. For a step from minimum to maximum value, the output will be within 0.2% of its final value after 12ms.

The PowerFlex 700 standard I/O analog output is permanently configured as a 0-10 volt output. The output has 10 bits of resolution yielding 1024 steps. The analog output circuit has a maximum 1.3% gain error and a maximum 100 mV offset error. For a step from minimum to maximum value, the output will be within 0.2% of its final value after 12ms.

Absolute (default)

Certain quantities used to drive the analog output are signed, i.e. the quantity can be both positive and negative. The user has the option of having the absolute value (value without sign) of these quantities taken before the scaling occurs. Absolute value is enabled separately for each analog output via the bitmapped parameter [Anlg Out Absolut].

Important: If absolute value is enabled but the quantity selected for output is not a signed quantity, then the absolute value operation will have no effect.

Scaling Blocks

The user defines the scaling for the analog output by entering analog output voltages into two parameters, [Analog Out1 Lo] and [Analog Out1 Hi]. These two output voltages correspond to the bottom and top of the possible range covered by the quantity being output. The output voltage will vary linearly with the quantity being output. The analog output voltage will not go outside the range defined by [Analog Out1 Lo] and [Analog Out1 Hi].

Analog Output Configuration Examples

This section gives a few examples of valid analog output configurations and describes the behavior of the output in each case.

Example 1 -- Unsigned Output Quantity

- [Analog Out1 Sel] = "Output Current"
- [Analog Out1 Lo] = 1 volt
- [Analog Out1 Hi] = 9 volts



Note that analog output value never goes outside the range defined by [Analog Out1 Lo] and [Analog Out1 Hi]. This is true in all cases, including all the following examples.

Example 2 -- Unsigned Output Quantity, Negative Slope

- [Analog Out1 Sel] = "Output Current"
- [Analog Out1 Lo] = 9 volts
- [Analog Out1 Hi] = 1 volts



This example shows that you can have [Analog Out1 Lo] greater than [Analog Out1 Hi]. The result is a negative slope on the scaling from original quantity to analog output voltage. Negative slope could also be applied to any of the other examples in this section.

Example 3 – Signed Output Quantity, Absolute Value Enabled

- [Analog Out1 Sel] = "Output Torque Current"
- [Analog Out1 Lo] = 1 volt
- [Analog Out1 Hi] = 9 volts
- [Anlg Out Absolut] set so that absolute value is enabled for output 1.



Example 4 – Signed Output Quantity, Absolute Value Disabled

- [Analog Out1 Sel] = "Output Torque Current"
- [Analog Out1 Lo] = 1 volt
- [Analog Out1 Hi] set to 9 volts
- [Anlg Out Absolut] set so that absolute value is disabled for output 1.



Filtering

Software filtering will be performed on the analog outputs for certain signal sources, as specified in Table 2.A. “Filter A” is one possible such filter, and it is described later in this section. Any software filtering is in addition to any hardware filtering and sampling delays.

Table 2.A Software Filters

Quantity	Filter
Output Frequency	No extra filtering
Commanded Frequency	No extra filtering
Output Current	Filter A
Output Torque Current	Filter A
Output Flux Current	Filter A
Output Power	Filter A
Output Voltage	No extra filtering
DC Bus Voltage	Filter A
PI Reference	No extra filtering
PI Feedback	No extra filtering
PI Error	No extra filtering
PI Output	No extra filtering

Analog output software filters are specified in terms of the time it will take the output of the filter to move from 0% to various higher levels, given an instantaneous step in the filter input from 0% to 100%. The numbers describing filters in this document should be considered approximate; the actual values will depend on implementation.

Filter A is a single pole digital filter with a 162ms time constant. Given a 0% to 100% step input from a steady state, the output of Filter A will take 500ms to get to 95% of maximum, 810 ms to get to 99%, and 910 ms to get to 100%.

PowerFlex 700 Firmware 3.001 (& later) Enhancements

Certain analog output enhancements have been included in firmware version 3.001 (and later) for the PowerFlex 700 Vector Control drive. These include:

- Ability to scale the analog outputs
- Connect scale blocks to the analog outputs
- Analog Output controlled via Datalink

Output Scaling

A new scaling feature has been added to allow scaling. Prior to this feature, [Analog Outx Lo] and [Analog Outx Hi] limited only the voltage. This voltage range was scaled to the selected option range listed in [Analog Outx Sel]. With the new feature, [Analog Outx Lo] and [Analog Outx Hi] still set the voltage range, but the scaling parameter now scales the range of the [Analog Outx Sel] selection. See the following example.

INPUTS & OUTPUTS	Analog Outputs	354 355	Vector v3 **[Anlg Out1 Scale]** Vector v3 **[Anlg Out2 Scale]** Sets the high value for the range of analog out scale. Entering 0.0 will disable this scale and max scale will be used. Example: If [Analog Out Sel] = "Commanded Trq," a value of 150 = 150% scale in place of the default 800%.	Default: 0.0 Min/Max: [Analog Out1 Sel] Units: 0.01	

Example

Analog Output 1 set for 0-10V DC at 0-100% Commanded Torque.

Setup

- [Analog Out1 Sel], parameter 342 = 14 "Commanded Torque"
- [Analog Out1 Hi], parameter 343 = 10.000 Volts
- [Analog Out1 Lo], parameter 344 = 0.000 Volts
- [Anlg Out1 Scale], parameter 354 = 100.0

If [Analog Out1 Lo] = –10.000 Volts the output will be –10.0 to +10.0V DC for –100% to +100% Commanded Torque.

If [Anlg Out1 Scale] = 0.0, the default scaling listed in [Analog Out1 Sel] will be used. This would be 0-1.25V DC for 0-100% Torque or 0-800% for 0-10V DC.

Scale Block Analog Output

Selects scaled analog output relative to the Scale Block value. Values not in the [Analog OutX Sel] parameter list can be used to drive the analog outputs. When using the Scale Block select, the Scale block Out Hi and Out Lo parameters are not used.



Example

Analog Output 2 set for 0-10V DC for Heat Sink Temp 0-100 Degrees C. using Scale Block 1.

Setup

- Link [Scale1 In Value], parameter 476 to [Testpoint 1 Data], param. 235
- [Testpoint 1 Sel], parameter 234 = 2 "Heat Sink Temp"
- [Analog Out2 Sel], parameter 345 = 20 "Scale Block 1"
- [Analog Out2 Hi], parameter 346 = 10.000 Volts
- [Analog Out2 Lo], parameter 347 = 0.000 Volts
- [Scale1 In Hi], parameter 477 = 100
- [Scale1 In Lo], parameter 478 = 0

Parameter Controlled Analog Output

Enables the analog outputs to be controlled by Datalinks to the drive.

		377 378	Vector v3 [Anlg1 Out Setpt] Vector v3 [Anlg2 Out Setpt] Sets the analog output value from a communication device. Example: Set [Data In Ax] to "377" (value from communication device). Then set [Analog Outx Sel] to "Param Cntl."	Default: Min/Max: Units:	20.000 mA, 10.000 Volts 0.000/20.000mA –/+10.000V 0.001 mA 0.001 Volt

Example

Analog Output 1 controlled by DataLink C1. Output 0-10V DC with DataLink values of 0-10000.

Setup

- [Data In C1], parameter = 304 "Analog Output 1 Setpoint"
- [Analog Out1 Sel], parameter 342 = 24 "Parameter Control"
- [Analog Out1 Hi], parameter 343 = 10.000 Volts
- [Analog Out1 Lo], parameter 344= 0.000 Volts

The device that writes to DataLink C1 now controls the voltage output of Analog Out1. For example: 2500 = 2.5V DC, 5000 = 5.0V DC, 7500 = 7.5V DC.

Auto/Manual

The intent of Auto/Manual is to allow the user to override the selected reference (referred to as the “auto” reference) by either toggling a button on the programming terminal (HIM), or continuously asserting a digital input that is configured for Auto/Manual.

- “Alt” Function on the HIM

  By toggling the “Alt” and “Auto/Man” function on the HIM, the user can switch the speed reference back and forth between the active “Auto” source (per drive programming and inputs) and the HIM requesting the manual control. “Manual” switches the Reference Source to the HIM, “Auto” switches it back to drive programming.

  The HIM manual reference can be **preloaded** from the auto source by enabling the [Man Ref Preload] parameter. With the preload function enabled, when the HIM requests Manual control, the current value of the auto source is loaded into the HIM reference before manual control is granted. This allows the manual control to begin at the same speed as the auto source, creating a smooth transition. If the preload function is disabled, the speed will ramp to whatever manual reference was present in the HIM at the time manual control was granted.

- Digital Input

  By toggling the digital input programmed as Auto/Manual, the user can switch the speed reference back and forth between the active “Auto” source (per drive programming and inputs) and the designated Terminal Block manual reference. When this digital input is asserted, the TB will attempt to gain exclusive control (Manual) of the reference. If granted control of the reference, the specific source for the reference is determined by the parameter TB manual reference select.

  The TB manual reference is selected in [TB Man Ref Sel]. The choices for this parameter are:

  – Analog Input 1
  – Analog Input 2
  – MOP Level
  – Analog Input 3 (PF700 Only)
  – Pulse Input (PF700 Only)
  – Encoder input (PF700 Only)
  – Releasing this input sends the control back to the Auto source.

General Rules

The following rules apply to the granting and releasing of Manual control:

1. Manual control is requested through a one-time request (Auto/Man toggle, not continuously asserted). Once granted, the terminal holds Manual control until the Auto/Man button is pressed again, which releases Manual control (i.e. back to Auto mode).

2. Manual control can only be granted to the TB or to a programming terminal (e.g. HIM) if Manual control is not already being exercised by the TB or another programming terminal at the time.

3. Manual control can only be granted to a terminal if no other device has Local control already asserted (i.e. no other device has ownership of the Local control function).

4. A HIM (or TB) with Manual control active can have it taken away if another DPI port requests, and is granted Local control. In this case when Local control is released the drive will not go back to Manual control, Manual control must be again requested (edge based request, see 1. above). This is true for both the HIM and the TB (i.e. if the TB switch was in the Manual position it must be switched to Auto and back to Manual to get Manual control again).

5. The status indicator (point LED on LED HIM & Text on LCD HIM) will indicate when that particular terminal has been granted Manual control, not the fact any terminal connected has Manual control and not the fact that the particular terminal has simply asked for Manual control.

6. When Manual control is granted, the drive will latch and save the current reference value prior to entering Manual. When Manual control is then released the drive will use that latched reference for the drive until another DPI device arbitrates ownership and changes the reference to a different value.

7. If a terminal has Manual control and clears its DPI reference mask (disallows reference ownership), then Manual control will be released. By extension, if the drive is configured such that the HIM can not select the reference (via reference mask setting), then the drive will not allow the terminal to acquire Manual control.

8. If a terminal has Manual control and clears its DPI logic mask (allowing disconnect of the terminal), then Manual control will be released. By extension if the drive is configured such that the HIM can be unplugged (via logic mask setting), then the drive will not allow the terminal to acquire Manual control. The disconnect also applies to a DPI HIM that executes a soft “Logout.”

9. If a com loss fault occurs on a DPI that has Manual control, then Manual control will be released as a consequence of the fault (on that port which had Manual control).

10. There will be no way to request and hence no support of the Auto/Manual feature on old SCANport based HIMs.

11. You can not acquire Manual control if you are already an assigned source for the DPI port requesting Manual.

12. When a restore factory defaults is performed Manual control is aborted.

Auto Restart (Reset/ Run)

The Auto Restart feature provides the ability for the drive to automatically perform a fault reset followed by a start attempt without user or application intervention. This allows remote or “unattended” operation. Only certain faults are allowed to be reset. Certain faults (Type 2) that indicate possible drive component malfunction are not resettable.

Caution should be used when enabling this feature, since the drive will attempt to issue its own start command based on user selected programming.

Configuration

This feature is configured through two user parameters

		174	**[Auto Rstrt Tries]** Sets the maximum number of times the drive attempts to reset a fault and restart. **ATTENTION:** Equipment damage and/or personal injury may result if this parameter is used in an inappropriate application. Do Not use this function without considering applicable local, national and international codes, standards, regulations or industry guidelines.	Default: 0 Min/Max: 0/9 Display: 1	175
		175	**[Auto Rstrt Delay]** Sets the time between restart attempts when [Auto Rstrt Tries] is set to a value other than zero.	Default: 1.0 Secs Min/Max: 0.5/30.0 Secs Display: 0.1 Secs	174

Setting [Auto Rstrt Tries] to a value greater than zero will enable the Auto Restart feature. Setting the number of tries equal to zero will disable the feature.

The [Auto Rstrt Delay] parameter sets the time, in seconds, between each reset/run attempt.

The auto-reset/run feature provides 2 status bits in [Drive Status 2] – an active status, and a countdown status.

UTILITY / Diagnostics — 210 **[Drive Status 2]** Read Only — 209

Present operating condition of the drive.

Bit #	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	x	x	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	DPI at 500 K	Motor OverId	Bus Freq Reg	Curr Limit	AutoRst Act	AutoRst Cntdn	DB Active *	Auto Tuning	DC Braking	Stopping	Jogging	Running	Active	Ready		

1 = Condition True
0 = Condition False
x = Reserved

** Vector firmware 3.001 & later*

The typical steps performed in an Auto-Reset/Run cycle are as follows:

1. The drive is running and an auto-resettable fault occurs, tripping the drive.
2. After the number of seconds in [Auto Rstrt Delay], the drive will automatically perform an internal Fault Reset, resetting the faulted condition.

3. The drive will then issue an internal Start command to start the drive.
4. If another auto-resettable fault occurs the cycle will repeat itself up to the number of attempts set in [Auto Rstrt Tries].
5. If the drive faults repeatedly for more than the number of attempts set in [Auto Rstrt Tries] with less than five minutes between each fault, the auto-reset/run is considered unsuccessful and the drive remains in the faulted state.
6. Aborting an Auto-Reset/Run Cycle (see Aborting an Auto-Reset/Run Cycle for details).
7. If the drive remains running for five minutes or more since the last reset/run without a fault, or is otherwise stopped or reset, the auto-reset/run is considered successful. The entire process is reset to the beginning and will repeat on the next fault.

Beginning an Auto-Reset/Run Cycle

The following conditions must be met when a fault occurs for the drive to begin an auto-reset/run cycle.

- The fault must be defined as an auto-resettable fault
- [Auto Rstrt Tries] setting must be greater than zero.
- The drive must have been running, not jogging, not autotuning, and not stopping, when the fault occurred. (Note that a DC Hold state is part of a stop sequence and therefore is considered stopping.)

Aborting an Auto-Reset/Run Cycle

During an auto-reset/run cycle the following actions/conditions will abort the reset/run attempt process.

- Issuing a stop command from any source. (Note: Removal of a 2-wire run-fwd or run-rev command is considered a stop assertion).
- Issuing a fault reset command from any source.
- Removal of the *enable* input signal.
- Setting [Auto Rstrt Tries] to zero.
- The occurrence of a fault which is not auto-resettable.
- Removing power from the drive.
- Exhausting an Auto-Reset/Run Cycle

After all [Auto Rstrt Tries] have been made and the drive has not successfully restarted and remained running for five minutes or more, the auto-reset/run cycle will be considered exhausted and therefore unsuccessful. In this case the auto-reset/run cycle will terminate and an additional fault, “Auto Rstrt Tries” (Auto Restart Tries) will be issued if bit 5 of [Fault Config 1] = “1.”

Autotune

Description of parameters determined by the autotune tests.

Flux Current Test

[Flux Current Ref] is set by the flux current test. Flux current is the reactive portion of the motor current (portion of the current that is out of phase with the motor voltage) and is used to magnetize the motor. The flux current test is used to identify the value of motor flux current required to produce rated motor torque at rated current. When the flux test is performed, the motor will rotate. The drive accelerates the motor to approximately two-thirds of base speed and then coasts for several seconds.

IR Voltage Drop Test

[IR Voltage Drop] is set by the IR voltage drop test. [IR Voltage Drop] is used by the IR Compensation procedure to provide additional voltage at all frequencies to offset the voltage drop developed across the stator resistance. An accurate calculation of the [IR Voltage Drop] will ensure higher starting torque and better performance at low speed operation. The motor should not rotate during this test.

Vector FV Leakage Inductance Test

[Ixo Voltage Drop] is set by the leakage inductance test. This test measures the inductance characteristics of the motor. A measurement of the motor inductance is required to determine references for the regulators that control torque. The motor should not rotate during this test.

Vector FV Inertia Test

[Total Inertia] is set by the inertia test. [Total Inertia] represents the time in seconds, for the motor coupled to a load to accelerate from zero to base speed at rated motor torque. During this test, the motor is accelerated to about 2/3 of base motor speed. This test is performed during the Start-up mode, but can be manually performed by setting [Inertia Autotune] to “Inertia Tune”. The [Total Inertia] and [Speed Desired BW] automatically determine the [Ki Speed Loop] and [Kp Speed Loop] gains for the speed regulator.

Autotune Procedure for Sensorless Vector and Economizer

The purpose of Autotune is to identify the motor flux current and stator resistance for use in Sensorless Vector Control and Economizer modes.

The user must enter motor nameplate data into the following parameters for the Autotune procedure to obtain accurate results:

- [Motor NP Volts]
- [Motor NP Hertz]
- [Motor NP Power]

Next, the Dynamic or Static Autotune should be performed:

- Dynamic - the motor shaft will rotate during this test. The dynamic autotune procedure determines both the stator resistance and motor flux current. The test to identify the motor flux current requires the load to be uncoupled from the motor to find an accurate value. If this is not possible then the static test can be performed.
- Static - the motor shaft will not rotate during this test. The static test determines only [IR Voltage Drop]. This test does not require the load to be uncoupled from the motor.

The static and dynamic tests can be performed during the Start-up routine on the LCD HIM. The tests can also be run manually by setting the value of the [Autotune] parameter to 1 “Static Tune” or 2 “Rotate Tune”.

Alternate Methods to Determine [IR Voltage Drop] & [Flux Current Ref]

If it is not possible or desirable to run the Autotune tests, there are three other methods for the drive to determine the [IR Voltage Drop] and [Flux Current] parameters:

- The first method is used when the motor nameplate parameters are left at default. When the drive is initially powered up, the [Autotune] parameter is defaulted to a value of 3 “Calculate”. The values for [IR Voltage Drop] and [Flux Current] are calculated based on the default motor nameplate data. This is the least preferred method.
- The second method calculates them from the user-entered motor nameplate data parameters. When [Autotune] is set to 3 “Calculate”, any changes made by the user to motor nameplate HP, Voltage, or Frequency activates a new calculation. This calculation is based on a typical motor with those nameplate values.
- Finally, if the stator resistance and flux current of the motor are known, the user can calculate the voltage drop across the stator resistance. Then set [Autotune] to 0 “Ready” and directly enter these values into the [Flux Current] and [IR Voltage Drop] parameters.

Autotune Procedure for Flux Vector

Vector FV For FVC vector control an accurate model of the motor must be used. For this reason, the motor data must be entered and the autotune tests should be performed with the connected motor.

Motor nameplate data must be entered into the following parameters for the Autotune procedure to obtain accurate results:

- [Motor NP Volts]
- [Motor NP FLA]
- [Motor NP Hertz]
- [Motor NP RPM]
- [Motor NP Power]
- [Motor Poles]

Next the Dynamic or Static Autotune should be performed:

- Dynamic - the motor shaft will rotate during this test. The dynamic autotune procedure determines the stator resistance, motor flux current, and leakage inductance. The test to identify the motor flux current requires the load to be uncoupled from the motor to find an accurate value. If this is not possible then the static test can be performed.
- Static - the motor shaft will not rotate during this test. The static test determines only [IR Voltage Drop] and [Ixo Voltage Drop]. This test does not require the load to be uncoupled from the motor.

The static and dynamic tests can be performed during the Start-up routine on the LCD HIM. The tests can also be run manually by setting the value of [Autotune] to "1," (Static Tune) or "2" (Rotate Tune), respectively, and then starting the drive.

After the Static or Dynamic Autotune the Inertia test should be performed. The motor shaft will rotate during the inertia test. During the inertia test the motor should be coupled to the load to find an accurate value. The inertia test can be performed during the Start-up routine on the LCD HIM. The inertia test can also be run manually by setting [Inertia Autotune] to 1 "Inertia Tune", and then starting the drive.

Troubleshooting the Autotune Procedure

If any errors are encountered during the Autotune process drive parameters are not changed, the appropriate fault code will be displayed in the fault queue, and the [Autotune] parameter is reset to 0. If the Autotune procedure is aborted by the user, the drive parameters are not changed and the [Autotune] parameter is reset to 0.

The following conditions will generate a fault during an Autotune procedure:

- Incorrect stator resistance measurement
- Incorrect motor flux current measurement
- Load too large
- Autotune aborted by user
- Vector FV Incorrect leakage inductance measurement

Block Diagrams

The following pages contain the block diagrams for the PowerFlex 700 Vector Control drive.

Figure 2.1 PowerFlex 700VC Block Diagams (1)





V/Hz Mode with Speed Control

Figure 2.2 PowerFlex 700VC Block Diagams (2)

Figure 2.3 PowerFlex 700VC Block Diagams (3)



Speed Control - Reference (2.0 ms)



Figure 2.4 PowerFlex 700VC Block Diagams (4)

Figure 2.5 PowerFlex 700VC Block Diagams (5)





Figure 2.6 PowerFlex 700VC Block Diagams (6)

Figure 2.7 PowerFlex 700VC Block Diagams (7)



Figure 2.8 PowerFlex 700VC Block Diagams (8)



Figure 2.9 PowerFlex 700VC Block Diagams (9)



Figure 2.10 PowerFlex 700VC Block Diagams (10)



Figure 2.11 PowerFlex 700VC Block Diagams (11)



Figure 2.12 PowerFlex 700VC Block Diagams (12)



Bus Regulation

[Bus Reg Gain]
[Bus Reg Mode A, B]

Some applications, such as the hide tanning shown here, create an intermittent regeneration condition. When the hides are being lifted (on the left), motoring current exists. However, when the hides reach the top and fall onto a paddle, the motor regenerates power back to the drive, creating the potential for a nuisance overvoltage trip.

When an AC motor regenerates energy from the load, the drive DC bus voltage increases unless there is another means (dynamic braking chopper/ resistor, etc.) of dissipating the energy.



Without bus regulation, if the bus voltage exceeds the operating limit established by the power components of the drive, the drive will fault, shutting off the output devices to protect itself from excess voltage.



With bus regulation enabled, the drive can respond to the increasing voltage by advancing the output frequency until the regeneration is counteracted. This keeps the bus voltage at a regulated level below the trip point.

Since the same integrator is used for bus regulation as for normal frequency ramp operation, a smooth transition between normal frequency ramp operation and bus regulation is accomplished.

The regulator senses a rapid rise in the bus voltage and activates prior to actually reaching the internal bus voltage regulation set point Vreg. This is important since it minimizes overshoot in the bus voltage when bus regulation begins thereby attempting to avoid an over-voltage fault.

The bus voltage regulation set point (Vreg) in the drive is fixed for each voltage class of drive. The bus voltage regulation set points are identical to the internal dynamic brake regulation set points VDB's.



To avoid over-voltage faults, a bus voltage regulator is incorporated as part of the acceleration/deceleration control. As the bus voltage begins to approach the bus voltage regulation point (Vreg), the bus voltage regulator increases the magnitude of the output frequency and voltage to reduce the bus voltage. The bus voltage regulator function takes precedence over the other two functions. See Figure 2.13.

The bus voltage regulator is shown in the lower one-third of Figure 2.13. The inputs to the bus voltage regulator are the bus voltage, the bus voltage regulation set point Vreg, proportional gain, integral gain, and derivative gain. The gains are intended to be internal values and not parameters. These will be test points that are not visible to the user. Bus voltage regulation is selected by the user in the Bus Reg Mode parameter.

Operation

Bus voltage regulation begins when the bus voltage exceeds the bus voltage regulation set point Vreg and the switches shown in Figure 2.13 move to the positions shown in Table 2.B.

Table 2.B Switch Positions for Bus Regulator Active

	SW 1	SW 2	SW 3	SW 4	SW 5
Bus Regulation	Limit	Bus Reg	Open	Closed	Don't Care

Figure 2.13 Bus Voltage Regulator, Current Limit and Frequency Ramp.



The derivative term senses a rapid rise in the bus voltage and activates the bus regulator prior to actually reaching the bus voltage regulation set point Vreg. The derivative term is important since it minimizes overshoot in the bus voltage when bus regulation begins thereby attempting to avoid an over-voltage fault. The integral channel acts as the acceleration or deceleration rate and is fed to the frequency ramp integrator. The proportional term is added directly to the output of the frequency ramp integrator to form the output frequency. The output frequency is then limited to a maximum output frequency.

Bus voltage regulation is the highest priority of the three components of this controller because minimal drive current will result when limiting the bus voltage and therefore, current limit will not occur.

ATTENTION: The “adjust freq” portion of the bus regulator function is extremely useful for preventing nuisance overvoltage faults resulting from aggressive decelerations, overhauling loads, and eccentric loads. It forces the output frequency to be greater than commanded frequency while the drive's bus voltage is increasing towards levels that would otherwise cause a fault; however, it can also cause either of the following two conditions to occur.

1. Fast positive changes in input voltage (more than a 10% increase within 6 minutes) can cause uncommanded positive speed changes; however an “OverSpeed Limit” fault will occur if the speed reaches [Max Speed] + [Overspeed Limit]. If this condition is unacceptable, action should be taken to 1) limit supply voltages within the specification of the drive and, 2) limit fast positive input voltage changes to less than 10%. Without taking such actions, if this operation is unacceptable, the “adjust freq” portion of the bus regulator function must be disabled (see parameters 161 and 162).
2. Actual deceleration times can be longer than commanded deceleration times; however, a “Decel Inhibit” fault is generated if the drive stops decelerating altogether. If this condition is unacceptable, the “adjust freq” portion of the bus regulator must be disabled (see parameters 161 and 162). In addition, installing a properly sized dynamic brake resistor will provide equal or better performance in most cases.

Note: These faults are not instantaneous and have shown test results that take between 2 and 12 seconds to occur.

PowerFlex 70/700

The user selects the bus voltage regulator using the Bus Reg Mode parameters. The available modes include:

- off
- frequency regulation
- dynamic braking
- frequency regulation as the primary regulation means with dynamic braking as a secondary means
- dynamic braking as the primary regulation means with frequency regulation as a secondary means

The bus voltage regulation setpoint is determined off of bus memory (a means to average DC bus over a period of time). The following graph and tables describe the operation.

Table 2.C

Voltage Class	DC Bus Memory	DB On Setpoint	DB Off Setpoint
240	< 342V DC	375V DC	On – 4V DC
	> 342V DC	Memory + 33V DC	
480	< 685V DC	750V DC	On – 8V DC
	> 685V DC	Memory + 65V DC	
600	< 856V DC	937V DC	On – 10V DC
	> 856V DC	Memory + 81V DC	
600/690V PowerFlex 700 Frames 5 & 6 Only	< 983V DC	1076V DC	On – 11V DC
	> 983V DC	Memory + 93V DC	



If [Bus Reg Mode A], parameter 161 is set to “Dynamic Brak”

The Dynamic Brake Regulator is enabled. In “Dynamic Brak” mode the Bus Voltage Regulator is turned off. The “DB Turn On” and turn off curves apply (Table 2.C). For example, with a DC Bus Memory at 684V DC, the Dynamic Brake Regulator will turn on at 750V DC and turn back off at 742V DC.

If [Bus Reg Mode A], parameter 161 is set to “Both-Frq 1st”

Both regulators are enabled, and the operating point of the Bus Voltage Regulator is lower than that of the Dynamic Brake Regulator. The Bus Voltage Regulator setpoint follows the “Bus Reg Curve 2” below a DC Bus Memory of 650V DC and follows the “DB Turn Off” curve above a DC Bus Memory of 650V DC (Table 2.D). The Dynamic Brake Regulator follows the “DB Turn On” and turn off curves (Table 2.C). For example, with a DC Bus Memory at 684V DC, the Bus Voltage Regulator setpoint is 742V DC and the Dynamic Brake Regulator will turn on at 750V DC and back off at 742V DC.

If [Bus Reg Mode A], parameter 161 is set to “Adjust Freq”

The Bus Voltage Regulator is enabled. The Bus Voltage Regulator setpoint follows “Bus Reg Curve 1” below a DC Bus Memory of 650V DC and follows the “DB Turn On” above a DC Bus Memory of 650V DC (Table 2.D). For example, with a DC Bus Memory at 684V DC, the adjust frequency setpoint is 750V DC.

If [Bus Reg Mode A], parameter 161 is set to "Both-DB 1st"

Both regulators are enabled, and the operating point of the Dynamic Brake Regulator is lower than that of the Bus Voltage Regulator. The Bus Voltage Regulator setpoint follows the "DB Turn On" curve (Table 2.C). The Dynamic Brake Regulator follows the "DB Turn On" and turn off curves (Table 2.C). For example, with a DC Bus Memory at 684V DC, the Bus Voltage Regulator setpoint is 750V DC and the Dynamic Brake Regulator will turn on at 750V DC and back off at 742V DC.

Table 2.D

Voltage Class	DC Bus Memory	Bus Reg Curve #1	Bus Reg Curve #2
240	< 325V DC	Memory + 50V DC	Curve 1 – 4V DC
	325V DC ≤ DC Bus Memory ≤ 342V DC	375V DC	
	> 342V DC	Memory + 33V DC	
480	< 650V DC	Memory + 100V DC	Curve 1 – 8V DC
	650V DC ≤ DC Bus Memory ≤ 685V DC	750V DC	
	> 685V DC	Memory + 65V DC	
600	< 813V DC	Memory + 125V DC	Curve 1 – 10V DC
	813V DC ≤ DC Bus Memory ≤ 856V DC	937V DC	
	> 856V DC	Memory + 81V DC	
600/690V PowerFlex 700 Frames 5 & 6 Only	< 933V DC	Memory + 143V DC	Curve 1 – 11V DC
	933V DC ≤ DC Bus Memory ≤ 983V DC	1076V DC	
	> 983V DC	Memory + 93V DC	

Cable, Control

Refer to "*Wiring and Grounding Guidelines for Pulse Width Modulated (PWM) AC Drives*," publication DRIVES-IN001 for detailed information on Cable, Control.

Cable, Motor Lengths

Refer to "*Wiring and Grounding Guidelines for Pulse Width Modulated (PWM) AC Drives*," publication DRIVES-IN001 for detailed information on Cable, Motor Lengths.

Cable, Power

Refer to "*Wiring and Grounding Guidelines for Pulse Width Modulated (PWM) AC Drives*," publication DRIVES-IN001 for detailed information on Cable, Power.

Cable Trays and Conduit

Refer to "*Wiring and Grounding Guidelines for Pulse Width Modulated (PWM) AC Drives*," publication DRIVES-IN001 for detailed information on Cable Trays and Conduit.

Carrier (PWM) Frequency

See page 1-3 for derating guidelines as they relate to carrier frequency.

In general, the lowest possible switching frequency that is acceptable for any particular application is the one that should be used. There are several benefits to increasing the switching frequency. Refer to Figure 2.14 and Figure 2.15. Note the output current at 2 kHz and 4 kHz. The “smoothing” of the current waveform continues all the way to 10 kHz.

Figure 2.14 Current at 2 kHz PWM Frequency



Figure 2.15 Current at 4 kHz PWM Frequency



The benefits of increased carrier frequency include less motor heating and lower audible noise. An increase in motor heating is considered negligible and motor failure at lower switching frequencies is very remote. The higher switching frequency creates less vibration in the motor windings and laminations thus, lower audible noise. This may be desirable in some applications.

Some undesirable effects of higher switching frequencies include derating ambient temperature vs. load characteristics of the drive, higher cable charging currents and higher potential for common mode noise.

A very large majority of all drive applications will perform adequately at 2-4 kHz.

CE Conformity

EMC Instructions

CE Conformity

Conformity with the Low Voltage (LV) Directive and Electromagnetic Compatibility (EMC) Directive has been demonstrated using harmonized European Norm (EN) standards published in the Official Journal of the European Communities. PowerFlex Drives comply with the EN standards listed below when installed according to the User and Reference Manuals.

CE Declarations of Conformity are available online at:
http://www.ab.com/certification/ce/docs.

Low Voltage Directive (73/23/EEC)

- EN50178 Electronic equipment for use in power installations.

EMC Directive (89/336/EEC)

- EN61800-3 Adjustable speed electrical power drive systems Part 3: EMC product standard including specific test methods.

General Notes

- If the adhesive label is removed from the top of the drive, the drive must be installed in an enclosure with side openings less than 12.5 mm (0.5 in.) and top openings less than 1.0 mm (0.04 in.) to maintain compliance with the LV Directive.
- The motor cable should be kept as short as possible in order to avoid electromagnetic emission as well as capacitive currents.
- Use of line filters in ungrounded systems is not recommended.
- PowerFlex drives may cause radio frequency interference if used in a residential or domestic environment. The user is required to take measures to prevent interference, in addition to the essential requirements for CE compliance listed below, if necessary.
- Conformity of the drive with CE EMC requirements does not guarantee an entire machine or installation complies with CE EMC requirements. Many factors can influence total machine/installation compliance.
- PowerFlex drives can generate conducted low frequency disturbances (harmonic emissions) on the AC supply system.

Essential Requirements for CE Compliance

Conditions 1-6 listed below **must be** satisfied for PowerFlex drives to meet the requirements of **EN61800-3**.

1. Standard PowerFlex CE compatible Drive.
2. Review important precautions/attention statements throughout the User Manual before installing the drive.
3. Grounding as described on page 2-107.
4. Output power, control (I/O) and signal wiring must be braided, shielded cable with a coverage of 75% or better, metal conduit or equivalent attenuation.
5. All shielded cables should terminate with the proper shielded connector.
6. Conditions in the appropriate table (2.E, 2.F or 2.G).

Table 2.E PowerFlex 70 – EN61800-3 EMC Compatibility

Frame	Drive Description	Second Environment			
		Restrict Motor Cable to 40 m (131 ft.)	*Internal Filter Option*	*External Filter (1)*	*Input Ferrite (2)*
A	Drive Only	✔	–	✔	–
	Drive with any Comm Option	✔	–	✔	–
	Drive with ControlNet	✔	–	✔	✔
B	Drive Only	✔	✔	–	–
	Drive with any Comm Option	✔	✔	–	–
	Drive with ControlNet	✔	✔	–	✔
C	Drive Only	✔	–	–	–
	Drive with any Comm Option	✔	–	–	–
	Drive with ControlNet	✔	–	–	✔
D	Drive Only	✔	–	–	–
	Drive with any Comm Option	✔	–	–	–
	Drive with ControlNet	✔	–	–	✔
E	Drive Only	✔	–	–	–
	Drive with any Comm Option	✔	–	–	–
	Drive with ControlNet	✔	–	–	✔

Table 2.F PowerFlex 70 – EN61800-3 First Environment Restricted Distribution)

Frame	Drive Description	First Environment Restricted Distribution				
		Restrict Motor Cable to:	*Internal Filter Option*	*External Filter (1)*	*Comm Cable Ferrite (2)*	*Common Mode Core (3)*
A	Drive Only	40 m (131 ft.)	–	✔	–	–
	Drive with any Comm Option	40 m (131 ft.)	–	✔	–	–
	Drive with ControlNet	40 m (131 ft.)	–	✔	✔	–
B	Drive Only	12 m (40 ft.)	✔	–	–	–
	Drive with any Comm Option	12 m (40 ft.)	✔	–	–	–
	Drive with ControlNet	12 m (40 ft.)	✔	–	✔	–
C	Drive Only	12 m (40 ft.)	–	–	–	✔
	Drive with any Comm Option	12 m (40 ft.)	–	–	–	✔
	Drive with ControlNet	12 m (40 ft.)	–	–	✔	✔
D	Drive Only	12 m (40 ft.)	–	–	–	–
	Drive with any Comm Option	12 m (40 ft.)	–	–	–	–
	Drive with ControlNet	12 m (40 ft.)	–	–	✔	–
E	Drive Only	30 m (98 ft.)	–	✔	–	–
	Drive with any Comm Option	30 m (98 ft.)	–	✔	–	–
	Drive with ControlNet	30 m (98 ft.)	–	✔	✔	–

Table 2.G PowerFlex 700 EN61800-3 EMC Compatibility (1)

Frame	Second Environment *Restrict Motor Cable to 30 m (98 ft.)*	First Environment Restricted Distribution *Restrict Motor Cable to 150 m (492 ft.)*	
	Any Drive and Option	*Any Drive and Option*	*External Filter Required*
0-6	✔	✔	✔

(1) External filters for First Environment installations and increasing motor cable lengths in Second Environment installations are available. Roxburgh models KMFA (RF3 for UL installations) and MIF or Schaffner FN3258 and FN258 models are recommended. Refer to Table 2.H and **http://www.deltron-emcon.com** and **http://www.mtecorp.com** (USA) or **http://www.schaffner.com**, respectively.

(2) Two turns of the blue comm option cable through a Ferrite Core (Frames A, B, C Fair-Rite #2643102002, Frame D Fair-Rite #2643251002 or equivalent).

(3) Refer to the 1321 Reactor and Isolation Transformer Technical Data publication, 1321-TD001x for 1321-Mxxx selection information.

Table 2.H Recommended Filters(1)

Manufacturer	Drive Type	Frame	Manufacturer Part Number	Class A (Meters)	Class B (Meters)	Manufacturer Part Number	Class A (Meters)	Class B (Meters)
Deltron	PowerFlex 70	A	KMF306A	25	25	–	–	–
		B w/o Filter	KMF310A	50	25	–	–	–
		B w/Filter	KMF306A	100	50	MIF306	–	100
		C	KMF318A	–	150	–	–	–
		D	KMF336A	150	5	MIF330	–	150
		D w/o DC CM Capacitor	KMF336A	–	50	–	–	–
		E	–	–	–	MIF3100	–	30
	PowerFlex 700	0	KMF318A	–	100	MIF316	–	150
		1	KMF325A	–	150	–	–	–
		2	KMF350A	200	150	–	–	–
		2 w/o DC CM Capacitor	KMF350A	176	150	–	–	–
		3	KMF370A	150	100	–	–	–
		3 w/o DC CM Capacitor	KMF370A	150	100	–	–	–
Schaffner	PowerFlex 70	A	FN3258-7-45	–	50	–	–	–
		B w/o Filter	FN3258-7-45	100	50	–	–	–
		B w/Filter	FN3258-7-45	–	100	–	–	–
		C	FN3258-16-45	–	150	–	–	–
		D	FN3258-30-47	0	0	FN258-30-07	–	150
		D w/o DC CM Capacitor	FN3258-30-47	–	150	–	–	–
	PowerFlex 700	0	FN3258-16-45	–	150	–	–	–
		1	FN3258-30-47	–	150	–	–	–
		2	FN3258-42-47	50	50	–	–	–
		2 w/o DC CM Capacitor	FN3258-42-47	150	150	–	–	–
		3	FN3258-75-52	100	100	–	–	–
		3 w/o DC CM Capacitor	FN3258-75-52	150	150	–	–	–

(1) Use of these filters assumes that the drive is mounted in an EMC enclosure.

Copy Cat

Some PowerFlex drives have a feature called Copy Cat, which allows the user to upload a complete set of parameters to the LCD HIM. This information can then be used as backup or can be transferred to another drive by downloading the memory.

Generally, the transfer process manages all conflicts. If a parameter from HIM memory does not exist in the target drive, if the value stored is out of range for the drive or the parameter cannot be downloaded because the drive is running, the download will stop and a text message will be issued. The user than has the option of completely stopping the download or continuing after noting the discrepancy for the parameter that could not be downloaded. These parameters can then be adjusted manually.

The LCD HIM will store a number of parameter sets (memory dependant) and each individual set can be named for clarity.

Current Limit

[Current Lmt Sel]
[Current Lmt Val]
[Current Lmt Gain]

There are 6 ways that the drive can protect itself from overcurrent or overload situations:

- Instantaneous Overcurrent trip
- Software Instantaneous Trip
- Software Current Limit
- Overload Protection IT
- Heatsink temperature protection
- Thermal Manager

1. Instantaneous Overcurrent - This is a feature that instantaneously trips or faults the drive if the output current exceeds this value. The value is fixed by hardware and is typically 250% of drive rated amps. The Fault code for this feature is F12 “HW Overcurrent.” This feature cannot be defeated or mitigated.

2. Software Instantaneous Trip - There could be situations where peak currents do not reach the F12 “HW Overcurrent” value and are sustained long enough and high enough to damage certain drive components. If this situation occurs, the drives protection scheme will cause an F36 “SW Overcurrent” fault. The point at which this fault occurs is fixed and stored in drive memory.

3. Software Current Limit - This is a software feature that selectively faults the drive or attempts to reduce current by folding back output voltage and frequency if the output current exceeds this value. The [Current Lmt Val] parameter is programmable between approximately 25% and 150% of drive rating. The reaction to exceeding this value is programmable with [Shear Pin Fault]. Enabling this parameter creates an F63 “Shear Pin Fault.” Disabling this parameter causes the drive to use Volts/Hz fold back to try and reduce load.

   The frequency adjust or fold back operation consists of two modes. In the primary mode of current limit operation, motor phase current is sampled and compared to the Current Limit setting in the [Current Lmt Val]. If a current “error” exists, error is scaled by an integral gain and fed to the integrator. The output of this integrator is summed with the proportional term and the active speed mode component to adjust the output frequency and the commanded voltage. The second mode of current limit operation is invoked when a frequency limit has been reached and current limit continues to be active. At this point, a current regulator is activated to adjust the output voltage to limit the current. When the current limit condition ceases or the output voltage of the current regulator attempts to exceed the open loop voltage commands, control is transferred to the primary current limit mode or normal ramp operation.

4. Overload Protection I^2T - This is a software feature that monitors the output current over time and integrates per IT. The base protection is 110% for 1 minute or the equivalent I^2T value (i.e. 150% for 3 seconds, etc.). If the IT integrates to maximum, an F64 “Drive Overload” fault will occur. The approximate integrated value can be monitored via the [Drive OL Count] parameter.

5. Heatsink Temperature Protection - The drive constantly monitors the heatsink temperature. If the temperature exceeds the drive maximum, a “Heatsink OvrTemp” fault will occur. The value is fixed by hardware at a nominal value of 100 degrees C. This fault is generally not used for overcurrent protection due to the thermal time constant of the heatsink. It is an overload protection.

6. Thermal manager (see Drive Overload on page 2-86).

Datalinks

A Datalink is one of the mechanisms used by PowerFlex drives to transfer data to and from a programmable controller. Datalinks allow a parameter value to be changed without using an Explicit Message or Block Transfer. Datalinks consist of a pair of parameters that can be used independently for 16 bit transfers or in conjunction for 32 bit transfers. Because each Datalink consists of a pair of parameters, when enabled, each Datalink occupies two 16 or 32-bit words in both the input and output image tables, depending on configuration. A user enters a parameter number into the Datalink parameter. The value that is in the corresponding output data table word in the controller is then transferred to the parameter whose number has been placed in the Datalink parameter. The following example demonstrates this concept. The object of the example is to change Accel and Decel times “on the fly” under PLC control.

The user makes the following PowerFlex drive parameter settings:
Parameter 300 [Data In A1] = 140 (the parameter number of [Accel Time 1]
Parameter 301 [Data In A2] = 142 (the parameter number of [Decel Time 1]



In the PLC data Table, the user enters Word 3 as a value of 100 (10.0 Secs) and word 4 as a value of 133 (13.3 seconds). On each I/O scan, the parameters in the PowerFlex drive are updated with the value from the data table:
Accel Time P140 = 10.0 seconds (value from output image table Word 3)
Decel Time P142 = 13.3 seconds (value from output image table Word 4).

Any time these values need to be changed, the new values are entered into the data table, and the parameters are updated on the next PLC I/O scan.

Rules for Using Datalinks

1. 1. A Datalink consists of 4 words, 2 for Datalink x IN and 2 for Datalink x Out. They cannot be separated or turned on individually.
2. Only one communications adapter can use each set of Datalink parameters in a PowerFlex drive. If more than one communications adapter is connected to a single drive, multiple adapters must not try to use the same Datalink.
3. Parameter settings in the drive determine the data passed through the Datalink mechanism
4. When you use a Datalink to change a value, the value is not written to the Non-Volatile Storage (EEprom memory). The value is stored in volatile memory (RAM) and lost when the drive loses power.

32-Bit Parameters using 16-Bit Datalinks

To read (and/or write) a 32-bit parameter using 16-bit Datalinks, typically both Datalinks (A,B,C,D) are set to the 32-bit parameter. For example, to read Parameter 09 - [Elapsed MWh], both Datalink A1 and A2 are set to "9." Datalink A1 will contain the least significant word (LSW) and Datalink A2 the most significant word (MSW). In this example, the parameter 9 value of 5.8MWh is read as a "58" in Datalink A1

Datalink	Most/Least Significant Word	Parameter	Data (decimal)
A1	LSW	9	58
A2	MSW	9	0

Regardless of the Datalink combination, x1 will always contain the LSW and x2 will always contain the MSW.

In the following examples Parameter 242 - [Power Up Marker] contains a value of 88.4541 hours.

Datalink	Most/Least Significant Word	Parameter	Data (decimal)
A1	LSW	242	32573
A2	-Not Used-	0	0

Datalink	Most/Least Significant Word	Parameter	Data (decimal)
A1	-Not Used-	0	0
A2	MSW	242	13

Even if non-consecutive Datalinks are used (in the next example, Datalinks A1 and B2 would not be used), data is still returned in the same way.

Datalink	Most/Least Significant Word	Parameter	Data (decimal)
A2	MSW	242	13
B1	LSW	242	32573

32-bit data is stored in binary as follows:

MSW	2^{31} through 2^{16}
LSW	2^{15} through 2^{0}

Example

Parameter 242 - [Power Up Marker] = 88.4541 hours
MSW = $13_{decimal} = 1101_{binary} = 2^{16} + 2^{18} + 2^{19} = 851968$
LSW = 32573
851968 + 32573 = 884541

DC Bus Voltage / Memory

[DC Bus Voltage] is a measurement of the instantaneous value. [DC Bus Memory] is a heavily filtered value or "nominal" bus voltage. Just after the pre-charge relay is closed during initial power-up bus pre-charge, bus memory is set equal to bus voltage. Thereafter it is updated by ramping at a very slow rate toward Vbus. The filtered value ramps at approximately 2.4V DC per minute (for a 480V AC drive).

Bus memory is used as the base line to sense a power loss condition. If the drive enters a power loss state, the bus memory will also be used for recovery (i.e. pre-charge control or inertia ride through upon return of the power source) upon return of the power source. Update of the bus memory is blocked during deceleration to prevent a false high value caused by a regenerative condition.

Decel Time

[Decel Time 1, 2]

Sets the rate at which the drive ramps down its output frequency after a Stop command or during a decrease in command frequency (speed **change**). The rate established is the result of the programmed Decel Time and the Minimum and Maximum Frequency, as follows:

$$\frac{\text{Maximum Speed}}{\text{Decel Time}} = \text{Decel Rate (Hz/sec)}$$

Two decel times exist to allow the user to change rates "on the fly" via PLC command or digital input. The selection is made by programming [Decel Time 1] & [Decel Time 2] and then using one of the digital inputs ([Digital Inx Sel]) programmed as "Decel 2" (see Table 2.I for further information). However, if a PLC is used, manipulate the bits of the command word as shown below.


MOP Dec
Spd Ref ID 2 (1)
Spd Ref ID 1 (1)
Spd Ref ID 0 (1)
Decel 2
Decel 1
Accel 2
Accel 1
Mop Inc
Local Contrl
Reverse
Forward
Clear Fault
Jog
Start
Stop
0 0 0 0 1 1 1 0 1 0 0 0 1 1 0 0
15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0
Bit #
1 = Condition True
0 = Condition False
x = Reserved
0 0 0 1 Accel 1
0 0 1 0 Accel 2
0 1 0 0 Decel 1
1 0 0 0 Decel 2

The effectiveness of these bits or digital inputs can be affected by [Decel Mask]. See Masks on page 2-114 for more information.

Times are adjustable in 0.1 second increments from 0.0 seconds to 3600.0 seconds.

In its factory default condition, when no decel select inputs are closed and no time bits are "1," the default deceleration time is [Decel Time 1] and the rate is determined as above.

Digital Inputs

Cable Selection

Refer to "*Wiring and Grounding Guidelines for Pulse Width Modulated (PWM) AC Drives*," publication DRIVES-IN001 for detailed information on Cable Selection for Digital Inputs.

Wiring Examples

Refer to the appropriate PowerFlex user manual for wiring diagrams.

PowerFlex 70

Each digital input has a maximum response/pass through/function execution time of 25ms. For example, no more than 25ms should elapse from the time the level changes at the Start input to the time voltage is applied to the motor.

There is both hardware and software filtering on these inputs. The hardware provides an average delay of 12ms from the time the level changes at the input to the earliest time that the software can detect the change. The actual time can vary between boards from 7 to 17ms, but any particular board should be consistent to within 1% of its average value. The amount of software filtering is not alterable by the user.

PowerFlex 700

Each digital input has a maximum response/pass through/function execution time of 25ms. This means that, for example, no more than 25ms should elapse from the time the level changes at the Start input to the time voltage is applied to the motor.

Digital Input Configuration

Inputs are configured for the required function by setting a [Digital Inx Sel] parameter (one for each input). These parameters cannot be changed while the drive is running.

PowerFlex 700 Digital Input Selection

INPUTS & OUTPUTS / Digital Inputs

361 **[Digital In1 Sel]**
362 **[Digital In2 Sel]**
363 **[Digital In3 Sel]**
364 **[Digital In4 Sel]**
365 **[Digital In5 Sel]**
366 **[Digital In6 Sel]**(11)

Selects the function for the digital inputs.

(1) Speed Select Inputs.

3	2	1	Auto Reference Source
0	0	0	Reference A
0	0	1	Reference B
0	1	0	Preset Speed 2
0	1	1	Preset Speed 3
1	0	0	Preset Speed 4
1	0	1	Preset Speed 5
1	1	0	Preset Speed 6
1	1	1	Preset Speed 7

To access Preset Speed 1, set [Speed Ref x Sel] to "Preset Speed 1".

Type 2 Alarms - Some digital input programming may cause conflicts that will result in a Type 2 alarm. Example: [Digital In1 Sel] set to "5, Start" in 3-wire control and [Digital In2 Sel] set to 7 "Run" in2-wire.

Refer to User Manual for information on resolving this type of conflict.

(2) Vector Control Option Only.

(3)

3	2	1	Spd/Trq Mode
0	0	0	Zero Torque
0	0	1	Spd Reg
0	1	0	Torque Reg
0	1	1	Min Spd/Trq
1	0	0	Max Spd/Trq
1	0	1	Sum Spd/Trq
1	1	0	Absolute
1	1	1	Zero Trq

Default:	4	"Stop – CF"	
Default:	5	"Start"	
Default:	18	"Auto/ Manual"	
Default:	15	"Speed Sel 1"	
Default:	16	"Speed Sel 2"	
Default:	17	"Speed Sel 3"	
Options:	0	"Not Used"	
	1	"Enable"(8)(10)	
	2	"Clear Faults"(CF)(4)	
	3	"Aux Fault"	
	4	"Stop – CF"(10)	
	5	"Start"(5)(9)	
	6	"Fwd/ Reverse"(5)	
	7	"Run"(6)(10)	
	8	"Run Forward"(6)	
	9	"Run Reverse"(6)	
	10	"Jog"(5) "Jog1"(2)(5)	
	11	"Jog Forward"(6)	100
	12	"Jog Reverse"(6)	
	13	"Stop Mode B"	
	14	"Bus Reg Md B"	156
	15-17	"Speed Sel 1-3"(1)	162
	18	"Auto/ Manual"(7)	
	19	"Local"	
	20	"Acc2 & Dec2"	
	21	"Accel 2"	096
	22	"Decel 2"	
	23	"MOP Inc"	140
	24	"MOP Dec"	
	25	"Excl Link"	
	26	"PI Enable"	194
	27	"PI Hold"	
	28	"PI Reset"	380
	29	"Pwr Loss Lvl"	384
	30	"Precharge En"	388
	31-33	"Spd/Trq Sel1-3"(2,3)	124
	34	"Jog 2"(2)	

(4) When [Digital Inx Sel] is set to option 2 "Clear Faults" the Stop button cannot be used to clear a fault condition.

(5) Typical 3-Wire Inputs - Requires that only 3-wire functions are chosen. Including 2-wire selections will cause a type 2 alarm.

(6) Typical 2-Wire Inputs - Requires that only 2-wire functions are chosen. Including 3-wire selections will cause a type 2 alarm. See User Manual for conflicts.

(7) Auto/Manual - Refer to User Manual for details.

(8) Opening an "Enable" input will cause the motor to coast-to-stop, ignoring any programmed Stop modes.

(9) A "Dig In ConflictB" alarm will occur if a "Start" input is programmed without a "Stop" input.

(10) Refer to the Sleep-Wake Mode Attention statement on User Manual .

(11) A dedicated hardware enable input is available via a jumper selection. Refer to User Manual for further information.

PowerFlex 70 Digital Input Selection

INPUTS & OUTPUTS (File J) — Digital Inputs

361	**[Digital In1 Sel]**	Default:	4	"Stop – CF" (CF = Clear Fault)
362	**[Digital In2 Sel]**	Default:	5	"Start"
363	**[Digital In3 Sel]**	Default:	18	"Auto/ Manual"
364	**[Digital In4 Sel]**	Default:	15	"Speed Sel 1"
365	**[Digital In5 Sel]**	Default:	16	"Speed Sel 2"
366	**[Digital In6 Sel]**	Default:	17	"Speed Sel 3"
	Selects the function for the digital inputs.	Options:	0	"Not Used"
	(1) When [Digital Inx Sel] is set to option 2 "Clear Faults" the Stop button cannot be used to clear a fault condition.		1	"Enable"(6)
			2	"Clear Faults"(1)
			3	"Aux Fault"
			4	"Stop – CF"(2)
	(2) Typical 3-Wire Inputs. Requires that only 3-wire functions are chosen. Including 2-wire selections will cause a type 2 alarm.		5	"Start"(2)(7)
			6	"Fwd/ Reverse"(2)
			7	"Run"(3)
	(3) Typical 2-Wire Inputs. Requires that only 2-wire functions are chosen. Including 3-wire selections will cause a type 2 alarm.		8	"Run Forward"(3)
			9	"Run Reverse"(3)
			10	"Jog"(2) 100
			11	"Jog Forward"
			12	"Jog Reverse"
			13	"Stop Mode B" 156
			14	"Bus Reg Md B" 162
			15	"Speed Sel 1"(4)
			16	"Speed Sel 2"(4)
			17	"Speed Sel 3"(4)
			18	"Auto/ Manual"(5) 096
			19	"Local"
			20	"Acc2 & Dec2" 140
			21	"Accel 2"
			22	"Decel 2"
			23	"MOP Inc" 194
			24	"MOP Dec"
			25	"Excl Link" 380
			26	"PI Enable" 384
			27	"PI Hold" 388
			28	"PI Reset" 124

(4) Speed Select Inputs.

3	2	1	Auto Reference Source
0	0	0	Reference A
0	0	1	Reference B
0	1	0	Preset Speed 2
0	1	1	Preset Speed 3
1	0	0	Preset Speed 4
1	0	1	Preset Speed 5
1	1	0	Preset Speed 6
1	1	1	Preset Speed 7

To access Preset Speed 1, set [Speed Ref A Sel] or [Speed Ref B Sel] to "Preset Speed 1".

Type 2 Alarms
Some digital input programming may cause conflicts that will result in a Type 2 alarm. Example: [Digital In1 Sel] set to 5 "Start" in 3-wire control and [Digital In2 Sel] set to 7 "Run" in 2-wire.

Refer to Alarm Descriptions in the User Manual for information on resolving this type of conflict.

(5) Auto/Manual - Refer to User Manual for details.

(6) Opening an "Enable" input will cause the motor to coast-to-stop, ignoring any programmed Stop modes.

(7) A "Dig In ConflictB" alarm will occur if a "Start" input is programmed without a "Stop" input.

The available functions are defined in Table 2.I.

Table 2.I Digital Input Function List

Input Function Name	Purpose
Stop - CF	Stop drive Clear Faults (open to closed transition)
Run Forward	Run in forward direction (2-wire start mode)
Run Reverse	Run in reverse direction (2-wire start mode)
Run	Run in current direction (2-wire start mode)
Start	Start drive (3-wire start mode)
Forward/Reverse	Set drive direction (3-wire mode only)
Jog	Jog drive
Jog Forward	Jog in forward direction
Jog Reverse	Jog in reverse direction
Speed Select 3 Speed Select 2 Speed Select 1	Select which Speed reference the drive uses.
Auto/Manual	Allows terminal block to assume complete control of Speed Reference.
Accel 2	Select acceleration rate 1 or 2.
Decel 2	Select deceleration rate 1 or 2.
Accel 2 & Decel 2	Select acceleration rate 1 and deceleration rate 1 or acceleration rate 2 and deceleration rate 2.
MOP Increment	Increment MOP (Motor Operated Pot Function Speed ref)
MOP Decrement	Decrement MOP (Motor Operated Pot Function Speed ref)
Stop Mode B	Select Stop Mode A (open) or B (closed)
Bus Regulation Mode B	Select which bus regulation mode to use
PI Enable	Enable Process PI loop.
PI Hold	Hold integrator for Process PI loop at current value.
PI Reset	Clamp integrator for Process PI loop to 0.
Auxiliary Fault	Open to cause “auxiliary fault” (external string).
Local Control	Allows terminal block to assume complete control of drive logic.
Clear Faults	Clear faults and return drive to ready status.
Enable	Open input causes drive to coast to stop, disallows start.
Exclusive Link	Exclusive Link – digital input is routed through to digital output, no other use.
Power Loss Level (PowerFlex 700 only)	Selects between using fixed value for power loss level and getting the level from a parameter
Precharge Enable (PowerFlex 700 only)	If common bus configuration, denotes whether drive is disconnected from DC bus or not. Controls precharge sequence on reconnection to bus.

Input Function Detailed Descriptions

- **Stop - Clear Faults**

  An open input will cause the drive to stop and become “not ready”. A closed input will allow the drive to run.

  If “Start” is configured, then “Stop - Clear Faults” must also be configured. Otherwise, a digital input configuration alarm will occur. “Stop - Clear Faults” is optional in all other circumstances.

  An open to closed transition is interpreted as a Clear Faults request. The drive will clear any existing faults. The terminal block bit must be set in the [Fault Mask] and [Logic Mask] parameters in order for the terminal block to clear faults using this input function.

If the “Clear Faults” input function is configured at the same time as “Stop - Clear Faults”, then it will not be possible to reset faults with the “Stop - Clear Faults” input.

- **Run Forward, Run Reverse**

  An open to closed transition on one input or both inputs while drive is stopped will cause the drive to run unless the “Stop - Clear Faults” input function is configured and open.

  The table below describes the basic action taken by the drive in response to particular states of these input functions.

Run Forward	Run Reverse	Action
Open	Open	Drive stops, terminal block relinquishes direction ownership.
Open	Closed	Drive runs in reverse direction, terminal block takes direction ownership.
Closed	Open	Drive runs in forward direction, terminal block takes direction ownership.
Closed	Closed	Drive continues to run in current direction, but terminal block maintains direction ownership.

  If one of these input functions is configured and the other one isn’t, the above description still applies, but the unconfigured input function should be considered permanently open.

  The terminal block bit must be set in the [Start Mask], [Direction Mask], and [Logic Mask] parameters in order for the terminal block to start or change the direction of the drive using these inputs.

  Important: Direction control is an “Exclusive Ownership” function (see Owners). This means that only one control device (terminal block, DPI device, HIM, etc.) at a time is allowed to control direction at a time. The terminal block must become direction “owner” before it can be used to control direction. If another device is currently the direction owner (as indicated by [Direction Owner]), **it will not be possible to start the drive or change direction by using the terminal block digital inputs programmed for both Run and Direction control (i.e. Run/Fwd).**

  If one or both of these input functions is configured, it will not be possible to start or jog the drive from any other control device. This is true irrespective of the state of the [Start Mask], [Direction Mask], and [Logic Mask] parameters.

- **Run**

  An open to closed transition on this input while drive is stopped will cause the drive to run in the currently selected direction unless the “Stop - Clear Faults” input function is configured and open.

  If this input is open, then the drive will stop.

  The purpose of this input function is to allow a 2-wire start while the direction is being controlled by some other means.

The terminal block bit must be set in the [Start Mask] and [Logic Mask] parameters in order for the terminal block to start the drive using this input.

If the “Run” input function is configured, it will not be possible to start or jog the drive from any other control device. This is true irrespective of the state of the [Start Mask], [Direction Mask], and [Logic Mask] parameters.

The Effects of 2-Wire Start Modes on Other DPI Devices

The “Run/Stop” and “Run Fwd/Rev” start modes are also called “2-wire” start modes, because they allow the drive to be started and stopped with only a single input and two wires. When a “2-wire” terminal block start mode is put into effect by the user, the drive can no longer be started or jogged from any other control device (i.e. HIM, network card, etc.). This restriction persists as long as one or more of “Run”, “Run Forward”, and “Run Reverse” are configured. This is true even if the configuration is otherwise illegal and causes a configuration alarm. See page 2-109 for typical 2 and 3-wire configurations.

- **Start**
  An open to closed transition while the drive is stopped will cause the drive to run in the current direction, unless the “Stop – Clear Faults” input function is open.

  The terminal block bit must be set in the [Start Mask] and [Logic Mask] parameters in order for the terminal block to start or change the direction of the drive using these inputs.

  If “Start” is configured, then “Stop - Clear Faults” must also be configured.

- **Forward/Reverse**
  This function is one of the ways to provide direction control when the Start / Stop / Run functions of the drive are configured as 3 – wire control.

  An open input sets direction to forward. A closed input sets direction to reverse. If state of input changes and drive is running or jogging, drive will change direction.

  The terminal block bit must be set in the [Direction Mask] and [Logic Mask] parameters in order for the terminal block to select the direction of the drive using this input function.

  Important: Direction control is an “Exclusive Ownership” function (see Owners). This means that only one control device (terminal block, DPI device, HIM, etc.) at a time is allowed to control direction at a time. The terminal block must become direction “owner” before it can be used to control direction. If another device is currently the direction owner (as indicated by [Direction Owner]), **it will not be possible to**

start the drive or change direction by using the terminal block digital inputs programmed for both Run and Direction control (i.e. Run/Fwd).

Important: Because an open condition (or unwired condition) commands Forward, the terminal block seeks direction ownership as soon as this input function is configured, which may happen at power-up. In order for the terminal block to actually gain ownership, the masks must be set up correctly (see above) and no other device can currently have direction ownership. Once the terminal block gains direction ownership, it will retain it until shutdown, until the [Direction Mask] or [Logic Mask] bits for the terminal block are cleared, or until this input function is no longer configured

- **Jog**

  Jog is essentially a non-latched “run/start” command. An open to closed transition while drive is stopped causes drive to start (jog) in the current direction. When the input opens while drive is running (jogging), the drive will stop.

  The drive will not jog while running or while the “Stop - Clear Faults” input is open. **Start has precedence.**

ATTENTION: If a normal drive start command is received while the drive is jogging, the drive will switch from jog mode to run mode. The drive will not stop, but may change speed and/or change direction.

  The terminal block bit must be set in the [Jog Mask] and [Logic Mask] parameters in order for the terminal block to cause the drive to jog using this input function.

- **Jog Forward, Jog Reverse**

  An open to closed transition on one input or both inputs while drive is stopped will cause the drive to jog unless the “Stop - Clear Faults” input function is configured and open. The table below describes the actions taken by the drive in response to various states of these input functions.

Jog Forward	Jog Reverse	Action
Open	Open	Drive will stop if already jogging, but can be started by other means. Terminal block relinquishes direction ownership.
Open	Closed	Drive jogs in reverse direction. Terminal block takes direction ownership.
Closed	Open	Drive jogs in forward direction. Terminal block takes direction ownership.
Closed	Closed	Drive continues to jog in current direction, but terminal block maintains direction ownership.

  If one of these input functions is configured and the other one isn’t, the above description still applies, but the unconfigured input function should be considered permanently open.

The drive will not jog while drive is running or while “Stop - Clear Faults” input is open. **Start has precedence**.

ATTENTION: If a normal drive start command is received while the drive is jogging, the drive will switch from jog mode to run mode. The drive will not stop, but may change speed and/or change direction.

The terminal block bit must be set in the [Jog Mask], [Direction Mask], and [Logic Mask] parameters in order for the terminal block to cause the drive to jog using these input functions.

Important: Direction control is an “Exclusive Ownership” function (see Owners). This means that only one control device (terminal block, DPI device, HIM, etc.) at a time is allowed to control direction at a time. The terminal block must become direction “owner” before it can be used to control direction. If another device is currently the direction owner (as indicated by [Direction Owner]), **it will not be possible to jog the drive or change direction by using the terminal block digital inputs programmed for both Run and Direction control (i.e. Run/Fwd).**

If another device is not currently the direction owner (as indicated by [Direction Owner]) and the terminal block bit is set in the [Direction Mask] and [Logic Mask] parameters, the terminal block becomes direction owner as soon as one (or both) of the “Jog Forward” or “Jog Reverse” input functions is closed.

- **Speed select 1, 2, and 3**

  One, two, or three digital input functions can be used to select the speed reference used by the drive, and they are called the Speed Select input functions. The current open/closed state of all Speed Select input functions combine to select which source is the current speed reference. There are 8 possible combinations of open/closed states for the three input functions, and thus 8 possible parameters can be selected. The 8 parameters are: [Speed Ref A Sel], [Speed Ref B Sel], and [Preset Speed 2] through [Preset Speed 7].

  If the Speed Select input functions select [Speed Ref A Sel] or [Speed Ref B Sel], then the value of that parameter further selects a reference source. There are a large number of possible selections, including all 7 presets.

  If the input functions directly select one of the preset speed parameters, then the parameter contains a frequency that is to be used as the reference.

The terminal block bit must be set in the [Reference Mask] and [Logic Mask] parameters in order for the reference selection to be controlled from the terminal block using the Speed Select inputs functions.

Important: Reference Control is an “Exclusive Ownership” function (see Owners on page 2-127). This means that only one control device (terminal block, DPI device, HIM, etc.) at a time is allowed to select the reference source. The terminal block must become direction “owner” before it can be used to control direction. If another device is currently the reference owner (as indicated by [Reference Owner]), it will not be possible to select the reference by using the terminal block digital inputs, and the Speed Select Inputs will have no effect on which reference the drive is currently using.

Because any combination of open/closed conditions (or unwired condition) commands a reference source, terminal block seeks ownership of reference selection as soon as any of these input functions are configured, which may happen at power-up. In order for the terminal block to actually gain ownership, the masks must be set up correctly (see above) and no other device can currently have reference ownership. Once the terminal block gains reference ownership, it will retain it until shutdown, until the [Reference Mask] or [Logic Mask] bits for the terminal block are cleared, or until none of the digital inputs are configured as Speed Select input functions.

The Speed Select input function configuration process involves assigning the functionality of the three possible Speed Select input functions to physical digital inputs. The three Speed Select inputs functions are called “Speed Select 1”, “Speed Select 2”, and “Speed Select 3”, and they are assigned to physical inputs using the [Digital In*x* Sel] parameters.

The table below describes the various reference sources that can be selected using all three of the Speed Select input functions.

Speed Select 3	Speed Select 2	Speed Select 1	Parameter that determines Reference
Open	Open	Open	[Speed Ref A Sel]
Open	Open	Closed	[Speed Ref B Sel]
Open	Closed	Open	[Preset Speed 2]
Open	Closed	Closed	[Preset Speed 3]
Closed	Open	Open	[Preset Speed 4]
Closed	Open	Closed	[Preset Speed 5]
Closed	Closed	Open	[Preset Speed 6]
Closed	Closed	Closed	[Preset Speed 7]

If any of the three Reference Select input functions are not configured, then the software will still follow the table, but will treat the unconfigured inputs as if they are permanently open.

As an example, the table below describes what reference selections can be made if “Speed Select 1” is the only configured input function. This

configuration allows a single input to choose between [Speed Ref A Sel] and [Speed Ref B Sel].

Speed Select 1	Selected Parameter that determines Reference
Open	[Speed Ref A Sel]
Closed	[Speed Ref B Sel]

As another example, describes what reference selections can be made if the “Speed Select 3” and “Speed Select 2” input functions are configured, but “Speed Select 1” is not.

Speed Select 3	Speed Select 2	Selected Parameter that determines reference
Open	Open	[Speed Ref A Sel]
Open	Closed	[Preset Speed 2]
Closed	Open	[Preset Speed 4]
Closed	Closed	[Preset Speed 6]

- **Auto/Manual**

  The Auto/Manual facility is essentially a higher priority reference select. It allows a single control device to assume exclusive control of reference select, irrespective of the reference select digital inputs, reference select DPI commands, the reference mask, and the reference owner.

  If the “Auto/Manual” input function is closed, then the drive will use one of the analog inputs (defined by [TB Man Ref Sel]) as the reference, ignoring the normal reference selection mechanisms. This mode of reference selection is called “Terminal Block Manual Reference Selection Mode”.

  If this input function is open, then the terminal block does not request manual control of the reference. If no control device (including the terminal block) is currently requesting manual control of the reference, then the drive will use the normal reference selection mechanisms. This is called “Automatic Reference Selection” mode.

  The drive arbitrates among manual reference requests from different control devices, including the terminal block.

- **Accel 2 / Decel 2**

  The Acceleration/Deceleration Rate Control input functions (Acc/Dec input functions for short) allow the rate of acceleration and deceleration for the drive to be selected from the terminal block. The rates themselves are contained in [Accel Time 1], [Decel Time 1], [Accel Time 2], and [Decel Time 2]. The Acc/Dec input functions are used to determine which of these acceleration and deceleration rates are in effect at a particular time.

  The terminal block bit must be set in the [Accel Mask] and [Logic Mask] parameters in order for the acceleration rate selection to be controlled from the terminal block. The terminal block bit must be set in the [Decel Mask] and [Logic Mask] parameters in order for the deceleration rate selection to be controlled from the terminal block.

  There are two different schemes for using the Acc/Dec input functions. Each one will be described in its own section.

- **Accel 2, Decel 2**

  In the first scheme, one input function (called “Accel 2”) selects between [Accel Time 1] and [Accel Time 2], and another input function (called “Decel 2”) selects between [Decel Time 1] and [Decel Time 2]. The open state of the function selects [Accel Time 1] or [Decel Time 1], and the closed state selects [Accel Time 2] or [Decel Time 2].

  Important: Acc/Dec Control is an “Exclusive Ownership” function (see Owners). This means that only one control device (terminal block, DPI device, HIM, etc.) at a time is allowed to select the Acc/Dec rates. The terminal block must become Acc/Dec “owner” before it can be used to control ramp rates. If another device is currently the reference owner (as indicated by [Reference Owner]), it will not be possible to select the reference by using the terminal block digital inputs, and the Speed Select Inputs will have no effect on which reference the drive is currently using.

  Because any combination of open / closed conditions (or unwired condition) commands a reference source, the terminal block seeks accel ownership as soon as the “Accel 2” input function is configured, which may happen at power-up. In order for the terminal block to actually gain ownership, the masks must be set up correctly (see above) and no other device can currently have accel ownership. Once the terminal block gains accel ownership, it will retain it until shutdown, until the [Accel Mask] or [Logic Mask] bits for the terminal block are cleared, or until “Accel 2” is unconfigured.

  For the “Decel 2” input function, deceleration rate selection ownership is handled in a similar fashion to acceleration rate selection ownership.

- **Acc2 & Dec2**

  In the second scheme, the “1” rates are combined (Acc and Dec) and the “2” rates are combined. A single input function is used to select between [Accel Time 1]/[Decel Time 1] and [Accel Time 2]/[Decel Time 2]. This input function is called “Acc 2 & Dec 2”.

  If function is open, then drive will use [Accel Time 1] as the acceleration rate and [Decel Time 1] as the deceleration rate. If function is closed, then drive will use [Accel Time 2] as the acceleration rate and [Decel Time 2] as the deceleration rate.

  The same ownership rules as above apply.

- **MOP Increment, MOP Decrement**

  These inputs are used to increment and decrement the Motor Operated Potentiometer (MOP) value inside the drive. The MOP is a reference setpoint (called the “MOP Value”) that can be incremented and decremented by external devices. The MOP value will be retained through a power cycle.

  While the “MOP Increment” input is closed, MOP value will increase at rate contained in [MOP Rate]. Units for rate are Hz per second.

While the “MOP Decrement” input is closed, MOP value will decrease at rate contained in [MOP Rate]. Units for rate are Hz per second.

If both the “MOP Increment” and “MOP Decrement” inputs are closed, MOP value will stay the same.

The terminal block bit must be set in the [MOP Mask] and [Logic Mask] parameters in order for the MOP to be controlled from the terminal block.

In order for the drive to use the MOP value as the current speed reference, either [Speed Ref A Sel] or [Speed Ref B Sel] must be set to “MOP.”

- **Stop Mode B**
  This digital input function selects between two different drive stop modes. See also Stop Modes on page 2-201.

  If the input is open, then [Stop Mode A] selects which stop mode to use. If the input is closed, then [Stop Mode B] selects which stop mode to use. If this input function is not configured, then [Stop Mode A] always selects which stop mode to use.

- **Bus Regulation Mode B**
  This digital input function selects how the drive will regulate excess voltage on the DC bus. See also Bus Regulation.

  If the input is open, then [Bus Reg Mode A] selects which bus regulation mode to use. If the input is closed, then [Bus Reg Mode B] selects which bus regulation mode to use. If this input function is not configured, then [Bus Reg Mode A] always selects which bus regulation mode to use.

- **PI Enable**
  If this input function is closed, the operation of the Process PI loop will be enabled.

  If this input function is open, the operation of the Process PI loop will be disabled. See Process PI Loop on page 2-137.

- **PI Hold**
  If this input function is closed, the integrator for the Process PI loop will be held at the current value, which is to say that it will not increase.

  If this input function is open, the integrator for the Process PI loop will be allowed to increase. See Process PI Loop on page 2-137.

- **PI Reset**
  If this input function is closed, the integrator for the Process PI loop will be reset to 0.

  If this input function is open, the integrator for the Process PI loop will integrate normally. See Process PI Loop on page 2-137.

- **Auxiliary Fault**

  The “Aux Fault” input function allows external equipment to fault the drive. Typically, one or more machine inputs (limit switches, pushbuttons, etc.) will be connected in series and then connected to this input. If the input function is open, the software detects the change of state then the drive will fault with the “Auxiliary Input” (F2) fault code.

  If the “Aux Fault” input function is assigned to a physical digital input, that input will be active regardless of any drive control masks. Also, the input will be active even if a device other than the terminal block gains complete local control of drive logic. See Local Control.

  If this input function is not configured, then the fault will not occur.

- **Local Control**

  The “Local Control” input function allows exclusive control of all drive logic functions from the terminal block. If this input function is closed, the terminal block has exclusive control (disabling all the DPI devices) of drive logic, including start, reference selection, acceleration rate selection, etc. The exception is the stop condition, which can always be asserted from any connected control device.

  The drive must be stopped in order for the terminal block to gain complete local control.

  Important: Local Control is an “Exclusive Ownership” function (see Owners). This means that only one control device (terminal block, DPI device, HIM, etc.) at a time is allowed take local control. If another device is not currently the local owner (as indicated by [Local Owner]) and the terminal block bit is set in the [Local Mask] and [Logic Mask] parameters, the terminal block becomes local owner as soon as the “Local Control” input function is closed.

- **Clear Faults**

  The “Clear Faults” digital input function allows an external device to reset drive faults through the terminal block. An open to closed transition on this input will cause the current fault (if any) to be reset.

  If this input is configured at the same time as “Stop - Clear Faults”, then only the “Clear Faults” input can actually cause faults to be reset.

  The terminal block bit must be set in the [Fault Mask] and [Logic Mask] parameters in order for faults to be reset from the terminal block.

- **Enable**

  If this input is closed, then the drive can run (start permissive). If open, the drive will not start.

  If the drive is already running when this input is opened, the drive will coast and indicate “not enabled” on the HIM (if present). This is not considered a fault condition, and no fault will be generated.

This input is not used for a fast output power removal. The drive will not stop running until the software detects the open state of this input function.

If multiple “Enable” inputs are configured, then the drive will not run if any of the inputs are open.

- **Exclusive Link**
  This input function is used to activate the state of the input to control one of the drive’s digital outputs. See Digital Outputs.

  If an Input is so configured, no function exists for the input until complementary Digital Output programming is done. If no outputs are programmed (linked), the input has no function.

  This choice is made when the user wishes to link the input to the output, but desires that no other functionality be assigned to the input.

  The state of any digital input can be “passed through” to a digital output by setting the value of a digital output configuration parameter ([Digital Out*x* Sel]) to “Input *n* Link”. The output will then be controlled by the state of the input, even if the input is being used for a second function. If the input is configured as “Not used” input function, the link to the input is considered non-functional.

- **Power Loss Level (PowerFlex 700 only)**
  When the DC bus level in the drive falls below a certain level, a “power loss” condition is created in the drive logic. This input allows the user to select between two different “power loss” detection levels dynamically.

  If the physical input is closed, then the drive will take its power loss level from [Power Loss Level]. If the physical input is open (de-energized), then the drive will use a power loss level designated by internal drive memory, typically 82% of nominal.

  If the input function is not configured, then the drive always uses the internal power loss level. This input function is used in PowerFlex 700 drives only. In PowerFlex 70 drives, the power loss level is always internal and not selectable.

- **Precharge Enable (PowerFlex 700 only)**
  This input function is used to manage disconnection from a common DC bus.

  If the physical input is closed, this indicates that the drive is connected to common DC bus and normal precharge handling can occur, and that the drive can run (start permissive). If the physical input is open, this indicates that the drive is disconnected from the common DC bus, and thus the drive should enter the precharge state (precharge relay open) and initiate a coast stop immediately in order to prepare for reconnection to the bus.

  If this input function is not configured, then the drive assumes that it is always connected to the DC bus, and no special precharge handling will be done. This input function is used in PowerFlex 700 drive only. In

PowerFlex 70 drives, the drive assumes it is always connected to the DC bus.

Digital Input Conflict Alarms

If the user configures the digital inputs so that one or more selections conflict with each other, one of the digital input configuration alarms will be asserted**. As long as the Digital Input Conflict exists, the drive will not start.** These alarms will be automatically cleared by the drive as soon as the user changes the parameters so that there is an internally consistent digital input configuration.

Examples of configurations that cause an alarm are:

- User tries to configure both the "Start" input function and the "Run Forward" input function at the same time. "Start" is only used in "3-wire" start mode, and "Run Forward" is only used in "2-wire" run mode, so they should never be configured at the same time
- User tries to assign a toggle input function (for instance "Forward/ Reverse") to more than one physical digital input simultaneously.
- These alarms, called Type 2 Alarms, are different from other alarms in that it will not be possible to start the drive while the alarm is active. It should not be possible for any of these alarms to occur while drive is running, because all configuration parameters are only changeable while drive is stopped. Whenever one or more of these alarms is asserted, the drive ready status will become "not ready" and the HIM will reflect a message signaling the conflict. In addition, the drive status light will be flashing yellow.

There are three different digital input configuration alarms. They appear to the user (in [Drive Alarm 2]) as "DigIn CflctA", "DigIn CflctB", and "DigIn CflctC".

"DigIn CflctA" indicates a conflict between different input functions that are not specifically associated with particular start modes.

The table below defines which pairs of input functions are in conflict. Combinations marked with a " " will cause an alarm.

Important: There are combinations of input functions in Table 2.J that will produce **other** digital input configuration alarms. "DigIn CflctA" alarm will **also** be produced if "Start" is configured and "Stop – Clear Faults" is not.

Table 2.J Input function combinations that produce "DigIn CflctA" alarm

	Acc2/Dec2	Accel 2	Decel 2	Jog	Jog Fwd	Jog Rev	Fwd/Rev
Acc2 / Dec2							
Accel 2							
Decel 2							
Jog							
Jog Fwd							
Jog Rev							
Fwd / Rev							

"DigIn CflctB" indicates a digital Start input has been configured without a Stop input or other functions are in conflict. Combinations that conflict are marked with a "" and will cause an alarm.

Table 2.K Input function combinations that produce "DigIn CflctB" alarm

	Start	Stop–CF	Run	Run Fwd	Run Rev	Jog	Jog Fwd	Jog Rev	Fwd/ Rev
Start									
Stop–CF									
Run									
Run Fwd									
Run Rev									
Jog									
Jog Fwd									
Jog Rev									
Fwd / Rev									

"Digin CflctC" indicates that more than one physical input has been configured to the same input function, and this kind of multiple configuration isn't allowed for that function. Multiple configuration is allowed for some input functions and not allowed for others.

The input functions for which multiple configuration is not allowed are:

Forward/Reverse	Run Forward	Stop Mode B
Speed Select 1	Run Reverse	Bus Regulation Mode B
Speed Select 2	Jog Forward	Accel2 & Decel2
Speed Select 3	Jog Reverse	Accel 2
	Run	Decel 2

There is one additional alarm that is related to digital inputs: the "Bipolar Cflct" alarm occurs when there is a conflict between determining motor direction using digital inputs on the terminal block and determining it by the polarity of an analog speed reference signal.

Note that the drive will assert an alarm when the user sets up a illegal configuration rather than refusing the first parameter value that results in such a configuration. This is necessary because the user may have to change several parameters one at a time in order to get to a new desired configuration, and some of the intermediate configurations may actually be illegal. Using this scheme, the user or a network device can send parameter updates in any order when setting up the digital input configuration.

The "Bipolar Cflct" alarm occurs when there is a conflict between determining motor direction using digital inputs on the terminal block and determining it by some other means.

When [Direction Mode] is "Bipolar", the drive uses the sign of the reference to determine drive direction; when [Direction Mode] is "Reverse Dis", then the drive never permits the motor to run in the reverse direction. In both of these cases, the terminal block inputs cannot be used to set direction, so this alarm is asserted if any digital input function that can set motor direction is configured.

The “Bipolar Cflct” alarm will be asserted if **both** of the following are true:

- One or more of the following digital input functions are configured: “Forward/Reverse”, “Run Forward”, “Run Reverse”, “Jog Forward”, “Jog Reverse”.
- [Direction Mode] is set to “Bipolar” or “Reverse Dis”.

Digital In Status

This parameter represents the current state of the digital inputs. It contains one bit for each input. The bits are “1” when the input is closed and “0” when the input is open.

Digital In Examples

PowerFlex 70

Figure 2.16 shows a typical digital input configuration that includes “3-wire” start. The digital input configuration parameters should be set as shown.

Figure 2.16 Typical digital input configuration with “3-wire” start



Figure 2.17 represents a typical digital input configuration that includes “2-wire” start. The digital input configuration parameters should be set up as shown

Figure 2.17 Typical digital input configuration with “Run Fwd/Rev” start



Digital Outputs

Each drive provides digital (relay) outputs for external annunciation of a variety of drive conditions. Each relay is a Form C (1 N.O. – 1 N.C. with shared common) device whose contacts and associated terminals are rated for a maximum of 250V AC or 220V DC. The table below shows specifications and limits for each relay/contact.

	PowerFlex 70		PowerFlex 700	
	Resistive Load	Inductive Load	Resistive Load	Inductive Load
Rated Voltage	250V AC	250V AC	240V AC	240V AC
	220V DC	220V DC	30V DC	30V DC
Maximum Current	3 A	1.5 A	5 A	3.5 A
Maximum Power	AC - 50 VA	AC - 25 VA	1200 VA	840 VA
	DC - 60 W	DC - 30 W	150W	105W
Minimum DC Current	10 μA		10 mA	
Switching Time	8 ms		10 ms	
Initial State	De-energized		De-energized	
Number of relays (Standard I/O)	2		2 - Standard Control 3 - Vector Control	

Configuration

The outputs may be independently configured via the following parameters to switch for various states of the drive.

PowerFlex 700 Digital Output Selection

		380 384 388	**[Digital Out1 Sel]**(5) **[Digital Out2 Sel]** Vector **[Digital Out3 Sel]**	Default: Options:	1 4 4 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21-26 27 28 29 30	"Fault" "Run" "Run" "Fault"(1) "Alarm"(1) "Ready" "Run" "Forward Run" "Reverse Run" "Auto Restart" "Powerup Run" "At Speed"(6) "At Freq"(3) "At Current"(3) "At Torque"(3) "At Temp"(3) "At Bus Volts"(3) "At PI Error"(3) "DC Braking" "Curr Limit" "Economize" "Motor Overld" "Power Loss" "Input 1-6 Link"(6) "PI Enable"(2) "PI Hold"(2) "Drive Overload"(2) "Param Cntl"(4, 6)	381 385 389 382 386 390 383 002 001 003 004 218 012 137 157 147 053 048 184 379

Selects the drive status that will energize a (CRx) output relay.

(1) Any relay programmed as Fault or Alarm will energize (pick up) when power is applied to drive and deenergize (drop out) when a fault or alarm exists. Relays selected for other functions will energize only when that condition exists and will deenergize when condition is removed.

(2) Vector Control Option Only.

(3) Activation level is defined in [Dig Outx Level] below.

(4) Vector firmware 3.001 and later.

(5) When [TorqProve Cnfg] is set to "Enable," [Digital Out1 Sel] becomes the brake control and any other selection will be ignored.

(6) Refer to Option Definitions in User Manual.

PowerFlex 70 Digital Output Selection

INPUTS & OUTPUTS (File J)	Digital Outputs	380 384	**[Digital Out1 Sel]** **[Digital Out2 Sel]** Selects the drive status that will energize a (CRx) output relay. (1) Contacts shown on page 1-14 of the User Manual are in drive powered state with condition not present. For functions such as "Fault" and "Alarm" the normal relay state is energized and N.O. / N.C. contact wiring may have to be reversed.	Default: Options:	1 4 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26	"Fault" "Run" "Fault"(1) "Alarm"(1) "Ready" "Run" "Forward Run" "Reverse Run" "Auto Restart" "Powerup Run" "At Speed" "At Freq" "At Current" "At Torque" "At Temp" "At Bus Volts" "At PI Error" "DC Braking" "Curr Limit" "Economize" "Motor Overld" "Power Loss" "Input 1 Link" "Input 2 Link" "Input 3 Link" "Input 4 Link" "Input 5 Link" "Input 6 Link"	381 385 389 382 386 390 383 002 001 003 004 218 012 137 157 147 053 048 184

The selections can be divided into three types of annunciation.

1. The relay changes state due to a particular status condition in the drive.

The following drive conditions or status can be selected to cause the relay activation:

Condition	Description
Fault	A drive Fault has occurred and stopped the drive
Alarm	A Drive Type 1 or Type 2 Alarm condition exists
Ready	The drive is powered, Enabled and no Start Inhibits exist. It is "ready" to run
Run	The drive is outputting Voltage and frequency to the motor (indicates 3–wire control, either direction)
Forward Run	The drive is outputting Voltage and frequency to the motor (indicates 2–wire control in Forward)
Reverse Run	The drive is outputting Voltage and frequency to the motor (indicates 2–wire control in Reverse)
Reset/Run	The drive is currently attempting the routine to clear a fault and restart the drive
Powerup Run	The drive is currently executing the Auto Restart or "Run at Power Up" function
DC Braking	The drive is currently executing either a "DC Brake" or a "Ramp to Hold" Stop command and the DC braking voltage is still being applied to the motor.
Current Limit	The drive is currently limiting output current
Economize	The drive is currently reducing the output voltage to the motor to attempt to reduce energy costs during a lightly loaded situation.
Mtr Overload	The drive output current has exceeded the programmed [Motor NP FLA] and the electronic motor overload function is accumulating towards an eventual trip.
Power Loss	The drive has monitored DC bus voltage and sensed a loss of input AC power that caused the DC bus voltage to fall below the fixed monitoring value (82% of [DC bus Memory]

2. The relay changes state because a particular value in the drive has exceeded a preset limit.

The following drive values can be selected to cause the relay activation:

Condition	Description
At Speed	The drive Output Frequency has equalled the commanded frequency

The balance of these functions require that the user set a limit for the specified value. The limit is set into one of two parameters: [Dig Out1 Level] and [Dig Out2 Level] depending on the output being used. If the value for the specified function (frequency, current, etc.) exceeds the user programmed limit, the relay will activate. If the value falls back below the limit, the relay will deactivate.

		381 385 389	**[Dig Out1 Level]** **[Dig Out2 Level]** Vector **[Dig Out3 Level]** Sets the relay activation level for options 10 – 15 in [Digital Outx Sel]. Units are assumed to match the above selection (i.e. “At Freq” = Hz, “At Torque” = Amps).	Default: Min/Max: Units:	0.0 0.0 0.0/819.2 0.1	380 384 388

Notice that the [Dig Outx Level] parameters do not have units. The drive assumes the units from the selection for the annunciated value. For example, if the chosen “driver” is current, the drive assumes that the entered value for the limit [Dig Outx Level] is% rated Amps. If the chosen “driver” is Temperature, the drive assumes that the entered value for the limit [Dig Outx Level] is degrees C. No units will be reported to LCD HIM users, offline tools, devices communicating over a network, PLC’s, etc.

The online and offline limits for the digital output threshold parameters will be the minimum and maximum threshold value required for any output condition.

If the user changes the currently selected output condition for a digital output, then the implied units of the corresponding threshold parameter will change with it, although the value of the parameter itself will not. **For example,** if the output is set for “At Current” and the threshold for 100, drive current over 100% will activate the relay. If the user changes the output to “At Temp”, the relay will deactivate (even if current > 100%) because the drive is cooler than 100 degrees C.

The following values can be annunciated

Value	Description
At Freq	The drive output frequency equals or exceeds the programmed Limit
At Current	The drive total output current exceeds the programmed Limit
At Torque	The drive output torque current component exceeds the programmed Limit
At Temp	The drive operating temperature exceeds the programmed Limit
At Bus Volts	The drive bus voltage exceeds the programmed Limit
At PI Error	The drive Process PI Loop error exceeds the programmed Limit

3. The relay changes state because a Digital Input link has been established and the Input is closed.

An Output can be “linked” directly to an Digital Input so that the output “tracks” the input. When the input is closed, the Output will be energized, and when the input is open, the output will be de-energized. This “tracking will occur if two conditions exist:

– The Input is configured for any choice other than “Unused”
– The Output is configured for the appropriate “Input x Link”

Note that the output will continue to track or be controlled by the state of the input, even if the input has been assigned a function (i.e. Start, Jog)

Output Time Delay

Each digital output has two user-controlled timers associated with it.

One timer (the ON timer) defines the delay time between a FALSE to TRUE transition (condition appears) on the output condition and the corresponding change in state of the digital output.

The second timer (the OFF timer) defines the delay time between a TRUE to FALSE transition (condition disappears) on the output condition and the corresponding change in the state of the digital output.

	382 386 390	**[Dig Out1 OnTime]** **[Dig Out2 OnTime]** **Vector** **[Dig Out3 OnTime]** Sets the “ON Delay” time for the digital outputs. This is the time between the occurrence of a condition and activation of the relay.	Default: 0.00 Secs 0.00 Secs Min/Max: 0.00/600.00 Secs Units: 0.01 Secs	380 384 388
	383 387 391	**[Dig Out1 OffTime]** **[Dig Out2 OffTime]** **Vector** **[Dig Out3 OffTime]** Sets the “OFF Delay” time for the digital outputs. This is the time between the disappearance of a condition and de-activation of the relay.	Default: 0.00 Secs 0.00 Secs Min/Max: 0.00/600.00 Secs Units: 0.01 Secs	380 384 388

Either timer can be disabled by setting the corresponding delay time to “0.”

Important: Whether a particular type of transition (False-True or True-False) on an output condition results in an energized or de-energized output depends on the output condition.

If a transition on an output condition occurs and starts a timer, and the output condition goes back to its original state before the timer runs out, then the timer will be aborted and the corresponding digital output will not change state.



PowerFlex 700 Firmware 3.001 (& later) Enhancements

Certain digital output enhancements have been included in firmware version 3.001 (and later) for the PowerFlex 700 Vector Control drive. These include:

- Digital output control via Datalink

Parameter Controlled Digital Outputs
Enables control of the digital outputs through the Data In parameters.


INPUTS & OUTPUTS
Digital Outputs
379
Vector v3
[Dig Out Setpt]
380
Sets the digital output value from a communication device.
Example
Set [Data In B1] to "379." The first three bits of this value will determine the setting of [Digital Outx Sel] which should be set to "24, Param Cntl."
Net DigOut3
Net DigOut2
Net DigOut1
x x x x x x x x x x x x x 0 0 0
15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0
Bit #
1 = Output Energized
0 = Output De-energized
x = Reserved

Example
Digital Output 2 controlled by Data In B1

Setup
- [Data In B1], parameter 302 = 379 ([Dig Out Setpt] as the Data In target)
- [Digital Out2 Sel], parameter 384 = 30 "Param Cntl"

When Bit 1 of Data In B1 =1 Digital Out 2 will be energized.

Direction Control

Direction control of the drive is an exclusive ownership function. Thus only one device can be commanding/controlling direction at a time and that device can only command one direction or the other, not both. Direction is defined as the forward (+) or reverse (–) control of the drive output frequency, not motor rotation. Motor wiring and phasing determines its CW or CCW rotation. Direction of the drive is controlled in one of four ways:

1. 2-Wire digital input selection such as Run Forward or Run Reverse (Figure 2.17 on page 2-77).
2. 3-Wire digital input selection such as Forward/Reverse, Forward or Reverse (Figure 2.16 on page 2-77).
3. Control Word bit manipulation from a DPI device such as a communications interface. Bits 4 & 5 control direction. Refer to the *Logic Command Word* information in Appendix A of the PowerFlex 70 or 700 User Manual.
4. The sign (+/-) of a bipolar analog input.

Direction commands by various devices can be controlled using the [Direction Mask]. See page 2-114 for details on masks.

Refer to Digital Inputs on page 2-61 and Analog Inputs on page 2-9 for more detail on the configuration and operating rules for direction control.

DPI

Drive Peripheral Interface (DPI) is an enhancement to SCANport that provides more functions and better performance. SCANport was a CAN based, Master-Slave protocol, created to provide a standard way of connecting motor control products and optional peripheral devices together. It allows multiple (up to 6) devices to communicate with a motor control product without requiring configuration of the peripheral. SCANport and DPI both provide two basic message types called Client/Server (C/S) and Producer/Consumer (P/C). Client/Server messages are used to transfer parameter and configuration information in the background (relative to other message types). Producer/Consumer messages are used for control and status information. DPI adds a higher baud rate, brand specific enabling, Peer-to-Peer (P/P) communication, and Flash Memory programming support. PowerFlex 70 & 700 support the existing SCANport and DPI communication protocols. Multiple devices of each type (SCANport or DPI) can be attached to and communicate with PowerFlex 70 & 700 drives at the same time. This communication interface is the primary way to interact with, and control the drive.

Important: The PowerFlex 700 Vector Control option only supports the DPI communication protocol. It will not communicate with SCANport peripheral devices.

Client/Server

Client/Server messages operate in the background (relative to other message types) and are used for non-control purposes. The Client/Server messages are based on a 10ms “ping” event that allows peripherals to perform a single transaction (i.e. one C/S transaction per peripheral per time period). Message fragmentation (because the message transaction is larger than the standard CAN message of eight data bytes) is automatically handled by Client/Server operation. The following types of messaging are covered:

- Logging in peripheral devices
- Read/Write of parameter values
- Access to all parameter information (limits, scaling, default, etc.)
- User set access
- Fault/Alarm queue access
- Event notification (fault, alarm, etc.)
- Access to all drive classes/objects (e.g. Device, Peripheral, Parameter, etc.)

Producer/Consumer operation overview

Producer/Consumer messages operate at a higher priority than Client/Server messages and are used to control/report the operation of the drive (e.g. start, stop, etc.). A P/C status message is transmitted every 5ms (by the drive) and a command message is received from every change of state in any attached DPI peripheral. Change of state is a button being pressed or error detected by a DPI peripheral. SCANport devices are slightly different in that those peripherals transmit command messages upon reception of a drive status

message rather than on detection of a change of state. Producer/Consumer messages are of fixed size, so support of message fragmentation is not required. The following types of messaging are covered:

- Drive status (running, faulted, etc.)
- Drive commands (start, stop, etc.)
- Control logic parsing operations (e.g., mask and owner parameters)
- Entering Flash programming mode
- “Soft” login and logout of peripheral devices (enabling/disabling of peripheral control)

Peer-to-Peer operation

Peer-to-Peer messaging allows two devices to communicate directly rather than through the master or host (i.e. drive). They are the same priority as C/S messages and will occur in the background. In the PowerFlex 70 drive, the only Peer-to-Peer functionality supports proxy operations for the LED HIM. Since the PowerFlex 700 drive does not support an LED HIM, it will not support Peer-to-Peer proxy operations. The Peer-to-Peer proxy operation is only used so that the LED HIM can access parameters that are not directly part of the regulator board (e.g. DeviceNet baud rate, etc.). The LED HIM is not attached to a drive through a CAN connection (as normal DPI or SCANport devices are), so a proxy function is needed to create a DPI message to access information in an off-board peripheral. If an LCD HIM is attached to the PowerFlex 70 or 700 drive, it will be able to directly request off-board parameters using Peer-to-Peer messages (i.e. no proxy support needed in the drive). Because the PowerFlex 70 supports the LED HIM, only 4 communication ports can be used. PowerFlex 700 drives can use all 6 communication ports because Peer-to-Peer proxy operations are not needed. All Peer-to-Peer operations occur without any intervention from the user (regardless whether proxy or normal P/P operation), no setup is required. No Peer-to-Peer proxy operations are required while the drive is in Flash mode.

All the timing requirements specified in the DPI and SCANport System, Control, and Messaging specifications are supported. Peripheral devices will be scanned (“pinged”) at a 10ms rate. Drive status messages will be produced at a 5ms rate, while peripheral command messages will be accepted (by the drive) as they occur (i.e. change of state). Based on these timings, the following worst case conditions can occur (independent of the baud rate and protocol):

- Change of peripheral state (e.g. Start, Stop, etc.) to change in the drive – 10ms
- Change in reference value to change in drive operation – 10ms
- Change in Datalink data value to change in the drive – 10ms
- Change of parameter value into drive – 20ms times the number of attached peripherals

The maximum time to detect the loss of communication from a peripheral device is 500ms.

Table 2.L Timing specifications contained in DPI and SCANport

DPI	Host status messages only go out to peripherals once they log in and at least every 125ms (to all attached peripherals). Peripherals time out if >250ms. Actual time dependent on number of peripherals attached. Minimum time goal of 5ms (may have to be dependent on Port Baud Rate). DPI allows minimum 5ms status at 125k and 1ms status at 500k.
SCANport	Host status messages only go out to peripherals once they log in. Peripherals time out if >500ms. If Peripheral receives incorrect status message type, Peripheral generates an error. Actual time dependent on number of peripherals attached. SCANport allows minimum rate of 5ms.
DPI	Host determines MUT based on number of attached peripherals. Range of values from 2 to 125ms. Minimum goal time of 5ms. DPI allows 2ms min at 500k and 5ms min at 125k.
SCANport	No MUT.
DPI	Peripheral command messages (including Datalinks) generated on change-of-state, but not faster than Host MUT and at least every 250ms. Host will time out if >500ms.
SCANport	Command messages produced as a result of Host status message. If no command response to Host status within 3 status scan times, Host will time out on that peripheral.
DPI	Peer messages requests cannot be sent any faster than 2x of MUT.
SCANport	No Peer message support
DPI	Host must ping every port at least every 2 sec. Peripherals time out if >3 sec. Host will wait maximum of 10ms (125k) or 5ms (500k) for peripheral response to ping. Peripherals typical response time is 1ms. Peripherals only allow one pending explicit message (i.e. ping response or peer request) at a time.
SCANport	Host waits at least 10ms for response to ping. Host cannot send more than 2 event messages (including ping) to a peripheral within 5ms. Peripherals typical response time is 1ms.
DPI	Response to an explicit request or fragment must occur within 1 sec or device will time out (applies to Host or Peripheral). Time-out implies retry from beginning. Maximum number of fragments per transaction is 16. Flash memory is exception with 22 fragments allowed.
SCANport	Assume same 1 sec time-out. Maximum number of fragments is 16
DPI	During Flash mode, host stops ping, but still supports status/command messages at a 1 – 5 sec rate. Drive will use 1 sec rate. Data transfer occurs via explicit message as fast as possible (i.e. peripheral request, host response, peripheral request, etc.) but only between two devices.
SCANport	No Flash mode support

The Minimum Update Time (MUT), is based on the message type only. A standard command and Datalink command could be transmitted from the same peripheral faster than the MUT and still be O.K. Two successive Datalink commands or standard commands will still have to be separated by the MUT, however.

Drive Overload

The drive thermal overload has two primary functions. The first requirement is to make sure the drive is not damaged by abuse. The second is to perform the first in a manor that does not degrade the performance, as long the drive temperature and current ratings are not exceeded.

The purpose of is to protect the power structure from abuse. Any protection for the motor and associated wiring is provided by a Motor Thermal Overload feature.

The drive will monitor the temperature of the power module based on a measured temperature and a thermal model of the IGBT. As the temperature rises the drive may lower the PWM frequency to decrease the switching losses in the IGBT. If the temperature continues to rise, the drive may reduce current limit to try to decrease the load on the drive. If the drive temperature becomes critical the drive will generate a fault.

If the drive is operated in a low ambient condition the drive may exceed rated levels of current before the monitored temperature becomes critical. To guard against this situation the drive thermal overload also includes an inverse time algorithm. When this scheme detects operation beyond rated levels, current limit may be reduced or a fault may be generated.

Operation

The drive thermal overload has two separate protection schemes, an overall RMS protection based on current over time, and an IGBT junction thermal manager based on measured power module temperature and operating conditions. The drive may fold back current limit when either of these methods detects a problem.

Overall RMS Protection

The overall RMS protection makes sure the current ratings of the drive are not exceeded. The lower curve in Figure 2.18 shows the boundary of normal-duty operation. In normal duty, the drive is rated to produce 110% of rated current for 60 seconds, 150% of rated current for three seconds, and 165% of rated current for 100 milliseconds. The maximum value for current limit is 150% so the limit of 165% for 100 milliseconds should never be crossed. If the load on the drive exceeds the level of current as shown on the upper curve, current limit may fold back to 100% of the drive rating until the 10/90 or 5/95 duty cycle has been achieved. For example, 60 seconds at 110% will be followed by 9 minutes at 100%, and 3 seconds at 150% will be followed by 57 seconds at 100%. With the threshold for where to take action slightly above the rated level the drive will only fold back when drive ratings are exceeded.

If fold back of current limit is not enabled in [Drive OL Mode], the drive will generate a fault when operation exceeds the rated levels. This fault can not be disabled. If current limit fold back is enabled then a fault is generated when current limit is reduced.

Figure 2.18 Normal Duty Boundary of Operation



The lower curve in Figure 2.19 shows the boundary of heavy duty operation. In heavy duty, the drive is rated to produce 150% of rated current for 60 seconds, 200% for three seconds, and 220% for 100 milliseconds. The maximum value for current limit is 200% so the limit of 220% for 100 milliseconds should never be crossed. If the load on the drive exceeds the level of current as shown on the upper curve, current limit may fold back to 100% of the drive rating until the 10/90 or 5/95 duty cycle has been achieved. For example, 60 seconds at 150% will be followed by 9 minutes at 100%, and 3 seconds at 200% will be followed by 57 seconds at 100%. With the threshold for where to take action slightly above the rated level the drive will only fold back when drive ratings are exceeded.

Again, if fold back of current limit is not enabled in the [Drive OL Mode], the drive will generate a fault when operation exceeds the rated levels. This fault can not be disabled. If current limit fold back is enabled then a fault is generated when current limit is reduced.

Figure 2.19 Heavy Duty Boundary of Operation



Thermal Manager Protection

The thermal manager protection assures that the thermal ratings of the power module are not exceeded. The operation of the thermal manager can be thought of as a function block with the inputs and outputs as shown below.

Figure 2.20 Thermal Manager Inputs/Outputs



The following is a generalization of the calculations done by the thermal manager. The IGBT junction temperature T_J is calculated based on the measured drive temperature T_{Drive}, and a temperature rise that is a function of operating conditions. When the calculated junction temperature reaches a maximum limit the drive will generate a fault. This fault can not be disabled. This maximum junction temperature is stored in EE on the power board along with other information to define the operation of the drive thermal overload function. These values are not user adjustable. In addition to the maximum junction temperature there are thresholds that select the point at which the PWM frequency begins to fold back, and the point at which current limit begins to fold back. As T_J increases the thermal manager may reduce the PWM frequency. If T_J continues to rise current limit may be reduced, and if T_J continues to rise the drive generates a fault. The calculation of the reduced PWM frequency and current limit is implemented with an integral control.

PWM Frequency

PWM Frequency as selected by the user can be reduced by the thermal manager. The resulting Active PWM Frequency may be displayed in a test point parameter.

The active PWM frequency will change in steps of 2 kHz. It will always be less than or equal to the value selected by the user, and will not be less than the drives minimum PWM frequency. When drive temperature reaches the level where PWM frequency would be limited, the *Drv OL Lvl 1* Alarm is turned on. This alarm will be annunciated even if the reduced PWM frequency is not enabled.

Current Limit

Current Limit as selected by the user can be reduced by the thermal manager. The resulting active current limit may be displayed as a test point parameter.

The active current limit will always be less than or equal to the value selected by the user, and will not be less than flux current. When drive temperature reaches the level where current limit would be clamped, the *Drv OL Lvl 2* Alarm is turned on. This alarm will be annunciated even if reduced current limit is not enabled.

The active current limit is used during normal operation and during DC injection braking. Any level of current requested for DC injection braking is limited by the Active Current Limit.

Configuration

The [Drive OL Mode] allows the user to select the action(s) to perform with increased current or drive temperature. When this parameter is “Disabled,” the drive will not modify the PWM frequency or current limit. When set to “Reduce PWM” the drive will only modify the PWM frequency. “Reduce CLim” will only modify the current limit. Setting this parameter to “Both-PWM 1st” the drive will modify the PWM frequency and the current limit.

DTO Fault

For all possible settings of [Drive OL Mode], the drive will always monitor the T_j and T_{Drive} and generate a fault when either temperature becomes critical. If T_{Drive} is less than –20° C, a fault is generated. With these provisions, a DTO fault is generated if the NTC ever malfunctions.

Temperature Display

The Drive’s temperature is measured (NTC in the IGBT module) and displayed as a percentage of drive thermal capacity in [Drive Temp]. This parameter is normalized to the thermal capacity of the drive (frame dependent) and displays thermal usage in % of maximum (100% = drive Trip). A test point, “Heatsink temperature” is available to read temperature directly in degrees C, but cannot be related to the trip point since “maximums” are only given in %. The IGBT temperature shown in Figure 2.20 is used only for internal development and is not provided to the user.

Low Speed Operation

When operation is below 4 Hz, the duty cycle is such that a given IGBT will carry more of the load for a while and more heat will build up in that device. The thermal manager will increase the calculated IGBT temperature at low output frequencies and will cause corrective action to take place sooner.

When the drive is in current limit the output frequency is reduced to try to reduce the load. This works fine for a variable torque load, but for a constant torque load reducing the output frequency does not lower the current (load). Lowering current limit on a CT load will push the drive down to a region where the thermal issue becomes worse. In this situation the thermal manager will increase the calculated losses in the power module to track the worst case IGBT. For example, if the thermal manager normally provides 150% for 3 seconds at high speeds, it may only provide 150% for one second before generating a fault at low speeds.

If operating at 60Hz 120%, lowering the current limit may cause a fault sooner than allowing the drive to continue to operate. In this case the user may want to disable current limit fold back.

Drive Ratings (kW, Amps, Volts)

Refer to Fuses and Circuit Breakers on page 2-100.

Droop

Vector Droop is used to “shed” load and is usually used when a soft coupling of two motors is present in an application. The master drive speed regulates and the follower uses droop so it does not “fight” the master. The input to the droop block is the commanded motor torque. The output of the droop block reduces the speed reference. [Droop RPM @ FLA] sets the amount of speed, in RPM, that the speed reference is reduced when at full load torque. For example, when [Droop RPM @ FLA] is set to 50 RPM and the drive is running at 100% rated motor torque, the droop block would subtract 50 RPM from the speed reference.

Economizer (Auto-Economizer)

Refer to Torque Performance Modes on page 2-205.

Economizer mode consists of the sensorless vector control with an additional energy savings function.

When steady state speed is achieved, the economizer becomes active and automatically adjusts the drive output voltage based on applied load. By matching output voltage to applied load, the motor efficiency is optimized. Reduced load commands a reduction in motor flux current. The flux current is reduced as long as the total drive output current does not exceed 75% of motor rated current as programmed in [Motor NP FLA], parameter 42. The flux current is not allowed to be less than 50% of the motor flux current as programmed in [Flux Current Ref], parameter 63. During acceleration and deceleration, the economizer is inactive and sensorless vector motor control performs normally.



Efficiency

The following chart shows typical efficiency for PWM variable frequency drives, regardless of size. Drives are most efficient at full load and full speed.



Fan Curve

When torque performance (see page 2-205) is set to Fan/Pump, the relationship between frequency and voltage is shown in the following figure. The fan/pump curve generates voltage that is a function of the stator frequency squared up to the motor nameplate frequency. Above base frequency voltage is a linear function of frequency. At low speed the fan curve can be offset by the run boost parameter to provide extra starting torque if needed. No extra parameters are needed for fan/pump curve.

The pattern matches the speed vs. load characteristics of a centrifugal fan or pump and optimizes the drive output to those characteristics.



Fan

See Fan Curve above.

Faults

Faults are events or conditions occurring within and/or outside of the drive. Theses events or conditions are (by default) considered to be of such significant magnitude that drive operation should or must be discontinued. Faults are annunciated to the user via the HIM, communications and/or contact outputs. The condition that caused the fault determines the user response.

Once a fault occurs, the fault condition is latched, requiring the user or application to perform a fault reset action to clear the latched condition. If the condition that caused fault still exists when the fault is reset, the drive will fault again and the fault will be latched again.

When a Fault Occurs

1. The drive is set as faulted, causing the drive output to be immediately disabled and a “coast to stop” sequence to occur
2. The fault code is entered into the first buffer of the fault queue (see “Fault Queue” below for rules).
3. Additional data on the status of the drive at the time that the fault occurred is recorded. Note that there is only a single copy of this information which is always related to the most recent fault queue entry [Fault 1 Code], parameter 243. When another fault occurs, this data is overwritten with the new fault data. The following data/conditions are captured and latched into non-volatile drive memory:
   - [Status 1 @ Fault] - drive condition at the time of the fault.
   - [Status 2 @ Fault] - drive condition at the time of the fault.
   - [Alarm 1 @ Fault], - alarm condition at the time of the fault.
   - [Alarm 2 @ Fault] - alarm conditions at the time of the fault.
   - Fault Motor Amps - motor amps at time of fault.
   - [Fault Bus Volts] - unfiltered DC Bus volts at time of fault..
   - [Fault Frequency] (Standard Control).
   - [Fault Speed] (Vector Control) - drive output frequency (or speed) at time of fault.

Fault Queue

Faults are also logged into a fault queue such that a history of the most recent fault events is retained. Each recorded event includes a fault code (with associated text) and a fault “time of occurrence.” The PowerFlex 70 drive has a four event queue and the PowerFlex 700 has an eight event queue.

A fault queue will record the occurrence of each fault event that occurs while no other fault is latched. Each fault queue entry will include a fault code and a time stamp value. A new fault event will not be logged to the fault queue if a previous fault has already occurred, but has not yet been reset. Only faults that actually trip the drive will be logged. No fault that occurs while the drive is already faulted will be logged.

The fault queue will be a first-in, first-out (FIFO) queue. Fault queue entry #1 will always be the most-recent entry (newest). Entry 4 (8) will always be the oldest. As a new fault is logged, each existing entry will be shifted up by one (i.e. previous entry #1 will move to entry #2, previous entry #2 will move to entry #3, etc.). If the queue is full when a fault occurs, the oldest entry will be discarded.

The fault queue will be saved in nonvolatile storage at power loss, thus retaining its contents through a power off - on cycle.

Fault Code/Text [Fault Code 1-x]

The fault code for each entry can be read in its respective read-only parameter. When viewed with a HIM, only the fault code is displayed. If viewed via a DPI peripheral (communications network), the queue is not accessed through parameters, and a text string of up to 16 characters is also available.

Fault Time [Fault 1-8 Time]

PowerFlex drives have an internal drive-under-power-timer. The user has no control over the value of this timer, which will increment in value over the life of the drive and saved in nonvolatile storage. Each time the drive is powered down and then repowered, the value of this timer is written to [Power Up Marker], parameter 242.

The time is presented in xxx.yyyy hours (4 decimal places). Each increment of 1 represents approximately 0.36 seconds. Internally it will be accumulated in a 32-bit unsigned integer with a resolution of 0.35 seconds, resulting in a rollover to zero every 47.66 years.

The time stamp value recorded in the fault queue at the time of a fault is the value of internal drive under power timer. By comparing this value to the [PowerUp Marker], it is possible to determine when the fault occurred relative to the last drive power-up.

The time stamp for each fault queue entry can be read via the corresponding parameter. Time comparisons of one fault to the next and/or with [PowerUp Marker] are only meaningful if they occur less than or equal to the rollover range.

Resetting or Clearing a Fault

A latched fault condition can be cleared by the following:

1. An off to on transition on a digital input configured for fault reset or stop/reset.
2. Setting [Fault Clear] to "1."
3. A DPI peripheral (several ways).
4. Performing a reset to factory defaults via parameter write.
5. Cycling power to the drive such that the control board goes through a power-up sequence.

Resetting faults will clear the faulted status indication. If any fault condition still exists, the fault will relatch and another entry made in the fault queue.

Clearing the Fault Queue

Performing a fault reset does not clear the fault queue. Clearing the fault queue is a separate action.

Fault Configuration

The drive can be configured such that some fault conditions do not trip the drive. Configurable faults include those that are user inputs.

[Fault Config 1] is a bit-mapped 16 bit word enabling or disabling certain fault conditions (see below). Disabling a fault removes the effect of the fault condition and makes the event unknown to the user. If the bit is on, the fault is enabled. If the bit is off, the fault is not enabled.


Out PhaseLoss *
ShearPNo Acc *
Load Loss *
In PhaseLoss *
Motor Therm *
Decel Inhibt
AuthstTries
Shear Pin
Motor OverLd
UnderVoltage
Power Loss
x x x 0 0 x 0 0 0 1 0 0 1 x 1 0
15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0
1 = Enabled
0 = Disabled
x = Reserved
Bit #
* Vector firmware 3.001 & later
Factory Default Bit Values

Power Up Marker

Copy of factory "drive under power" timer at the last power-up of the drive. Used to provide relevance of Fault 'n' Time values with respect to the last power-up of the drive.

This value will rollover to 0 after the drive has been powered on for more than the hours shown in the Range field (approximately 47.667 years).

Flux Braking

Vector You can use flux braking to stop the drive or to shorten the deceleration time to a lower speed. Other methods of deceleration or stopping may perform better depending on the motor and the load.

To enable flux braking:

1. [Bus Reg Mode A, B] must be set to "1" Adjust Freq to enable the bus regulator.
2. [Flux Braking] must be set to 1 "Enabled".

When enabled, flux braking automatically increases the motor flux resulting in an increase of motor losses. The flux current is only increased when the bus voltage regulator is active. When the bus voltage regulator is not active, the flux current is returned to normal. The maximum flux current is equal to rated motor current but may be further reduced depending on the load level, IT protection, or current limits. In general, the flux current is not increased when the motor is at or above rated speed. At higher speeds, field weakening is active and the motor flux current cannot be increased. As the speed decreases below base speed, the flux current increases until there is enough voltage margin to run rated motor current.

Because flux braking increases motor losses, the duty cycle used with this method must be limited. Check with the motor vendor for flux braking or DC braking application guidelines. You may also want to consider using external motor thermal protection.

Flux Up

[Flux Up Mode]
AC induction motors require flux to be established before controlled torque can be developed. To build flux in these motors, voltage is applied to them. PowerFlex drives have two methods to flux the motor.

The first method is a normal start. During a normal start, flux is established as the output voltage and frequency are applied to the motor. While the flux is being built, the unpredictable nature of the developed torque may cause the rotor to oscillate even though acceleration of the load may occur. In the motor, the acceleration profile may not follow the commanded acceleration profile due to the lack of developed torque.

Figure 2.21 Accel Profile during Normal Start - No Flux Up



The second method is Flux Up Mode. In this mode, DC current is applied to the motor at a level equal to the lesser of the current limit setting, drive rated current, and drive DC current rating. The flux up time period is based on the level of flux up current and the rotor time constant of the motor.

The flux up current is not user adjustable.

Figure 2.22 Flux Up Current versus Flux Up Time



[Flux Up Time]

Once rated flux is reached in the motor, normal operation begins and the desired acceleration profile is achieved.

Rated Flux Reached



Flying Start

The Flying Start feature is used to start into a rotating motor, as quick as possible, and resume normal operation with a minimal impact on load or speed.

When a drive is started in its normal mode it initially applies a frequency of 0 Hz and ramps to the desired frequency. If the drive is started in this mode with the motor already spinning, large currents will be generated. An overcurrent trip may result if the current limiter cannot react quickly enough. The likelihood of an overcurrent trip is further increased if there is a residual flux (back emf) on the spinning motor when the drive starts. Even if the current limiter is fast enough to prevent an overcurrent trip, it will take an unacceptable amount of time for synchronization to occur and for the motor to reach its desired frequency. In addition, larger mechanical stress is placed on the application, increasing downtime and repair costs while decreasing productivity.

In Flying Start mode, the drive's response to a start command will be to identify the motor's speed and apply a voltage that is synchronized in frequency, amplitude and phase to the back emf of the spinning motor. The motor will then accelerate to the desired frequency. This process will prevent an overcurrent trip and significantly reduce the time for the motor to reach its desired frequency. Since the motor is "picked up "smoothly at its rotating speed and ramped to the proper speed, little or no mechanical stress is present.

Configuration

Flying Start is activated by setting the [Flying Start En] parameter to "Enable"

		169	**[Flying Start En]** Enables/disables the function which reconnects to a spinning motor at actual RPM when a start command is issued.	Default: Options:	0 0 1	"Disabled" "Disabled" "Enabled"	170

The gain can be adjusted to increase responsiveness. Increasing the value in [Flying StartGain] increases the responsiveness of the Flaying Start Feature

	Restart Modes	170	**[Flying StartGain]** Sets the response of the flying start function.	Default: Min/Max: Display:	4000 20/32767 1		169

Application Example

In some applications, such as large fans, wind or drafts may rotate the fan in the reverse direction when the drive is stopped. If the drive were started in the normal manner, its output would begin at zero Hz, acting as a brake to bring the reverse rotating fan to a stop and then accelerating it in the correct direction.

This operation can be very hard on the mechanics of the system including fans, belts and other coupling devices.

Cooling Tower Fans

Draft/wind blows idle fans in reverse direction. Restart at zero damages fans, breaks belts. Flying start alleviates the problem



Fuses and Circuit Breakers

Tables 2.M through 2.W provide drive ratings (including continuous, 1 minute and 3 second) and recommended AC line input fuse and circuit breaker information. Both types of short circuit protection are acceptable for UL and IEC requirements. Sizes listed are the recommended sizes based on 40 degree C and the U.S. N.E.C. Other country, state or local codes may require different ratings.

Fusing

If fuses are chosen as the desired protection method, refer to the recommended types listed below. If available amp ratings do not match the tables provided, the closest fuse rating that exceeds the drive rating should be chosen.

- IEC – BS88 (British Standard) Parts 1 & 2(1), EN60269-1, Parts 1 & 2, type gG or equivalent should be used.
- UL – UL Class CC, T, RK1 or J must be used.

Circuit Breakers

The “non-fuse” listings in the following tables include both circuit breakers (inverse time or instantaneous trip) and 140M Self-Protecting Motor Starters. **If one of these is chosen as the desired protection method**, the following requirements apply.

- IEC and UL – Both types of devices are acceptable for IEC and UL installations.

(1) Typical designations include, but may not be limited to the following; Parts 1 & 2: AC, AD, BC, BD, CD, DD, ED, EFS, EF, FF, FG, GF, GG, GH.

Table 2.M PF70 208/240 Volt AC Input Recommended Protection Devices

Drive Catalog Number	Frame[1]	HP Rating		Input Ratings		Output Amps			Dual Element Time Delay Fuse		Non-Time Delay Fuse		Circuit Breaker[4]	Motor Circuit Protector[6]	140M Motor Starter with Adjustable Current Range[7][8]			
		ND	HD	Amps	kVA	Cont.	1 Min.	3 Sec.	Min.[2]	Max.[3]	Min.[2]	Max.[3]	Max.[5]	Max.[5]	Available Catalog Numbers[9]			
208 Volt AC Input																		
20AB2P2	A	0.5	0.33	2.9	1.1	2.5	2.7	3.7	6	6	6	10	15	7	140M-C2E-B40	140M-D8E-B40	–	–
20AB4P2	A	1	0.75	5.6	2	4.8	5.5	7.4	10	10	10	17.5	15	7	140M-C2E-B63	140M-D8E-B63	–	–
20AB6P8	B	2	1.5	10	3.6	7.8	10.3	13.8	15	15	15	30	30	15	140M-C2E-C10	140M-D8E-C10	140M-F8E-C10	–
20AB9P6	B	3	2	14	5.1	11	12.1	16.5	20	25	20	40	40	30	140M-C2E-C16	140M-D8E-C16	140M-F8E-C16	–
20AB015	C	5	3	16	5.8	17.5	19.2	26.6	20	35	20	70	70	30	140M-C2E-C20	140M-D8E-C20	140M-F8E-C20	–
20AB022	D	7.5	5	23.3	8.3	25.3	27.8	37.9	30	50	30	100	100	30	140M-C2E-C25	140M-D8E-C25	140M-F8E-C25	140-CMN-2500
20AB028	D	10	7.5	29.8	10.7	32.2	37.9	50.6	40	70	40	125	125	50	–	–	140M-F8E-C32	140-CMN-4000
240 Volt AC Input																		
20AB2P2	A	0.5	0.33	2.5	1.1	2.2	2.4	3.3	3	4.5	3	8	15	3	140M-C2E-B25	140M-D8E-B25	–	–
20AB4P2	A	1	0.75	4.8	2	4.2	4.8	6.4	6	9	6	15	15	7	140M-C2E-B63	140M-D8E-B63	–	–
20AB6P8	B	2	1.5	8.7	3.6	6.8	9	12	15	15	15	25	25	15	140M-C2E-C10	140M-D8E-C10	140M-F8E-C10	–
20AB9P6	B	3	2	12.2	5.1	9.6	10.6	14.4	20	20	20	35	35	15	140M-C2E-C16	140M-D8E-C16	140M-F8E-C16	–
20AB015	C	5	3	13.9	5.8	15.3	17.4	23.2	20	30	20	60	60	30	140M-C2E-C16	140M-D8E-C16	140M-F8E-C16	–
20AB022	D	7.5	5	19.9	8.3	22	24.4	33	25	45	25	80	80	30	140M-C2E-C20	140M-D8E-C20	140M-F8E-C20	–
20AB028	D	10	7.5	25.7	10.7	28	33	44	35	60	35	110	110	50	–	–	140M-F8E-C32	140-CMN-4000

Table 2.N PF70 400/480 Volt AC Input Recommended Protection Devices

Drive Catalog Number	Frame[1]	kW (400V) HP (480V) Rating		Input Ratings		Output Amps			Dual Element Time Delay Fuse		Non-Time Delay Fuse		Circuit Breaker[4]	Motor Circuit Protector[6]	140M Motor Starter with Adjustable Current Range[7][8]			
		ND	HD	Amps	kVA	Cont.	1 Min.	3 Sec.	Min.[2]	Max.[3]	Min.[2]	Max.[3]	Max.[5]	Max.[5]	Available Catalog Numbers[9]			
400 Volt AC Input																		
20AC1P3	A	0.37	0.25	1.6	1.1	1.3	1.4	1.9	3	3	3	5	15	3	140M-C2E-B16	–	–	–
20AC2P1	A	0.75	0.55	2.5	1.8	2.1	2.4	3.2	4	6	4	8	15	7	140M-C2E-B25	140M-D8E-B25	–	–
20AC3P5	A	1.5	1.1	4.3	3	3.5	4.5	6	6	6	6	12	15	7	140M-C2E-B40	140M-D8E-B40	–	–
20AC5P0	B	2.2	1.5	6.5	4.5	5	5.5	7.5	10	10	10	20	20	15	140M-C2E-C10	140M-D8E-C10	140M-F8E-C10	–
20AC8P7	B	4	3	11.3	7.8	8.7	9.9	13.2	15	17.5	15	30	30	15	140M-C2E-C16	140M-D8E-C16	140M-F8E-C16	–
20AC011	C	5.5	4	11	7.6	11.5	13	17.4	15	25	15	45	40	15	140M-C2E-C16	140M-D8E-C16	140M-F8E-C16	–
20AC015	C	7.5	5.5	15.1	10.4	15.4	17.2	23.1	20	30	20	60	60	20	140M-C2E-C16	140M-D8E-C16	140M-F8E-C16	–
20AC022	D	11	7.5	21.9	15.2	22	24.2	33	30	45	30	80	80	30	140M-C2E-C25	140M-D8E-C25	140M-F8E-C25	140-CMN-2500
20AC030	D	15	11	30.3	21	30	33	45	40	60	40	120	120	50	–	–	140M-F8E-C32	140-CMN-4000
20AC037	D	18.5	15	35	24.3	37	45	60	45	80	45	125	125	50	–	–	140M-F8E-C45	–
20AC043	D	22	18.5	40.7	28.2	43	56	74	60	90	60	150	150	60	–	–	–	–
480 Volt AC Input																		
20AD1P1	A	0.5	0.33	1.3	1.1	1.1	1.2	1.6	3	3	3	4	15	3	140M-C2E-B16	–	–	–
20AD2P1	A	1	0.75	2.4	2	2.1	2.4	3.2	3	6	3	8	15	3	140M-C2E-B25	140M-D8E-B25	–	–
20AD3P4	A	2	1.5	3.8	3.2	3.4	4.5	6	6	6	6	12	15	7	140M-C2E-B40	140M-D8E-B40	–	–
20AD5P0	B	3	2	5.6	4.7	5	5.5	7.5	10	10	10	20	20	15	140M-C2E-C63	140M-D8E-B63	–	–
20AD8P0	B	5	3	9.8	8.4	8	8.8	12	15	15	15	30	30	15	140M-C2E-C10	140M-D8E-C10	140M-F8E-C10	–
20AD011	C	7.5	5	9.5	7.9	11	12.1	16.5	15	20	15	40	40	15	140M-C2E-C16	140M-D8E-C16	140M-F8E-C16	–
20AD014	C	10	7.5	12.5	10.4	14	16.5	22	20	30	20	50	50	20	140M-C2E-C16	140M-D8E-C16	140M-F8E-C16	–
20AD022	D	15	10	19.9	16.6	22	24.2	33	25	45	25	80	80	30	140M-C2E-C20	140M-D8E-C20	140M-F8E-C20	–
20AD027	D	20	15	24.8	20.6	27	33	44	35	60	35	100	100	50	–	–	140M-F8E-C25	140-CMN-2500
20AD034	D	25	20	34	25.9	34	40.5	54	40	70	40	125	125	50	–	–	140M-F8E-C45	140-CMN-4000
20AD040	D	30	25	40	39.7	40	51	68	50	90	50	150	150	50	–	–	140M-F8E-C45	140-CMN-4000

See page 2-102 for Notes.

Table 2.O PF70 600 Volt AC Input Recommended Protection Devices

Drive Catalog Number	Frame[1]	HP Rating		Input Ratings		Output Amps			Dual Element Time Delay Fuse		Non-Time Delay Fuse		Circuit Breaker[4]	Motor Circuit Protector[6]	140M Motor Starter with Adjustable Current Range[7][8]			
		ND	*HD*	*Amps*	*kVA*	*Cont.*	*1 Min.*	*3 Sec.*	*Min.[2]*	*Max.[3]*	*Min.[2]*	*Max.[3]*	*Max.[5]*	*Max.[5]*	*Available Catalog Numbers[9]*			
600 Volt AC Input																		
20AE0P9	A	0.5	0.33	1.3	1.3	0.9	1.1	1.4	3	3	3	3.5	15	3	140M-C2E-B16	–	–	–
20AE1P7	A	1	0.75	1.9	2	1.7	2	2.6	3	6	3	6	15	3	140M-C2E-B25	140M-D8E-B25	–	–
20AE2P7	A	2	1.5	3	3.1	2.7	3.6	4.8	4	6	4	10	15	7	140M-C2E-B40	140M-D8E-B40	–	–
20AE3P9	B	3	2	4.4	4.5	3.9	4.3	5.9	6	8	6	15	15	7	140M-C2E-C63	140M-D8E-B63	–	–
20AE6P1	B	5	3	7.5	7.8	6.1	6.7	9.2	10	12	10	20	20	15	140M-C2E-C10	140M-D8E-C10	140M-F8E-C10	–
20AE9P0	C	7.5	5	7.7	8	9	9.9	13.5	10	20	10	35	35	15	140M-C2E-C10	140M-D8E-C10	140M-F8E-C10	–
20AE011	C	10	7.5	9.8	10.1	11	13.5	18	15	20	15	40	40	15	140M-C2E-C16	140M-D8E-C16	140M-F8E-C16	–
20AE017	D	15	10	15.3	15.9	17	18.7	25.5	20	35	20	60	60	30	140M-C2E-C20	140M-D8E-C20	140M-F8E-C20	–
20AE022	D	20	15	20	20.8	22	25.5	34	25	45	25	80	80	30	140M-C2E-C25	140M-D8E-C25	140M-F8E-C25	140-CMN-2500

(1) For IP 66 (NEMA Type 4X/12) enclosures, drives listed as Frame A increase to Frame B and drives listed as Frame C increase to Frame D.
(2) Minimum protection device size is the lowest rated device that supplies maximum protection without nuisance tripping.
(3) Maximum protection device size is the highest rated device that supplies drive protection. For US NEC, minimum size is 125% of motor FLA. Ratings shown are maximum.
(4) Circuit Breaker - inverse time breaker. For US NEC, minimum size is 125% of motor FLA. Ratings shown are maximum.
(5) Maximum allowable rating by US NEC. Exact size must be chosen for each installation.
(6) Motor Circuit Protector - instantaneous trip circuit breaker. For US NEC, minimum size is 125% of motor FLA. Ratings shown are maximum.
(7) Bulletin 140M with adjustable current range should have the current trip set to the minimum range that the device will not trip.
(8) Manual Self-Protected (Type E) Combination Motor Controller, UL listed for 208 Wye or Delta, 240 Wye or Delta, 480Y/277 or 600Y/347. Not UL listed for use on 480V or 600V Delta/Delta systems.
(9) The AIC ratings of the Bulletin 140M Motor Protector may vary. See publication 140M-SG001B-EN-P.

Table 2.P PF700 208 Volt AC Input Protection Devices

Drive Catalog Number	Frame	HP Rating		PWM Freq.	Temp.	Input Ratings		Output Amps			Dual Element Time Delay Fuse		Non-Time Delay Fuse		Circuit Breaker (3)	Motor Circuit Protector (4)	140M Motor Starter with Adjustable Current Range (5)(6)			
		ND	HD	kHz	°C	Amps	kVA	Cont.	1 Min.	3 Sec.	Min. (1)	Max. (2)	Min. (1)	Max. (2)	Max. (8)	Max. (8)	Available Catalog Numbers - 140 . . . (7)			
208 Volt AC Input																				
20BB2P2	0	0.5	0.33	4	50	1.9	0.7	2.5	2.8	3.8	3	6	3	10	15	3	M-C2E-B25	M-D8E-B25	–	–
20BB4P2	0	1	0.75	4	50	3.7	1.3	4.8	5.6	7.0	6	10	6	17.5	15	7	M-C2E-B63	M-D8E-B63	–	–
20BB6P8	1	2	1.5	4	50	6.8	2.4	7.8	10.4	13.8	10	15	10	30	30	15	M-C2E-C10	M-D8E-C10	M-F8E-C10	–
20BB9P6	1	3	2	4	50	9.5	3.4	11	12.1	17	12	20	12	40	40	15	M-C2E-C16	M-D8E-C16	M-F8E-C16	–
20BB015	1	5	3	4	50	15.7	5.7	17.5	19.3	26.3	20	35	20	70	70	30	M-C2E-C20	M-D8E-C20	M-F8E-C20	–
20BB022	1	7.5	5	4	50	23.0	8.3	25.3	27.8	38	30	50	30	100	100	30	M-C2E-C25	M-D8E-C25	M-F8E-C25	-CMN-2500
20BB028	2	10	7.5	4	50	29.6	10.7	32.2	38	50.6	40	70	40	125	125	50	–	–	M-F8E-C32	-CMN-4000
20BB042	3	15	10	4	50	44.5	16.0	48.3	53.1	72.5	60	100	60	175	175	70	–	–	M-F8E-C45	-CMN-6300
20BB052	3	20	15	4	50	51.5	17.1	56	64	86	80	125	80	200	200	100	–	–	–	-CMN-6300
20BB070	4	25	20	4	50	72	25.9	78.2	93	124	90	175	90	300	300	100	–	–	–	-CMN-9000
20BB080	4	30	25	4	50	84.7	30.5	92	117	156	110	200	110	350	350	150	–	–	–	-CMN-9000
20BB104	5	40	–	4	50	113	40.7	120	132	175	150	250	150	475	350	150	–	–	–	–
		–	30	4	50	84.7	30.5	92	138	175	125	200	125	350	300	150	–	–	–	-CMN-9000
20BB130	5	50	–	4	50	122	44.1	130	143	175	175	275	175	500	375	250	–	–	–	–
		–	40	4	50	98	35.3	104	156	175	125	225	125	400	300	150	–	–	–	–
20BB154	6	60	–	4	50	167	60.1	177	195	266	225	350	225	500	500	250	–	–	–	–
		–	50	4	50	141	50.9	150	225	300	200	300	200	500	450	250	–	–	–	–
20BB192	6	75	–	4	50	208	75.0	221	243	308	300	450	300	600	600	400	–	–	–	–
		–	60	4	50	167	60.1	177	266	308	225	350	225	500	500	250	–	–	–	–

Table 2.Q PF700 240 Volt AC Input Protection Devices

Drive Catalog Number	Frame	HP Rating		PWM Freq.	Temp.	Input Ratings		Output Amps			Dual Element Time Delay Fuse		Non-Time Delay Fuse		Circuit Breaker (3)	Motor Circuit Protector (4)	140M Motor Starter with Adjustable Current Range (5)(6)			
		ND	HD	kHz	°C	Amps	kVA	Cont.	1 Min.	3 Sec.	Min. (1)	Max. (2)	Min. (1)	Max. (2)	Max. (8)	Max. (8)	Available Catalog Numbers - 140 . . . (7)			
240 Volt AC Input																				
20BB2P2	0	0.5	0.33	4	50	1.7	0.7	2.2	2.4	3.3	3	6	3	10	15	3	M-C2E-B25	M-D8E-B25	–	–
20BB4P2	0	1	0.75	4	50	3.3	1.4	4.2	4.8	6.4	5	8	5	15	15	7	M-C2E-B63	M-D8E-B63	–	–
20BB6P8	1	2	1.5	4	50	5.9	2.4	6.8	9	12	10	15	10	25	25	15	M-C2E-C10	M-D8E-C10	M-F8E-C10	–
20BB9P6	1	3	2	4	50	8.3	3.4	9.6	10.6	14.4	12	20	12	35	35	15	M-C2E-C10	M-D8E-C10	M-F8E-C10	–
20BB015	1	5	3	4	50	13.7	5.7	15.3	16.8	23	20	30	20	60	60	30	M-C2E-C16	M-D8E-C16	M-F8E-C16	–
20BB022	1	7.5	5	4	50	19.9	8.3	22	24.2	33	25	50	25	80	80	30	M-C2E-C25	M-D8E-C25	M-F8E-C25	-CMN-2500
20BB028	2	10	7.5	4	50	25.7	10.7	28	33	44	35	60	35	100	100	50	–	–	M-F8E-C32	-CMN-4000
20BB042	3	15	10	4	50	38.5	16.0	42	46.2	63	50	90	50	150	150	50	–	–	M-F8E-C45	-CMN-6300
20BB052	3	20	15	4	50	47.7	19.8	52	63	80	60	100	60	200	200	100	–	–	–	-CMN-6300
20BB070	4	25	20	4	50	64.2	26.7	70	78	105	90	150	90	275	275	100	–	–	–	-CMN-9000
20BB080	4	30	25	4	50	73.2	30.5	80	105	140	100	180	100	300	300	100	–	–	–	-CMN-9000
20BB104	5	40	–	4	50	98	40.6	104	115	175	125	225	125	400	300	150	–	–	–	–
		–	30	4	50	73	30.5	80	120	160	100	175	100	300	300	100	–	–	–	-CMN-9000
20BB130	5	50	–	4	50	122	50.7	130	143	175	175	275	175	500	375	250	–	–	–	–
		–	40	4	50	98	40.6	104	156	175	125	225	125	400	300	150	–	–	–	–
20BB154	6	60	–	4	50	145	60.1	154	169	231	200	300	200	600	450	250	–	–	–	–
		–	50	4	50	122	50.7	130	195	260	175	275	175	500	375	250	–	–	–	–
20BB192	6	75	–	4	50	180	74.9	192	211	288	225	400	225	600	575	250	–	–	–	–
		–	60	4	50	145	60.1	154	231	308	200	300	200	600	450	250	–	–	–	–

See page 2-105 for Notes.

Table 2.R PF700 400 Volt AC Input Protection Devices

Drive Catalog Number	Frame	kW Rating		PWM Freq.	Temp.	Input Ratings		Output Amps			Dual Element Time Delay Fuse		Non-Time Delay Fuse		Circuit Breaker (3)	Motor Circuit Protector (4)	140M Motor Starter with Adjustable Current Range (5)(6)			
		ND	HD	kHz	°C	Amps	kVA	Cont.	1 Min.	3 Sec.	Min. (1)	Max. (2)	Min. (1)	Max. (2)	Max. (8)	Max. (8)	Available Catalog Numbers - 140 . . . (7)			
400 Volt AC Input																				
20BC1P3	0	0.37	0.25	4	50	1.1	0.77	1.3	1.4	1.9	3	3	3	6	15	3	M-C2E-B16	–	–	–
20BC2P1	0	0.75	0.55	4	50	1.8	1.3	2.1	2.4	3.2	3	6	3	8	15	3	M-C2E-B25	M-D8E-B25	–	–
20BC3P5	0	1.5	0.75	4	50	3.2	2.2	3.5	4.5	6.0	6	7	6	12	15	7	M-C2E-B40	M-D8E-B40	–	–
20BC5P0	0	2.2	1.5	4	50	4.6	3.2	5.0	5.5	7.5	6	10	6	20	20	7	M-C2E-B63	M-D8E-B63	–	–
20BC8P7	0	4	2.2	4	50	7.9	5.5	8.7	9.9	13.2	15	17.5	15	30	30	15	M-C2E-C10	M-D8E-C10	M-F8E-C10	–
20BC011	0	5.5	4	4	50	10.8	7.5	11.5	13	17.4	15	25	15	45	45	15	M-C2E-C16	M-D8E-C16	M-F8E-C16	–
20BC015	1	7.5	5.5	4	50	14.4	10.0	15.4	17.2	23.1	20	30	20	60	60	20	M-C2E-C20	M-D8E-C20	M-F8E-C20	–
20BC022	1	11	7.5	4	50	20.6	14.3	22	24.2	33	30	45	30	80	80	30	M-C2E-C25	M-D8E-C25	M-F8E-C25	–
20BC030	2	15	11	4	50	28.4	19.7	30	33	45	35	60	35	120	120	50	–	–	M-F8E-C32	–
20BC037	2	18.5	15	4	50	35.0	24.3	37	45	60	45	80	45	125	125	50	–	–	M-F8E-C45	–
20BC043	3	22	18.5	4	50	40.7	28.2	43	56	74	60	90	60	150	150	60	–	–	–	–
20BC056	3	30	22	4	50	53	36.7	56	64	86	70	125	70	200	200	100	–	–	–	–
20BC072	3	37	30	4	50	68.9	47.8	72	84	112	90	150	90	250	250	100	–	–	–	–
20BC085	4	45	–	4	45	81.4	56.4	85	94	128	110	200	110	300	300	150	–	–	–	–
		–	37	4	45	68.9	47.8	72	108	144	90	175	90	275	300	100	–	–	–	–
20BC105	5	55	–	4	50	100.5	69.6	105	116	158	125	225	125	400	300	150	–	–	–	–
		–	45	4	50	81.4	56.4	85	128	170	110	175	110	300	300	150	–	–	–	–
20BC125	5	55	–	4	50	121.1	83.9	125	138	163	150	275	150	500	375	250	–	–	–	–
		–	45	4	50	91.9	63.7	96	144	168	125	200	125	375	375	150	–	–	–	–
20BC140	5	75	–	4	40	136	93.9	140	154	190	200	300	200	400	400	250	–	–	–	–
		–	55	4	40	101	69.6	105	157	190	150	225	150	300	300	150	–	–	–	–
20BC170	6	90	–	4	50	164	126	170	187	255	250	375	250	600	500	250	–	–	–	–
		–	75	4	50	136	103	140	210	280	200	300	200	550	400	250	–	–	–	–
20BC205	6	110	–	4	40	199	148	205	220	289	250	450	250	600	600	400	–	–	–	–
		–	90	4	40	164	126	170	255	313	250	375	250	600	500	250	–	–	–	–
20BC260	6	132	–	2	40	255	177	260	286	390	350	550	350	750	750	400	–	–	–	–
		–	110	2	40	199	138	205	308	410	250	450	250	600	600	400	–	–	–	–

Table 2.S PF700 480 Volt AC Input Protection Devices

Drive Catalog Number	Frame	HP Rating		PWM Freq.	Temp.	Input Ratings		Output Amps			Dual Element Time Delay Fuse		Non-Time Delay Fuse		Circuit Breaker (3)	Motor Circuit Protector (4)	140M Motor Starter with Adjustable Current Range (5)(6)			
		ND	HD	kHz	°C	Amps	kVA	Cont.	1 Min.	3 Sec.	Min. (1)	Max. (2)	Min. (1)	Max. (2)	Max. (8)	Max. (8)	Available Catalog Numbers - 140 . . . (7)			
480 Volt AC Input																				
20BD1P1	0	0.5	0.33	4	50	0.9	0.7	1.1	1.2	1.6	3	3	3	6	15	3	M-C2E-B16	–	–	–
20BD2P1	0	1	0.75	4	50	1.6	1.4	2.1	2.4	3.2	3	6	3	8	15	3	M-C2E-B25	–	–	–
20BD3P4	0	2	1.5	4	50	2.6	2.2	3.4	4.5	6.0	4	8	4	12	15	7	M-C2E-B40	M-D8E-B40	–	–
20BD5P0	0	3	2	4	50	3.9	3.2	5.0	5.5	7.5	6	10	6	20	20	7	M-C2E-B63	M-D8E-B63	–	–
20BD8P0	0	5	3	4	50	6.9	5.7	8.0	8.8	12	10	15	10	30	30	15	M-C2E-C10	M-D8E-C10	M-F8E-C10	–
20BD011	0	7.5	5	4	50	9.5	7.9	11	12.1	16.5	15	20	15	40	40	15	M-C2E-C16	M-D8E-C16	M-F8E-C16	–
20BD014	1	10	7.5	4	50	12.5	10.4	14	16.5	22	17.5	30	17.5	50	50	20	M-C2E-C16	M-D8E-C16	M-F8E-C16	–
20BD022	1	15	10	4	50	19.9	16.6	22	24.2	33	25	50	25	80	80	30	M-C2E-C25	M-D8E-C25	M-F8E-C25	-CMN-2500
20BD027	2	20	15	4	50	24.8	20.6	27	33	44	35	60	35	100	100	50	–	–	M-F8E-C32	-CMN-4000
20BD034	2	25	20	4	50	31.2	25.9	34	40.5	54	40	70	40	125	125	50	–	–	M-F8E-C45	-CMN-4000
20BD040	3	30	25	4	50	36.7	30.5	40	51	68	50	90	50	150	150	50	–	–	M-F8E-C45	-CMN-4000
20BD052	3	40	30	4	50	47.7	39.7	52	60	80	60	110	60	200	200	70	–	–	–	-CMN-6300
20BD065	3	50	40	4	50	59.6	49.6	65	78	104	80	125	80	250	250	100	–	–	–	-CMN-9000
20BD077	4	60	–	4	50	72.3	60.1	77	85	116	100	170	100	300	300	100	–	–	–	-CMN-9000
		–	50	4	50	59.6	49.6	65	98	130	80	125	80	250	250	100	–	–	–	-CMN-9000
20BD096	5	75	–	4	50	90.1	74.9	96	106	144	125	200	125	350	350	125	–	–	–	–
		–	60	4	50	72.3	60.1	77	116	154	100	170	100	300	300	100	–	–	–	-CMN-9000
20BD125	5	100	–	4	50	117	97.6	125	138	163	150	250	150	500	375	150	–	–	–	–
		–	75	4	50	90.1	74.9	96	144	168	125	200	125	350	350	125	–	–	–	–
20BD156	6	125	–	4	50	147	122	156	172	234	200	350	200	600	450	250	–	–	–	–
		–	100	4	50	131	109	125	188	250	175	250	175	500	375	250	–	–	–	–
20BD180	6	150	–	4	50	169	141	180	198	270	225	400	225	600	500	250	–	–	–	–
		–	125	4	50	147	122	156	234	312	200	350	200	600	450	250	–	–	–	–
20BD248	6	200	–	2	40	233	194	248	273	372	300	550	300	700	700	400	–	–	–	–
		–	150	2	40	169	141	180	270	360	225	400	225	600	500	250	–	–	–	–

See page 2-105 for Notes.

Table 2.T PF700 600 Volt AC Input Protection Devices

Drive Catalog Number	Frame	HP Rating		PWM Freq.	Temp.	Input Ratings		Output Amps			Dual Element Time Delay Fuse		Non-Time Delay Fuse		Circuit Breaker (3)	Motor Circuit Protector (4)	140M Motor Starter with Adjustable Current Range (5)(6)			
		ND	HD	kHz	°C	Amps	kVA	Cont.	1 Min.	3 Sec.	Min.(1)	Max.(2)	Min.(1)	Max.(2)	Max.(8)	Max.(8)	Available Catalog Numbers - 140 . . .(7)			
600 Volt AC Input																				
20BE1P7	0	1	0.5	4	50	1.3	1.4	1.7	2	2.6	2	4	2	6	15	3	M-C2E-B16	–	–	–
20BE2P7	0	2	1	4	50	2.1	2.1	2.7	3.6	4.8	3	6	3	10	15	3	M-C2E-B25	–	–	–
20BE3P9	0	3	2	4	50	3.0	3.1	3.9	4.3	5.9	6	9	6	15	15	7	M-C2E-B40	M-D8E-B40	–	–
20BE6P1	0	5	3	4	50	5.3	5.5	6.1	6.7	9.2	9	12	9	20	20	15	M-C2E-B63	M-D8E-B63	–	–
20BE9P0	0	7.5	5	4	50	7.8	8.1	9	9.9	13.5	10	20	10	35	30	15	M-C2E-C10	M-D8E-C10	M-F8E-C10	–
20BE011	1	10	7.5	4	50	9.9	10.2	11	13.5	18	15	25	15	40	40	15	M-C2E-C10	M-D8E-C10	M-F8E-C10	–
20BE017	1	15	10	4	50	15.4	16.0	17	18.7	25.5	20	40	20	60	50	20	M-C2E-C16	M-D8E-C16	M-F8E-C16	–
20BE022	2	20	15	4	50	20.2	21.0	22	25.5	34	30	50	30	80	80	30	M-C2E-C25	M-D8E-C25	M-F8E-C25	-CMN-2500
20BE027	2	25	20	4	50	24.8	25.7	27	33	44	35	60	35	100	100	50	–	–	M-F8E-C25	-CMN-2500
20BE032	3	30	25	4	50	29.4	30.5	32	40.5	54	40	70	40	125	125	50	–	–	M-F8E-C32	-CMN-4000
20BE041	3	40	30	4	50	37.6	39.1	41	48	64	50	90	50	150	150	100	–	–	M-F8E-C45	-CMN-4000
20BE052	3	50	40	4	50	47.7	49.6	52	61.5	82	60	110	60	200	200	100	–	–	–	-CMN-6300
20BE062	4	60	50	2	50	58.2	60.5	62	78	104	80	125	80	225	225	100	–	–	–	-CMN-6300
20BE077	5	75	–	2	50	72.3	75.1	77	85	116	90	150	90	300	300	100	–	–	–	-CMN-9000
		–	60	2	50	58.2	60.5	63	94	126	90	125	90	250	250	100	–	–	–	-CMN-6300
20BE099	5	100	–	2	40	92.9	96.6	99	109	126	125	200	125	375	375	150	–	–	–	–
		–	75	2	40	72.3	75.1	77	116	138	100	175	100	300	300	100	–	–	–	-CMN-9000
20BE125	6	125	–	2	50	117	122	125	138	188	150	250	150	375	375	250	–	–	–	–
		–	100	2	50	93	96.6	99	149	198	125	200	125	375	375	150	–	–	–	–
20BE144	6	150	–	2	50	135	141	144	158	216	175	300	175	400	400	250	–	–	–	–
		–	125	2	50	117	122	125	188	250	150	275	150	375	375	250	–	–	–	–

Table 2.U PF700 690 Volt AC Input Protection Devices

Drive Catalog Number	Frame	kW Rating		PWM Freq.	Temp.	Input Ratings		Output Amps			Dual Element Time Delay Fuse		Non-Time Delay Fuse		Circuit Breaker (3)	Motor Circuit Protector (4)
		ND	HD	kHz	°C	Amps	kVA	Cont.	1 Min.	3 Sec.	Min.(1)	Max.(2)	Min.(1)	Max.(2)	Max.(8)	Max.(8)
690 Volt AC Input																
20BF052	5	45	–	4	50	46.9	56.1	52	57	78	60	110	60	175	175	–
		–	37.5	4	50	40.1	48.0	46	69	92	50	90	50	150	150	–
20BF060	5	55	–	4	50	57.7	68.9	60	66	90	80	125	80	225	225	–
		–	45	4	50	46.9	56.1	52	78	104	60	110	60	175	175	–
20BF082	5	75	–	2	50	79.0	94.4	82	90	123	100	200	100	375	375	–
		–	55	2	50	57.7	68.9	60	90	120	80	125	80	225	225	–
20BF098	5	90	–	2	40	94.7	113	98	108	127	125	200	125	375	375	–
		–	75	2	40	79.0	94.4	82	123	140	100	200	100	375	375	–
20BF119	6	110	–	2	50	115	137	119	131	179	150	250	150	400	–	–
		–	90	2	50	94.7	113	98	147	196	125	200	125	375	–	–
20BF142	6	132	–	2	50	138	165	142	156	213	175	300	175	450	–	–
		–	110	2	50	115	137	119	179	238	150	250	150	400	–	–

Notes:

(1) Minimum protection device size is the lowest rated device that supplies maximum protection without nuisance tripping.

(2) Maximum protection device size is the highest rated device that supplies drive protection. For US NEC, minimum size is 125% of motor FLA. Ratings shown are maximum.

(3) Circuit Breaker - inverse time breaker. For US NEC, minimum size is 125% of motor FLA. Ratings shown are maximum.

(4) Motor Circuit Protector - instantaneous trip circuit breaker. For US NEC minimum size is 125% of motor FLA. Ratings shown are maximum.

(5) Bulletin 140M with adjustable current range should have the current trip set to the minimum range that the device will not trip.

(6) Manual Self-Protected (Type E) Combination Motor Controller, UL listed for 208 Wye or Delta, 240 Wye or Delta, 480Y/277 or 600Y/ 347. Not UL listed for use on 480V or 600V Delta/Delta systems.

(7) The AIC ratings of the Bulletin 140M Motor Protector may vary. See publication 140M-SG001B-EN-P.

(8) Maximum allowable rating by US NEC. Exact size must be chosen for each installation.

Table 2.V PF700 540 Volt DC Input Protection Devices

Drive Catalog Number	Frame	kW Rating		DC Input Ratings		Output Amps			Fuse	Bussmann Style Fuse
		ND	*HD*	*Amps*	*kW*	*Cont.*	*1 Min.*	*3 Sec.*		
540 Volt DC Input										
20BC1P3	1	0.37	0.25	1.3	0.7	1.3	1.4	1.9	3	BUSSMANN_JKS-3
20BC2P1	1	0.75	0.55	2.1	1.1	2.1	2.4	3.2	6	BUSSMANN_JKS-6
20BC3P5	1	1.5	0.75	3.7	2.0	3.5	4.5	6.0	8	BUSSMANN_JKS-8
20BC5P0	1	2.2	1.5	5.3	2.9	5.0	5.5	7.5	10	BUSSMANN_JKS-10
20BC8P7	1	4	3.0	9.3	5.0	8.7	9.9	13.2	20	BUSSMANN_JKS-20
20BC011	1	5.5	4	12.6	6.8	11.5	13	17.4	25	BUSSMANN_JKS-25
20BC015	1	7.5	5.5	16.8	9.1	15.4	17.2	23.1	30	BUSSMANN_JKS-30
20BC022	1	11	7.5	24	13	22	24.2	33	45	BUSSMANN_JKS-45
20BC030	2	15	11	33.2	17.9	30	33	45	60	BUSSMANN_JKS-60
20BC037	2	18.5	15	40.9	22.1	37	45	60	80	BUSSMANN_JKS-80
20BC043	3	22	18.5	47.5	25.7	43	56	74	90	BUSSMANN_JKS-90
20BC056	3	30	22	61.9	33.4	56	64	86	110	BUSSMANN_JKS-110
20BC072	3	37	30	80.5	43.5	72	84	112	150	BUSSMANN_JKS-150
20BC085	4	–	37	80.5	43.5	72	108	144	150	BUSSMANN_JKS-150
		45	–	95.1	51.3	85	94	128	200	BUSSMANN_JKS-200
20BH105 (1)	5	–	45	95.1	51.3	85	128	170	200	BUSSMANN_JKS-200
		55	–	117.4	63.4	105	116	158	200	BUSSMANN_JKS-200
20BH125 (1)	5	–	45	91.9	63.7	96	144	168	150	
		55	–	139.8	75.5	125	138	163	225	BUSSMANN_JKS-225
20BH140 (1)	6	–	55	117.4	63.4	105	158	210	200	BUSSMANN_JKS-200
		75	–	158.4	85.6	140	154	210	300	BUSSMANN_JKS-300
20DH170 (1)	6	–	75	158.4	85.6	140	210	280	300	BUSSMANN_JKS-300
		90	–	192.4	103.9	170	187	255	350	BUSSMANN_JKS-350
20DH205 (1)	6	–	90	192.4	103.9	170	255	313	350	BUSSMANN_JKS-350
		110	–	232	125.3	205	220	289	400	BUSSMANN_JKS-400

(1) Also applies to "P" voltage class.

Table 2.W PF700 650 Volt DC Input Protection Devices

Drive Catalog Number	Frame	kW Rating		DC Input Ratings		Output Amps			Fuse	Bussmann Style Fuse
		ND	*HD*	*Amps*	*kW*	*Cont.*	*1 Min.*	*3 Sec.*		
650 Volt DC Input										
20BD1P1	0	0.5	0.33	1.0	0.6	1.1	1.2	1.6	6	BUSSMANN_JKS-6
20BD2P1	0	1	0.75	1.9	1.2	2.1	2.4	3.2	6	BUSSMANN_JKS-6
20BD3P4	0	2	1.5	3.0	2.0	3.4	4.5	6.0	6	BUSSMANN_JKS-6
20BD5P0	0	3	2	4.5	2.9	5.0	5.5	7.5	10	BUSSMANN_JKS-10
20BD8P0	0	5	3	8.1	5.2	8.0	8.8	12	15	BUSSMANN_JKS-15
20BD011	0	7.5	5	11.1	7.2	11	12.1	16.5	20	BUSSMANN_JKS-20
20BD014	1	10	7.5	14.7	9.5	14	16.5	22	30	BUSSMANN_JKS-30
20BD022	1	15	10	23.3	15.1	22	24.2	33	45	BUSSMANN_JKS-45
20BD027	2	20	15	28.9	18.8	27	33	44	60	BUSSMANN_JKS-60
20BD034	2	25	20	36.4	23.6	34	40.5	54	70	BUSSMANN_JKS-70
20BD040	3	30	25	42.9	27.8	40	51	68	80	BUSSMANN_JKS-80
20BD052	3	40	30	55.7	36.1	52	60	80	100	BUSSMANN_JKS-100
20BD065	3	50	40	69.7	45.4	65	78	104	150	BUSSMANN_JKS-150
20BR077 (1)	4	–	50	67.9	45.4	65	98	130	150	BUSSMANN_JKS-150
	4	60	–	84.5	54.7	77	85	116	150	BUSSMANN_JKS-150
20BR096 (1)	5	–	60	84.5	54.7	77	116	154	150	BUSSMANN_JKS-150
		75	–	105.3	68.3	96	106	144	200	BUSSMANN_JKS-200
20BR125 (1)	5	–	75	105.3	68.3	96	144	168	200	BUSSMANN_JKS-200
		100	–	137.1	88.9	125	138	163	250	BUSSMANN_JKS-250
20BR156 (1)	6	–	100	137.1	88.9	125	188	250	250	BUSSMANN_JKS-250
		125	–	171.2	110.9	156	172	234	300	BUSSMANN_JKS-300
20BR180 (1)	6	–	125	171.2	110.9	156	234	312	300	BUSSMANN_JKS-300
		150	–	204.1	132.2	180	198	270	400	BUSSMANN_JKS-400

(1) Also applies to "J" voltage class.

Grounding, General

Refer to "*Wiring and Grounding Guidelines for PWM AC Drives,*" publication DRIVES-IN001.

HIM Memory

See Copy Cat on page 2-55.

HIM Operations

Selecting a Language

See also Language on page 2-111. PowerFlex 700 drives support multiple languages. When you first apply drive power, a language screen appears on the HIM. Use the Up or Down Arrow to scroll through the available languages. Press Enter to select the desired language. To switch to an alternate language, follow the steps below.

Step	Key(s)	Example Displays
1. Press ALT and then the Up Arrow (Lang). The Language screen will appear. 2. Press the Up Arrow or Down Arrow to scroll through the languages. 3. Press Enter to select a language.	ALT + ▲ ▲ ▼ ↵	Speak English? Parlez Francais? Spechen Duetsch? Plare Italiano?

Using Passwords

By default the password is set to 00000 (password protection disabled).

Logging in to the Drive

Step	Key(s)	Example Displays
1. Press the Up or Down Arrow to enter your password. Press Sel to move from digit to digit. 2. Press Enter to log in.	▲ ▼ ↵	Login: Enter Password 9999

Logging Out

Step	Key(s)	Example Displays
You are automatically logged out when the User Display appears. If you want to log out before that, select "log out" from the Main Menu.		

To change a password

Step	Key(s)	Example Displays
1. Use the Up Arrow or Down Arrow to scroll to Operator Intrfc. Press Enter. 2. Select "Change Password" and press Enter. 3. Enter the old password. If a password has not been set, type "0." Press Enter. 4. Enter a new password (1- 65535). Press Enter and verify the new password. Press Enter to save the new password.	▲ ▼ ↵ ▲ ▼ ↵	Operator Intrfc: Change Password User Display Parameters Password: Old Code: 0 New Code: 9999 Verify: 9999

The User Display

The User Display is shown when module keys have been inactive for a predetermined amount of time. The display can be programmed to show pertinent information.

Setting the User Display

Step	Key(s)	Example Displays
1. Press the Up Arrow or Down Arrow to scroll to Operator Intrfc. Press Enter. 2. Press the Up Arrow or Down Arrow to scroll to User Display. Press Enter. 3. Select the desired user display. Press Enter. Scroll to the parameter that the user display will be based on. 4. Press Enter. Set a scale factor. 5. Press Enter to save the scale factor and move to the last line. 6. Press the Up Arrow or Down Arrow to change the text. 7. Press Enter to save the new user display.		Operator Intrfc: Change Password User Display Parameters

Setting the Properties of the User Display

The following HIM parameters can be set as desired:

- User Display - Enables or disables the user display.
- User Display 1 - Selects which user display parameter appears on the top line of the user display.
- User Display 2 - Selects which user display parameter appears on the bottom line of the user display.
- User Display Time - Sets how many seconds will elapse after the last programming key is touched before the HIM displays the user display.

Input Devices

Contactors

See Motor Start/Stop Precautions on page 2-121

Circuit Breakers / Fuses

See Fuses and Circuit Breakers on page 2-100

Filters, EMC

Refer to CE Conformity on page 2-53.

Input Modes

The PowerFlex family of drives does not use a direct choice of 2-wire or 3-wire input modes, but allows full configuration of the digital I/O. As a means of defining the modes used, consider the following:

2-Wire Control This input mode is so named because it only utilizes one device and 2 wires to control both the Start (normally referred to as "RUN" in 2-wire) and Stop functions in an application.	• A maintained contact device, such as a thermostat, for example, closes its contact to Run the drive and opens to Stop the drive	
	• In other applications, the maintained device (such as a limit switch), can directly control both Run/Stop and direction control . . .	
	• Or, a combination of the two may be desirable.	
3-Wire Control This input mode utilizes 2 devices requiring 3 wires to control the Start (proper term for 3-wire) and Stop functions in an application. In this case, momentary contact devices, such as pushbuttons are used.	• A Start is issued when the Start button is closed, but unlike 2-wire circuits, the drive does not Stop when the Start button is released. Instead, 3-wire control requires a Stop input to Stop the drive	
	• Direction control is accomplished either with momentary inputs . . .	
	• Or, with a maintained input.	

Input Power Conditioning

Refer to Chapter 2 of "*Wiring and Grounding Guidelines for PWM AC Drives*," publication DRIVES-IN001A-EN-P.

Jog

Also refer to Jog on page 2-67.

When a JOG command is issued by any of the controlling devices (terminal block digital input, communications adapter or HIM), the drive ouputs voltage and frequency to the motor as long as the command is present. When the command is released, the drive output stops.

Whenever a jog command is present, the value programmed in parameter 100, [Jog Speed] becomes the active speed reference. Regardless of the [Speed Mode] or [Feedback Select] setting, no modifications (i.e. no PI adder, no slip adder, no trim adder, etc.) will be made to the reference.

For PowerFlex 70 and PowerFlex 700 with **Standard Control**, the jog reference will always be a positive number limited between Minimum Speed and Maximum Speed.

If [Direction Mode] = "Unipolar" the drive will jog using the Jog reference parameter value and will use the direction currently selected via the DPI commanded direction. When [Direction Mode] = "Bipolar" and a Jog command (with no direction) is asserted, the drive will jog using the Jog reference parameter (which is always positive or forward). To accommodate jogging with direction while in Bipolar mode (such as from a terminal block), the drive will allow Jog Fwd and Jog Rev to be configured as terminal block inputs. When these inputs are asserted, the drive will jog the requested direction. This still implies that a HIM can only jog in the forward direction when in Bipolar mode since they only transmit a Jog command with no direction via DPI.

For PowerFlex 700 drives with **Vector Control**, 2 independent Jog Speeds (1 and 2) are provided. The jog reference is signed and limited between Minimum Speed or Reverse Speed Limit (whichever is programmed)) and Maximum Speed. In this control, the jog reference controls both speed and direction of the jog operation. If the programmed Jog Speed is negative the drive will jog in the reverse direction: if the Jog Speed value is positive, the drive will jog in the forward direction.

When a jog command is issued, exclusive control of speed and direction is given to the Jog function. If the master speed reference is bipolar and commanding reverse direction but the programmed Jog Speed is a positive value, the drive will jog in the forward direction, overriding the direction control of a bipolar speed reference.

Language

PowerFlex drives are capable of communicating in 7 languages; English, Spanish, German, Italian, French, Portuguese and Dutch. All drive functions and information displayed on an LCD HIM are shown in the selected language. The desired language can be selected several different ways:

- On initial drive power-up, a language choice screen appears.
- The language choice screen can also be recalled at any time to change to a new language. This is accomplished by pressing the “Alt” key followed by the “Lang” key.
- The language can also be changed by selecting the [Language] parameter (201). Note that this parameter is not functional when using an LED HIM.

Linking Parameters

(Vector Control Option Only)

Most parameter values are entered directly by the user. However, certain parameters can be "linked," so the value of one parameter becomes the value of another. For Example: the value of an analog input can be linked to [Accel Time 2]. Rather than entering an acceleration time directly (via HIM), the link allows the value to change by varying the analog signal. This can provide additional flexibility for advanced applications.

Each link has 2 components:

- Source parameter – sender of information.
- Destination parameter – receiver of information.

Most parameters can be a source of data for a link, except parameter values that contain an integer representing an ENUM (text choice). These are not allowed, since the integer is not actual data (it represents a value). Table 2.X lists the parameters that can be destinations. All links must be established between equal data types (parameter value formatted in floating point can only source data to a destination parameter value that is also floating point).

Establishing A Link

Step	Key(s)	Example Displays
1. Select a valid destination parameter (see Table 2.X) to be linked. The parameter value screen will appear.		FGP: Parameter Accel Time 1 **Accel Time 2** Decel Time 1
2. Press Enter to edit the parameter. The cursor will move to the value line.	Enter	
3. Press ALT and then View (Sel). Next, press the Up or Down Arrow to change "Present Value" to "Define Link." Press Enter.	ALT + Sel ▲ or ▼ Enter	Min: 0.1 Secs Max: 3600.0 Secs Dflt: 10.0 Secs Present Value . . .
4. Enter the Source Parameter Number and press Enter. The linked parameter can now be viewed two different ways by repeating steps 1-4 and selecting "Present Value" or "Define Link." If an attempt is made to edit the value of a linked parameter, "Parameter is Linked!" will be displayed, indicating that the value is coming from a source parameter and can not be edited.	Enter	Define Link Parameter: #141 Accel Time 2 Link: 017 Analog In1 Value
5. To remove a link, repeat steps 1-5 and change the source parameter number to zero (0).		
6. Press Esc to return to the group list.	Esc	

Table 2.X Linkable Parameters

Number	Parameter
54	Maximum Voltage
56	Compensation
57	Flux Up Mode
58	Flux Up Time
59	SV Boost Filter
62	IR Voltage Drop
63	Flux Current Ref
69	Start/Acc Boost
70	Run Boost
71	Break Voltage
72	Break Frequency
84	Skip Frequency 1
85	Skip Frequency 2
86	Skip Frequency 3
87	Skip Freq Band
91	Speed Ref A Hi
92	Speed Ref A Lo
94	Speed Ref B Hi
95	Speed Ref B Lo
97	TB Man Ref Hi
98	TB Man Ref Lo
100	Jog Speed
101	Preset Speed 1
102	Preset Speed 2
103	Preset Speed 3
104	Preset Speed 4
105	Preset Speed 5
106	Preset Speed 6
107	Preset Speed 7
119	Trim Hi
120	Trim Lo
121	Slip RPM @ FLA
122	Slip Comp Gain
123	Slip RPM Meter
127	PI Setpoint
129	PI Integral Time
130	PI Prop Gain
131	PI Lower Limit
132	PI Upper Limit
133	PI Preload
140	Accel Time 1
141	Accel Time 2
142	Decel Time 1
143	Decel Time 2
146	S-Curve %
148	Current Lmt Val
149	Current Lmt Gain
151	PWM Frequency
152	Droop RPM @ FLA
153	Regen Power Limit
154	Current Rate Limit
158	DC Brake Level
159	DC Brake Time

Number	Parameter
160	Bus Reg Ki
164	Bus Reg Kp
165	Bus Reg Kd
170	Flying StartGain
175	Auto Rstrt Delay
180	Wake Level
181	Wake Time
182	Sleep Level
183	Sleep Time
185	Power Loss Time
186	Power Loss Level
321	Anlg In Sqr Root
322	Analog In1 Hi
323	Analog In1 Lo
324	Analog In1 Loss
325	Analog In2 Hi
326	Analog In2 Lo
327	Analog In2 Loss
343	Analog Out1 Hi
344	Analog Out1 Lo
346	Analog Out2 Hi
347	Analog Out2 Lo
381	Dig Out1 Level
382	Dig Out1 OnTime
383	Dig Out1 OffTime
385	Dig Out2 Level
386	Dig Out2 OnTime
387	Dig Out2 OffTime
389	Dig Out3 Level
390	Dig Out3 OnTime
391	Dig Out3 OffTime
416	Fdbk Filter Sel
419	Notch Filter Freq
420	Notch Filter K
428	Torque Ref A Hi
429	Torque Ref A Lo
430	Torq Ref A Div
432	Torque Ref B Hi
433	Torque Ref B Lo
434	Torq Ref B Mult
435	Torque Setpoint
436	Pos Torque Limit
437	Neg Torque Limit
445	Ki Speed Loop
446	Kp Speed Loop
447	Kf Speed Loop
449	Speed Desired BW
450	Total Inertia
454	Rev Speed Limit
460	PI Reference Hi
461	PI Reference Lo
462	PI Feedback Hi
463	PI Feedback Lo

Masks

A mask is a parameter that contains one bit for each of the possible Adapters. Each bit acts like a valve for issued commands. Closing the valve (setting a bit's value to 0) stops the command from reaching the drive logic. Opening the valve (setting a bit's value to 1) allows the command to pass through the mask into the drive logic.

COMMUNICATION	Masks & Owners	276	**[Logic Mask]** Determines which adapters can control the drive. If the bit for an adapter is set to "0," the adapter will have no control functions except for stop.  *Factory Default Bit Values*	288 thru 297
		277	**[Start Mask]** Controls which adapters can issue start commands.	See [Logic Mask].	288 thru 297
		278	**[Jog Mask]** Controls which adapters can issue jog commands.	See [Logic Mask].	288 thru 297
		279	**[Direction Mask]** Controls which adapters can issue forward/reverse direction commands.	See [Logic Mask].	288 thru 297
		280	**[Reference Mask]** Controls which adapters can select an alternate reference; [Speed Ref A, B Sel] or [Preset Speed 1-7].	See [Logic Mask].	288 thru 297
		281	**[Accel Mask]** Controls which adapters can select [Accel Time 1, 2].	See [Logic Mask].	288 thru 297
		282	**[Decel Mask]** Controls which adapters can select [Decel Time 1, 2].	See [Logic Mask].	288 thru 297
		283	**[Fault Clr Mask]** Controls which adapters can clear a fault.	See [Logic Mask].	288 thru 297
		284	**[MOP Mask]** Controls which adapters can issue MOP commands to the drive.	See [Logic Mask].	288 thru 297
		285	**[Local Mask]** Controls which adapters are allowed to take exclusive control of drive logic commands (except stop). Exclusive "local" control can only be taken while the drive is stopped.	See [Logic Mask].	288 thru 297

Example: A customer's process is normally controlled by a remote PLC, but the drive is mounted on the machine. The customer does not want anyone to walk up to the drive and reverse the motor because it would damage the process. The local HIM (drive mounted Adapter 1) is configured with an operator's panel that includes a "REV" Button. To assure that only the PLC (connected to Adapter 2) has direction control, the [Direction Mask] can be set as follows:

Direction Mask



This “masks out” the reverse function from all adapters except Adapter 2, making the local HIM (Adapter 1) REV button inoperable. Also see Owners on page 2-127.

MOP

The Motor Operated Pot (MOP) function is one of the sources for the frequency reference. The MOP function uses digital inputs to increment or decrement the Speed reference at a programmed rate.

The MOP has three components:

- [MOP Rate] parameter
- [Save MOP Ref] parameter
- [MOP Frequency] parameter

MOP increment input

MOP decrement input

The MOP reference rate is defined in [MOP rate]. The MOP function is defined graphically below



MOP rate is defined in Hz/sec. The MOP reference will increase/decrease linearly at that rate as long as the MOP inc or dec is asserted via TB or DPI port (the MOP inputs are treated as level sensitive).

Both the MOP inc and dec will use the same rate (i.e. they can not be separately configured). The MOP rate is the rate of change of the MOP reference. The selected active MOP reference still feeds the ramp function to arrive at the present commanded speed/frequency (eg. is still based on the accel/decel rates). Asserting both MOP inc and dec inputs simultaneously will result in no change to the MOP reference.

[Save MOP Ref] is a packed boolean parameter with two bits used as follows:

Bit 0
0 = Don’t save MOP reference on power-down (default)
1 = Save MOP reference on power-down

If the value is “SAVE MOP Ref” when the drive power returns, the MOP reference is reloaded with the value from the non-volatile memory. When the bit is set to 0, the MOP reference defaults to zero when power is restored. The MOP save reference parameter and the MOP rate parameter can be changed while the drive is running.

Bit 1
0 = Reset MOP reference when STOP edge is asserted
1 = Don’t reset MOP reference when STOP is asserted (default)

Important: The MOP reset only occurs on the *stop* edge and is not continuously cleared because the *stop* is asserted (this is always processed when a *stop* edge is seen, even if the drive is stopped). The reset only applies to the stop edge and not when a fault is detected.

In order to change the MOP reference (increment or decrement) a given DPI port must have the MOP mask asserted (and the logic mask asserted). In the case of the terminal block, if the MOP increment or MOP decrement function is assigned to a digital input, then the act of asserting either of those inputs will cause the TB to try and gain ownership of the MOP inc/dec reference change.

Ownership of the MOP function can be obtained even if the MOP reference is not being used to control the drive. If ownership is granted, the owner has the right to inc/dec the MOP reference. Whether this reference is the active speed reference for the drive is separately selected via TB reference select, or Ref A/B select through DPI.

The MOP Frequency parameter is an output which shows the active value of the MOP reference in Hz x 10.

MOP handling with Direction Mode

If the Direction Mode is configured for “Unipolar,” then the MOP decrement will clamp at zero not allowing the user to generate a negative MOP reference that is clamped off by the reference generation. When Direction Mode = “Bipolar” the MOP reference will permit the decrement function to produce negative values. If the drive is configured for Direction Mode = “Bipolar” and then is changed to “Unipolar”, the MOP reference will also be clamped at zero if it was less than zero.

Motor Control

See Torque Performance Modes on page 2-205

Motor Nameplate

[Motor NP Volts]
The motor nameplate base voltage defines the output voltage, when operating at rated current, rated speed, and rated temperature.

[Motor NP FLA]
The motor nameplate defines the output amps, when operating at rated voltage, rated speed, and rated temperature. It is used in the motor thermal overload, and in the calculation of slip.

[Motor NP Hz]
The motor nameplate base frequency defines the output frequency, when operating at rated voltage, rated current, rated speed, and rated temperature.

[Motor NP RPM]
The motor nameplate RPM defines the rated speed, when operating at motor nameplate base frequency, rated current, base voltage, and rated temperature. This is used to calculate slip.

[Motor NP Power]
The motor nameplate power is used together with the other nameplate values to calculate default values for motor parameters to and facilitate the commissioning process. This may be entered in horsepower or in kilowatts as selected in the previous parameter or kW for certain catalog numbers and HP for others.

[Motor NP Pwr Units]
Determines the units for [Motor NP Power]. Possible setting are:

0 “Horsepower” - units are displayed in HP
1 “kilowatts” - units are displayed in kW

The following are only available with the PowerFlex 700 Vector option
2 “Convert HP” - converts units to HP (from kW) by dividing [Motor NP Power] by 0.746.
3 “Covert kW” - converts units to kW (from HP) by multiplying [Motor NP Power] by 0.746.

Vector [Motor Poles]
Defines the number of motor poles in the motor. [Motor Poles] is calculated automatically if the user enters the motor nameplate data through the Start-up menu of an LCD HIM. The number of motor poles is defined by:

$$P = \frac{120f}{N}$$

where:
P = motor poles
f = base motor frequency (Hz)
N = base motor speed (RPM)
P is rounded up to the nearest whole even number

Motor Overload

The motor thermal overload uses an IT algorithm to model the temperature of the motor. The curve is modeled after a Class 10 protection thermal overload relay that produces a theoretical trip at 600% motor current in ten (10) seconds and continuously operates at full motor current.



Motor nameplate FLA programming is used to set the overload feature. This parameter, which is set in the start up procedure, is adjustable from 0 - 200% of drive rating and should be set for the actual motor FLA rating.

Setting the correct bit in [Fault Config x] to zero disables the motor thermal overload. Most multimotor applications (using one drive and more than one motor) will require the MTO to be disabled since the drive would be unable to distinguish each individual motor's current and provide protection.

Operation of the overload is based on three parameters; [Motor NP FLA], [Motor OL Factor] and [Motor OL Hertz].

1. [Motor NP FLA] is the base value for motor protection.
2. [Motor OL Factor] is used to adjust for the service factor of the motor. Within the drive, motor nameplate FLA is multiplied by motor overload factor to select the rated current for the motor thermal overload. This can be used to raise or lower the level of current that will cause the motor thermal overload to trip without the need to adjust the motor FLA. For example, if motor nameplate FLA is 10 Amps and motor overload factor is 1.2, then motor thermal overload will use 12 Amps as 100%.



3. [Motor OL Hertz] is used to further protect motors with limited speed ranges. Since some motors may not have sufficient cooling ability at lower speeds, the Overload feature can be programmed to increase protection in the lower speed areas. This parameter defines the frequency where derating the motor overload capacity should begin. As shown here, the motor overload capacity is reduced when operating below the motor overload Hz. For all settings of overload Hz other than zero, the overload capacity is reduced to 70% when output frequency is zero. During DC injection the motor current may exceed 70% of FLA, but this will cause the Motor Thermal Overload to trip sooner than when operating at base speed. At low frequencies, the limiting factor may be the Drive Thermal Overload.



Duty Cycle for the Motor Thermal Overload

When the motor is cold motor thermal overload will allow 3 minutes at 150%. When the motor is hot motor thermal overload will allow 1 minute at 150%. A continuous load of 102% will not trip. The duty cycle of the motor thermal overload is defined as follows. If operating continuous at 100% FLA, and the load increases to 150% FLA for 59 seconds and then returns to 100%FLA, the load must remain at 100% FLA for 20 minutes to reach steady state.



The ratio of 1:20 is the same for all durations of 150%. When operating continuous at 100%, if the load increases to 150% for 1 second the load must then return to 100% for 20 seconds before another step to 150%

FLA%	Cold Trip Time	Hot Trip Time
105	6320	5995
110	1794	1500
115	934	667
120	619	375
125	456	240
130	357	167
135	291	122
140	244	94
145	209	74
150	180	60

FLA%	Cold Trip Time	Hot Trip Time
155	160	50
160	142	42
165	128	36
170	115	31
175	105	27
180	96	23
185	88	21
190	82	19
195	76	17
200	70	15

FLA%	Cold Trip Time	Hot Trip Time
205	66	14
210	62	12
215	58	11
220	54	10
225	51	10
230	48	9
235	46	8
240	44	8
245	41	7
250	39	7

Motor Start/Stop Precautions

Input Contactor Precautions

ATTENTION: A contactor or other device that routinely disconnects and reapplies the AC line to the drive to start and stop the motor can cause drive hardware damage. The drive is designed to use control input signals that will start and stop the motor. If an input device is used, operation must not exceed one cycle per minute or drive damage will occur.

ATTENTION: The drive start/stop/enable control circuitry includes solid state components. If hazards due to accidental contact with moving machinery or unintentional flow of liquid, gas or solids exist, an additional hardwired stop circuit may be required to remove the AC line to the drive. An auxiliary braking method may be required.

Output Contactor Precaution

ATTENTION: To guard against drive damage when using output contactors, the following information must be read and understood. One or more output contactors may be installed between the drive and motor(s) for the purpose of disconnecting or isolating certain motors/loads. If a contactor is opened while the drive is operating, power will be removed from the respective motor, but the drive will continue to produce voltage at the output terminals. In addition, reconnecting a motor to an active drive (by closing the contactor) could produce excessive current that may cause the drive to fault. If any of these conditions are determined to be undesirable or unsafe, an auxiliary contact on the output contactor should be wired to a drive digital input that is programmed as “Enable.” This will cause the drive to execute a coast-to-stop (cease output) whenever an output contactor is opened.

Bypass Contactors

ATTENTION: An incorrectly applied or installed bypass system can result in component damage or reduction in product life. The most common causes are:

- Wiring AC line to drive output or control terminals.
- Improper bypass or output circuits not approved by Allen-Bradley.
- Output circuits which do not connect directly to the motor.

Contact Allen-Bradley for assistance with application or wiring.

Mounting

Refer to the Chapter 1 of the correct drive User Manual for mounting instructions and limitations. As a general rule, drives should be mounted on a metallic flat surface in the vertical orientation. If other orientations are being considered, contact the factory for additional data.

Notch Filter

Vector FV The 700 Vector has a notch filter in the torque reference loop used to eliminate mechanical resonance created by a gear train. [Notch Filter Freq] sets the center frequency for the 2 pole notch filter, and [Notch Filter K] sets the gain.

Figure 2.23 Notch Filter Frequency



Due to the fact that most mechanical frequencies are described in Hertz, [Notch Filter Freq] and [Notch Filter K] are in Hertz as well. The following is an example of a notch filter.

A mechanical gear train consists of two masses (the motor and the load) and spring (mechanical coupling between the two loads). See Figure 2.24.

Figure 2.24 Mechanical Gear Train



The resonant frequency is defined by the following equation:

$$resonance = \sqrt{Kspring \frac{(Jm + Jload)}{Jm \times Jload}}$$

Jm is the motor inertia (seconds)
Jload is the load inertia (seconds)
Kspring is the coupling spring constant (rad^2/sec)

Figure 2.25 shows a two mass system with a resonant frequency of 62 radians/second (9.87 Hz). One Hertz is equal to 2ðπ radians/second.

Figure 2.25 Resonance



The insert shows the resonant frequency in detail.

Figure 2.26 shows the same mechanical gear train as Figure 2.25. [Notch Filter Freq] is set to 10.

Figure 2.26 10 Hz Notch



Output Current

[Output Current]

This parameter displays the total output current of the drive. The current value displayed here is the vector sum of both torque producing and flux producing current components.

Output Devices

Drive Output Contactor

ATTENTION: To guard against drive damage when using output contactors, the following information must be read and understood. One or more output contactors may be installed between the drive and motor(s) for the purpose of disconnecting or isolating certain motors/loads. If a contactor is opened while the drive is operating, power will be removed from the respective motor, but the drive will continue to produce voltage at the output terminals. In addition, reconnecting a motor to an active drive (by closing the contactor) could produce excessive current that may cause the drive to fault. If any of these conditions are determined to be undesirable or unsafe, an auxiliary contact on the output contactor should be wired to a drive digital input that is programmed as "Enable." This will cause the drive to execute a coast-to-stop (cease output) whenever an output contactor is opened.

Also see Input Devices on page 2-108.

Cable Termination

Voltage doubling at motor terminals, known as reflected wave phenomenon, standing wave or transmission line effect, can occur when using drives with long motor cables.

Inverter duty motors with phase-to-phase insulation ratings of 1200 volts or higher should be used to minimize effects of reflected wave on motor insulation life.

Applications with non-inverter duty motors or any motor with exceptionally long leads may require an output filter or cable terminator. A filter or terminator will help limit reflection to the motor, to levels which are less than the motor insulation rating.

Cable length restrictions for unterminated cables are discussed on page 2-51. Remember that the voltage doubling phenomenon occurs at different lengths for different drive ratings. If your installation requires longer motor cable lengths, a reactor or cable terminator is recommended.

Optional Output Reactor

Bulletin 1321 Reactors can be used for drive input and output. These reactors are specifically constructed to accommodate IGBT inverter applications with switching frequencies up to 20 kHz. They have a UL approved dielectric strength of 4000 volts, opposed to a normal rating of 2500 volts. The first two and last two turns of each coil are triple insulated to guard

against insulation breakdown resulting from high dv/dt. When using motor line reactors, it is recommended that the drive PWM frequency be set to its lowest value to minimize losses in the reactors.

By using an output reactor the effective motor voltage will be lower because of the voltage drop across the reactor - this may also mean a reduction of motor torque.

Output Frequency

[Output Frequency]

This parameter displays the actual output frequency of the drive. The output frequency is created by a summation of commanded frequency and any active speed regulator such as slip compensation, PI Loop, bus regulator. The actual output may be different than the commanded frequency.

Output Power

This parameter displays the output kW of the drive. The output power is a calculated value and tends to be inaccurate at lower speeds. It is not recommended for use as a process variable to control a process.

Output Voltage

[Output Voltage]

This parameter displays the actual output voltage at the drive output terminals. The actual output voltage may be different than that determined by the sensorless vector or V/Hz algorithms because it may be modified by features such as the Auto-Economizer.

Overspeed Limit

The Overspeed Limit is a user programmable value that allows operation at maximum speed but also provides an “overspeed band” that will allow a speed regulator such as encoder feedback or slip compensation to increase the output frequency above maximum Speed in order to maintain maximum Motor Speed.

Figure 2.27 illustrates a typical Custom V/Hz profile. Minimum Speed determines the lower speed reference limit during normal operation. Maximum Speed determines the upper speed reference limit. The two “Speed” parameters only limit the speed reference and not the output frequency.

The actual output at maximum speed reference is the sum of the speed reference plus “speed adder” components from functions such as slip compensation, encoder feedback or process trim.

The Overspeed Limit is added to Maximum Speed and the sum of the two (Speed Limit) limits is output. This sum (Speed Limit) is compared to Maximum Frequency and an alarm is initiated which prevents operation if the Speed Limit exceeds Maximum Frequency.

Figure 2.27 Typical V/Hz Curve for Full Custom (with Speed/Frequency Limits



Note 1: The lower limit on this range can be 0 depending on the value of Speed Adder

Owners

An owner is a parameter that contains one bit for each of the possible DPI or SCANport adapters. The bits are set high (value of 1) when its adapter is currently issuing that command, and set low when its adapter is not issuing that command. Ownership falls into two categories;

Exclusive

Only one adapter at a time can issue the command and only one bit in the parameter will be high.

For example, it is not allowable to have one Adapter command the drive to run in the forward direction while another Adapter is issuing a command to make the drive run in reverse. Direction Control, therefore, is exclusive ownership.

Non Exclusive

Multiple adapters can simultaneously issue the same command and multiple bits may be high.

COMMUNICATIONS	Masks & Owners	288	**[Stop Owner]** Adapters presently issuing a valid stop command.  	Read Only	276 thru 285
		289	**[Start Owner]** Adapters that are presently issuing a valid start command.	See [Stop Owner]	276 thru 285
		290	**[Jog Owner]** Adapters that are presently issuing a valid jog command.	See [Stop Owner]	276 thru 285
		291	**[Direction Owner]** Adapter that currently has exclusive control of direction changes.	See [Stop Owner]	276 thru 285
		292	**[Reference Owner]** Adapter that has the exclusive control of the command frequency source selection.	See [Stop Owner]	276 thru 285
		293	**[Accel Owner]** Adapter that has exclusive control of selecting [Accel Time 1, 2].	See [Stop Owner]	140 276 thru 285
		294	**[Decel Owner]** Adapter that has exclusive control of selecting [Decel Time 1, 2].	See [Stop Owner]	142 276 thru 285
		295	**[Fault Clr Owner]** Adapter that is presently clearing a fault.	See [Stop Owner]	276 thru 285
		296	**[MOP Owner]** Adapters that are currently issuing increases or decreases in MOP command frequency.	See [Stop Owner]	276 thru 285
		297	**[Local Owner]** Adapter that has requested exclusive control of all drive logic functions. If an adapter is in local lockout, all other functions (except stop) on all other adapters are locked out and non-functional. Local control can only be obtained when the drive is not running.	See [Stop Owner]	276 thru 285

Conversely, any number of adapters can simultaneously issue Stop Commands. Therefore, Stop Ownership is **not** exclusive.

Example:

The operator presses the Stop button on the Local HIM to stop the drive. When the operator attempts to restart the drive by pressing the HIM Start button, the drive does not restart. The operator needs to determine why the drive will not restart.

The operator first views the Start owner to be certain that the Start button on the HIM is issuing a command.

Start Owner



When the local Start button is pressed, the display indicates that the command is coming from the HIM.

Start Owner



The [Start Owner] indicates that there is not any maintained Start commands causing the drive to run.

Stop Owner



The operator then checks the Stop Owner. Notice that bit 0 is a value of “1,” indicating that the Stop device wired to the Digital Input terminal block is open, issuing a Stop command to the drive.

Until this device is reclosed, a permanent Start Inhibit condition exists and the drive will not restart.

Also refer to Start Inhibits and Start Permissives.

Parameter Access Level

The PowerFlex 70 allows the user to restrict the number of parameters that are viewable on the LCD or LED HIM. By limiting the parameter view to the most commonly adjusted set, additional features that may make the drive seem more complicated are hidden.

If you are trying to gain access to a particular parameter and the HIM skips over it, you must change the parameter view from “Basic” to “Advanced.” This can be accomplished in two different ways:

- Press “Alt” and then “View” from the HIM and change the view.

or

- Reprogram Parameter 196 [Param Access Lvl] to “Advanced”.

PET

Pulse Elimination Technique – See Reflected Wave on page 2-152.

Power Loss

Some processes or applications cannot tolerate drive output interruptions caused by momentary power outages. When AC input line power is interrupted to the drive, user programming can determine the drive's reaction.

Terms

The following is a definition of terms. Some of these values are drive parameters and some are not. The description of how these operate is explained below

Term	Definition
Vbus	The instantaneous DC bus voltage.
Vmem	The average DC bus voltage. A measure of the "nominal" bus voltage determined by heavily filtering bus voltage. Just after the pre-charge relay is closed during the initial power-up bus pre-charge, bus memory is set equal to bus voltage. Thereafter it is updated by ramping at a very slow rate toward Vbus. The filtered value ramps at 2.4V DC per minute (for a 480VAC drive). An increase in Vmem is blocked during deceleration to prevent a false high value due to the bus being pumped up by regeneration. Any change to Vmem is blocked during inertia ride through.
Vslew	The rate of change of Vmem in volts per minute.
Vrecover	The threshold for recovery from power loss.
Vtrigger	The threshold to detect power loss. PowerFlex 700 The level is adjustable. The default is the value in the PF700 Bus Level table. If "Pwr Loss Lvl" is selected as an input function AND energized, Vtrigger is set to Vmem minus [Power Loss Level]. Vopen is normally 60V DC below Vtrigger (in a 480VAC drive). Both Vopen and Vtrigger are limited to a minimum of Vmin. This is only a factor if [Power Loss Level] is set to a large value. PowerFlex 70 This is a fixed value. **WARNING:** When using a value of Parameter #186 [Power Loss Level] larger than default, the customer must provide a minimum line impedance to limit inrush current when the power line recovers. The input impedance should be equal or greater than the equivalent of a 5% transformer with a VA rating 5 times the drive's input VA rating.
Vinertia	The software regulation reference for Vbus during inertia ride through.
Vclose	The threshold to close the pre-charge contactor.
Vopen	The threshold to open the pre-charge contactor.
Vmin	The minimum value of Vopen.
Voff	The bus voltage below which the switching power supply falls out of regulation.

Table 2.Y PF70 Bus Levels

Class	200/240 VAC	400/480 VAC	600/690 VAC
Vslew	1.2V DC	2.4V DC	3.0V DC
Vrecover	Vmem – 30V	Vmem – 60V	Vmem – 75V
Vclose	Vmem – 60V	Vmem – 120V	Vmem – 150V
Vtrigger1	Vmem – 60V	Vmem – 120V	Vmem – 150V
Vtrigger2	Vmem – 90V	Vmem – 180V	Vmem – 225V
Vopen	Vmem – 90V	Vmem – 180V	Vmem – 225V
Vmin	204V DC	407V DC	509V DC
Voff 3	?	300V DC	?





Table 2.Z PF700 Bus Levels

Class	200/240V AC	400/480V AC	600/690V AC
Vslew	1.2V DC	2.4V DC	3.0V DC
Vrecover	Vmem – 30V	Vmem – 60V	Vmem – 75V
Vclose	Vmem – 60V	Vmem – 120V	Vmem – 150V
Vtrigger1,2	Vmem – 60V	Vmem – 120V	Vmem – 150V
Vtrigger1,3	Vmem – 90V	Vmem – 180V	Vmem – 225V
Vopen	Vmem – 90V	Vmem – 180V	Vmem – 225V
Vopen4	153V DC	305V DC	382V DC
Vmin	153V DC	305V DC	382V DC
Voff 5	–	200V DC	–

Note 1:Vtrigger is adjustable, these are the standard values.







Restart after Power Restoration

If a power loss causes the drive to coast and power recovers the drive will return to powering the motor if it is in a “run permit” state. The drive is in a “run permit” state if:

3 wire mode – it is not faulted and if all Enable and Not Stop inputs are energized.

2 wire mode – it is not faulted and if all Enable, Not Stop, and Run inputs are energized.

Power Loss Actions

The drive is designed to operate at a nominal bus voltage. When Vbus falls below this nominal value by a significant amount, action can be taken to preserve the bus energy and keep the drive logic alive as long as possible. The drive will have three methods of dealing with low bus voltages:

- “Coast” – Disable the transistors and allow the motor to coast.
- “Decel” – Decelerate the motor at just the correct rate so that the energy absorbed from the mechanical load balances the losses.
- “Continue” – Allow the drive to power the motor down to half bus voltage.

	Power Loss	184	**[Power Loss Mode]** Sets the reaction to a loss of input power. Power loss is recognized when: • DC bus voltage is ≤ 73% of [DC Bus Memory] and [Power Loss Mode] is set to “Coast”. • DC bus voltage is ≤ 82% of [DC Bus Memory] and [Power Loss Mode] is set to “Decel”.	Default: Options:	0 0 1 2 3 4	“Coast” “Coast” “Decel” “Continue” “Coast Input” “Decel Input”	013 185

Coast

This is the default mode of operation.

The drive determines a power loss has occurred if the bus voltage drops below Vtrigger. If the drive is running the inverter output is disabled and the motor coasts.

The power loss alarm in [Drive Alarm 1] is set and the power loss timer starts.

The Alarm bit in [Drive Status 1] is set if the Power Loss bit in [Alarm Config 1] is set.

The drive faults with a F003 – Power Loss Fault if the power loss timer exceeds [Power Loss Time] and the Power Loss bit in [Fault Config 1] is set.

The drive faults with a F004 – UnderVoltage fault if the bus voltage falls below Vmin and the UnderVoltage bit in [Fault Config 1] is set.

The pre-charge relay opens if the bus voltage drops below Vopen and closes if the bus voltage rises above Vclose

If the bus voltage rises above Vrecover for 20mS, the drive determines the power loss is over. The power loss alarm is cleared.

If the drive is in a “run permit” state, the reconnect algorithm is run to match the speed of the motor. The drive then accelerates at the programmed rate to the set speed.



480V example shown, see Table 2.Z for further information.

Decel

This mode of operation is useful if the mechanical load is high inertia and low friction. By recapturing the mechanical energy, converting it to electrical energy and returning it to the drive, the bus voltage is maintained. As long as there is mechanical energy, the ride through time is extended and the motor remains fully fluxed up. If AC input power is restored, the drive can ramp the motor to the correct speed without the need for reconnecting.

The drive determines a power loss has occurred if the bus voltage drops below Vtrigger.

If the drive is running, the inertia ride through function is activated.

The load is decelerated at just the correct rate so that the energy absorbed from the mechanical load balances the losses and bus voltage is regulated to the value Vinertia.

The Power Loss alarm in [Drive Alarm 1] is set and the power loss timer starts.

The Alarm bit in [Drive Status 1] is set if the Power Loss bit in [Alarm Config 1] is set.

The drive faults with a F003 – Power Loss fault if the power loss timer exceeds [Power Loss Time] and the Power Loss bit in [Fault Config 1] is set.

The drive faults with a F004 – UnderVoltage fault if the bus voltage falls below Vmin and the UnderVoltage bit in [E238 Fault Config 1] is set.

The inverter output is disabled and the motor coasts if the output frequency drops to zero or if the bus voltage drops below Vopen or if any of the “run permit” inputs are de-energized.

The pre-charge relay opens if the bus voltage drops below Vopen.

The pre-charge relay closes if the bus voltage rises above Vclose

If the bus voltage rises above Vrecover for 20mS, the drive determines the power loss is over. The power loss alarm is cleared.

If the drive is still in inertia ride through operation, the drive immediately accelerates at the programmed rate to the set speed. If the drive is coasting and it is in a “run permit” state, the reconnect algorithm is run to match the speed of the motor. The drive then accelerates at the programmed rate to the set speed.



480V example shown, see Table 2.Z for further information.

Half Voltage

This mode provides the maximum power ride through. In a typical application 230VAC motors are used with a 480VAC drive, the input voltage can then drop to half and the drive is still able to supply full power to the motor.

ATTENTION: To guard against drive damage, a minimum line impedance must be provided to limit inrush current when the power line recovers. The input impedance should be equal or greater than the equivalent of a 5% transformer with a VA rating 6 times the drive’s input VA rating.

The drive determines a power loss has occurred if the bus voltage drops below Vtrigger.

If the drive is running the inverter output is disabled and the motor coasts.

If the bus voltage drops below Vopen/Vmin (In this mode of operation Vopen and Vmin are the same value) or if the Enable input is de-energized, the inverter output is disabled and the motor coasts. If the Not Stop or Run inputs are de-energized, the drive stops in the programmed manner.

The pre-charge relay opens if the bus voltage drops below Vopen/Vmin and closes if the bus voltage rises above Vclose.

The power loss alarm in [Drive Alarm 1] is set and the power loss timer starts. The Alarm bit in [Drive Status 1] is set if the Power Loss bit in [Alarm Config 1] is set.

The drive faults with a F003 – Power Loss fault if the power loss timer exceeds [Power Loss Time] and the Power Loss bit in [Fault Config 1] is set.

The drive faults with a F004 – UnderVoltage fault if the bus voltage falls below Vmin and the UnderVoltage bit in [Fault Config 1] is set.

If the bus voltage rises above Vrecover for 20mS, the drive determines the power loss is over. The power loss alarm is cleared.

If the drive is coasting and if it is in a “run permit” state, the reconnect algorithm is run to match the speed of the motor. The drive then accelerates at the programmed rate to the set speed.



480V example shown, see Table 2.Z for further information.

Coast Input (PowerFlex700 Only)

This mode can provide additional ride through time by sensing the power loss via an external device that monitors the power line and provides a hardware power loss signal. This signal is then connected to the drive through the “pulse” input (because of its high-speed capability). Normally this hardware power loss input will provide a power loss signal before the bus drops to less than Vopen.

The drive determines a power loss has occurred if the “pulse” input is de-energized OR the bus voltage drops below Vopen. If the drive is running, the inverter output is disabled.

The Power Loss alarm in [Drive Alarm 1] is set and the power loss timer starts.

The Alarm bit in [Drive Status 1] is set if the Power Loss bit in [Alarm Config 1] is set.

The drive faults with a F003 – Power Loss fault if the power loss timer exceeds [Power Loss Time] and the Power Loss bit in [Fault Config 1] is set.

The drive faults with a F004 – UnderVoltage fault if the bus voltage falls below Vmin and the UnderVoltage bit in [Fault Config 1] is set.

The pre-charge relay opens if the bus voltage drops below Vopen and closes if the bus voltage rises above Vclose.

If the “pulse” input is re energized and the pre-charge relay is closed, the drive determines the power loss is over. The power loss alarm is cleared.

If the drive is in a “run permit” state, the reconnect algorithm is run to match the speed of the motor. The drive then accelerates at the programmed rate to the set speed.

Decel Input (PF700 only)

This mode can provide additional ride through time by sensing the power loss via an external device that monitors the power line and provides a hardware power loss signal. This signal is then connected to the drive through the “pulse” input (because of its high-speed capability). Normally this hardware power loss input will provide a power loss signal before the bus drops to less than Vopen.

The drive determine a power loss has occurred if the “pulse” input is de-energized or the bus voltage drops below Vopen.

If the drive is running, the inertia ride through function is activated. The load is decelerated at just the correct rate so that the energy absorbed from the mechanical load balances the losses and bus voltage is regulated to the value Vmem.

If the output frequency drops to zero or if the bus voltage drops below Vopen or if any of the “run permit” inputs are de-energized, the inverter output is disabled and the motor coasts.

The power loss alarm in [Drive Alarm 1] is set and the power loss timer starts. The Alarm bit in [Drive Status 1] is set if the Power Loss bit in [Alarm Config 1] is set.

The drive faults with a F003 – Power Loss fault if the power loss timer exceeds [Power Loss Time] and the Power Loss bit in [E238 Fault Config 1] is set.

The drive faults with a F004 – UnderVoltage fault if the bus voltage falls below Vmin and the UnderVoltage bit in [Fault Config 1] is set.

The pre-charge relay opens if the bus voltage drops below Vopen and closes if the bus voltage rises above Vclose.

If power recovers while the drive is still in inertia ride through the power loss alarm is cleared and it then accelerates at the programmed rate to the set speed. Otherwise, if power recovers before power supply shutdown, the power loss alarm is cleared.

If the drive is in a “run permit” state, the reconnect algorithm is run to match the speed of the motor. The drive then accelerates at the programmed rate to the set speed.

Preset Frequency

There are 7 Preset Frequency parameters that are used to store a discrete frequency value. This value can be used for a speed reference or PI Reference. When used as a speed reference, they are accessed via manipulation of the digital inputs or the DPI reference command. Preset frequencies have a range of plus/minus [Maximum Speed].

Process PI Loop

[PI Config]
[PI Control]
[PI Reference Sel]
[PI Setpoint]
[PI Feedback Sel]
[PI Integral Time]
[PI Prop Gain]
[PI Upper/Lower Limit]
[PI Preload]
[PI Status]
[PI Ref Meter]
[PI Feedback Meter]
[PI Error Meter]
[PI Output Meter]

The internal PI function provides closed loop process control with proportional and integral control action. The function is designed to be used in applications that require simple control of a process without external control devices. The PI function allows the microprocessor to follow a single process control loop.

The PI function reads a process variable input to the drive and compares it to a desired setpoint stored in the drive. The algorithm will then adjust the output of the PI regulator, changing drive output frequency to try and make the process variable equal the setpoint.

Proportional control (P) adjusts output based on size of the error (larger error = proportionally larger correction). If the error is doubled, then the output of the proportional control is doubled and, conversely, if the error is cut in half then the output of the proportional output will be cut in half. With proportional control there is always an error, so the feedback and the reference are never equal.

Integral control (I) adjusts the output based on the duration of the error. (The longer the error is present, the harder it tries to correct). The integral

control by itself is a ramp output correction. This type of control gives a smoothing effect to the output and will continue to integrate until zero error is achieved. By itself, integral control is slower than many applications require and therefore is combined with proportional control (PI).

Derivative Control (D) adjusts the output based on the rate of change of the error and, by itself, tends to be unstable. The faster that the error is changing, the larger change to the output. Derivative control is generally not required and, when it is used, is almost always combined with proportional and integral control (PID).

The PI function can perform a combination of proportional and integral control. It does not perform derivative control, however, the accel / decel control of the drive can be considered as providing derivative control.

There are two ways the PI Controller can be configured to modify the commanded speed.

- Process Trim - The PI Output can be added to the master speed reference
- Process Control - PI can have exclusive control of the commanded speed.

The selection between these two modes of operation is done in the [PI Configuration] parameter.

Process Trim

Process Trim takes the output of PI regulator and sums it with a master speed reference to control the process. In the following example, the master speed reference sets the wind/unwind speed and the dancer pot signal is used as a PI Feedback to control the tension in the system. An equilibrium point is programmed as PI Reference, and as the tension increases or decreases during winding, the master speed is trimmed to compensate and maintain tension near the equilibrium point.



When the PI is disabled the commanded speed is the ramped speed reference.



When the PI is enabled, the output of the PI Controller is added to the ramped speed reference.



Exclusive Control

Process Control takes the output of PI regulator as the speed command. No master speed reference exists and the PI Output directly controls the drive output.

In the pumping application example below, the reference or setpoint is the required pressure in the system. The input from the transducer is the PI feedback and changes as the pressure changes. The drive output frequency is then increased or decreased as needed to maintain system pressure

regardless of flow changes. With the drive turning the pump at the required speed, the pressure is maintained in the system.



However, when additional valves in the system are opened and the pressure in the system drops, the PI error will alter its output frequency to bring the process back into control.

When the PI is disabled the commanded speed is the ramped speed reference.



When the PI is enabled, the speed reference is disconnected and PI Output has exclusive control of the commanded speed, passing through the linear ramp and s-curve.



Configuration

To operate the drive in PI Regulator Mode for the Standard Control option, change the mode by selecting “Process PI” through the [Speed Mode] parameter.

Three parameters are used to configure, control, and indicate the status of the logic associated with the Process PI controller; [PI Configuration], [PI Control], and [PI Status]. Together these three parameters define the operation of the PI logic.

1. **[PI Configuration]** is a set of bits that select various modes of operation. The value of this parameter can only be changed while the drive is stopped.

   - **Exclusive Mode** - see page 2-139.
   - **Invert Error** - This feature changes the “sign” of the error, creating a decrease in output for increasing error and an increase in output for decreasing error. An example of this might be an HVAC system with thermostat control. In Summer, a rising thermostat reading commands an increase in drive output because cold air is being blown. In Winter, a falling thermostat commands an increase in drive output because warm air is being blown.

     The PI has the option to change the sign of PI Error. This is used when an increase in feedback should cause an increase in output.

     The option to invert the sign of PI Error is selected in the PI Configuration parameter.



   - **Preload Integrator** - This feature allows the PI Output to be stepped to a preload value for better dynamic response when the PI Output is enabled. Refer to diagram 2 below.

     If PI is not enabled the PI Integrator may be initialized to the PI Pre-load Value or the current value of the commanded speed. The operation of Preload is selected in the PI Configuration parameter.



     By default, Pre-load Command is off and the PI Load Value is zero, causing a zero to be loaded into the integrator when the PI is disabled.

As below shown on the left, when the PI is enabled the PI output will start from zero and regulate to the required level. When PI is enabled with PI Load Value is set to a non-zero value the output begins with a step as shown below on the right. This may result in the PI reaching steady state sooner, however if the step is too large the drive may go into current limit which will extend the acceleration.



Pre-load command may be used when the PI has exclusive control of the commanded speed. With the integrator preset to the commanded speed there is no disturbance in commanded speed when PI is enabled. After PI is enabled the PI output is regulated to the required level.



When the PI is configured to have exclusive control of the commanded speed and the drive is in current limit or voltage limit the integrator is preset to the commanded speed so that it knows where to resume when no longer in limit.

- **Ramp Ref** - The PI Ramp Reference feature is used to provide a smooth transition when the PI is enabled and the PI output is used as a speed trim (not exclusive control),.

When PI Ramp Reference is selected in the PI Configuration parameter, and PI is disabled, the value used for the PI reference will be the PI feedback. This will cause PI error to be zero. Then when the PI is enabled the value used for the PI reference will ramp to the selected value for PI reference at the selected acceleration or deceleration rate. After the PI reference reaches the selected value the ramp is bypassed until the PI is disabled and enabled again. S-curve is not available as part of the PI linear ramp.

- **Zero Clamp** - This feature limits the possible drive action to one direction only. Output from the drive will be from zero to maximum frequency forward or zero to maximum frequency reverse. This removes the chance of doing a “plugging” type operation as an attempt to bring the error to zero.

  The PI has the option to limit operation so that the output frequency will always have the same sign as the master speed reference. The zero clamp option is selected in the PI Configuration parameter. Zero clamp is disabled when PI has exclusive control of speed command.

  For example, if master speed reference is +10 Hz and the output of the PI results in a speed adder of –15 Hz, zero clamp would limit the output frequency to not become less than zero. Likewise, if master speed reference is –10 Hz and the output of the PI results in a speed adder of +15 Hz, zero clamp would limit the output frequency to not become greater than zero.



- **Feedback Square Root** - This feature uses the square root of the feedback signal as the PI feedback. This is useful in processes that control pressure, since centrifugal fans and pumps vary pressure with the square of speed.

  The PI has the option to take the square root of the selected feedback signal. This is used to linearize the feedback when the transducer produces the process variable squared. The result of the square root is normalized back to full scale to provide a consistent range of operation. The option to take the square root is selected in the PI Configuration parameter.

- **Stop Mode (PowerFlex 700 Only).** When Stop Mode is set to “1” and a Stop command is issued to the drive, the PI loop will continue



to operate during the decel ramp until the PI output becomes more than the master reference. When set to "0," the drive will disable PI and perform a normal stop. This bit is active in Trim mode only.

- **Anti-Wind Up (PowerFlex 700 Only).** When Anti-Windup is set to "1" the PI loop will automatically prevent the integrator from creating an excessive error that could cause loop instability. The integrator will be automatically controlled without the need for PI Reset or PI Hold inputs.
- Vector FV **Torque Trim.** When Torque Trim is set to "1" the output of the process PI loop will be added to Torque Reference A and B, instead of being added to the speed reference.

2. **[PI Control]** is a set of bits to dynamically enable and disable the operation of the process PI controller. When this parameter is interactively written to from a network it must be done through a data link so the values are not written to EEprom.

   - **PI Enable** - The PI loop can be enabled/disabled. The Enabled status of the PI loop determines when the PI regulator output is part or all of the commanded speed. The logic evaluated for the PI Enabled status is shown in the following ladder diagram.

     The drive must be in run before the PI Enabled status can turn on. The PI will remain disabled when the drive is jogged. The PI is disabled when the drive begins a ramp to stop, except in the PowerFlex 700 when it is in Trim mode and the Stop mode bit in [PI Configuration] is on.

     When a digital input is configured as "PI Enable," the PI Enable bit of [PI Control] must be turned on for the PI loop to become enabled.

     If a digital input is not configured as "PI Enable" and the PI Enable bit in [PI Control] is turned on, then the PI loop may become enabled. If the PI Enable bit of [PI Control] is left continuously, then the PI

may become enabled as soon as the drive goes into run. If analog input signal loss is detected, the PI loop is disabled.



- **PI Hold** - The Process PI Controller has the option to hold the integrator at the current value so if some part of the process is in limit the integrator will maintain the present value to avoid windup in the integrator.

  The logic to hold the integrator at the current value is shown in the following ladder diagram. There are three conditions under which hold will turn on.

– If a digital input is configured to provide PI Hold and that digital input is turned on then the PI integrator will stop changing. Note that when a digital input is configured to provide PI Hold that takes precedence over the PI Control parameter.

– If a digital input is not configured to provide PI Hold and the PI Hold bit in the PI Control parameter is turned on then the PI integrator will stop changing.

– If the current limit or voltage limit is active then the PI is put into hold.



- **PI Reset –** This feature holds the output of the integral function at zero. The term “anti windup” is often applied to similar features. It may be used for integrator preloading during transfer and can be used to hold the integrator at zero during “manual mode”. Take the example of a process whose feedback signal is below the reference point, creating error. The drive will increase its output frequency in an attempt to bring the process into control. If, however, the increase in drive output does not zero the error, additional increases in output will be commanded. When the drive reaches programmed Maximum Frequency, it is possible that a significant amount of integral value has been “built up” (windup). This may cause undesirable and sudden operation if the system were switched to manual operation and back. Resetting the integrator eliminates this windup.

NOTE: In the PowerFlex 70, once the drive has reached the programmable positive and negative PI limits, the integrator stops integrating and no further “windup” is possible.

3. **[PI Status]** parameter is a set of bits that indicate the status of the process PI controller

   - **Enabled –** The loop is active and controlling the drive output.
   - **Hold –** A signal has been issued and the integrator is being held at its current value.
   - **Reset –** A signal has been issued and the integrator is being held at zero.
   - **In Limit –** The loop output is being clamped at the value set in [PI Upper/Lower Limit].

PI Reference and Feedback

The selection of the source for the reference signal is entered in the PI Reference Select parameter. The selection of the source for the feedback signal is selected in the PI Feedback Select parameter. The reference and feedback have the same limit of possible options.

PowerFlex 70 options include DPI adapter ports, MOP, preset speeds, analog inputs and PI setpoint parameter. In the PowerFlex 700, options are expanded to also include additional analog inputs, pulse input, and encoder input.

The value used for reference is displayed in PI Reference as a read only parameter. The value used for feedback is displayed in PI Feedback as a read only parameter. These displays are active independent of PI Enabled. Full scale is displayed as ±100.00.

Refer to Analog Input Configuration on page 2-9.

Vector PI Reference Scaling

The PI reference can be scaled by using [PI Reference Hi] and [PI Reference Lo]. [PI Refence Hi] determines the high value, in percent, for the PI reference. [PI Reference Lo] determines the low value, in percent, for the PI reference.

The PI feedback can be scaled by using [PI Feedback Hi] and [PI Feedback Lo]. [PI Feedback Hi] determines the high value, in percent, for the PI feedback. [PI Feedback Lo] determines the low value, in percent, for the PI feedback.

Configuration Example:

The PI reference meter and PI feedback meter should be displayed as positive and negative values. Feedback from our dancer comes into Analog Input 2 as a 0-10V DC signal.

- [PI Reference Sel] = 0 “PI Setpoint”
- [PI Setpoint] = 0 %
- [PI Feedback Sel] = 2 “Analog In 2”
- [PI Reference Hi] = 100 %
- [PI Reference Lo] = –100 %
- [PI Feedback Hi] = 100 %
- [PI Feedback Lo] = –100 %
- [Analog In 2 Hi] = 10V
- [Analog In 2 Lo] = 0V

PI Feedback Scaling

[Torque Ref A Sel] = “Analog In 1”	
[Analog In 2 Hi] 10 V	[PI Feedback Hi] 100 %
[Analog In 1 Lo] 0V	[PI Feedback Lo] -100 %

Now 5V corresponds to 0% on the PI Feedback, so we will try to maintain a PI setpoint of 0% (5V). Now [PI Ref Meter] and [PI Fdback Meter] are displayed as bipolar values.

PI Setpoint

This parameter can be used as an internal value for the setpoint or reference for the process. If [PI Reference Sel] points to this Parameter, the value entered here will become the equilibrium point for the process.

PI Output

The PI Error is then sent to the Proportional and Integral functions, which are summed together.

PI Gains

The PI Proportional Gain and the PI Integral Gain parameters determine the response of the PI.

The PI Proportional Gain is unitless and defaults to 1.00 for unit gain. With PI Proportional Gain set to 1.00 and PI Error at 1.00% the PI output will be 1.00% of maximum frequency.

The PI Integral Gain is entered in seconds. If the PI Integral Gain is set to 2.0 seconds and PI Error is 100.00% the PI output will integrate from 0 to 100.00% in 2.0 seconds.

Positive and Negative Limits

The PI has parameters to define the positive and negative limits of the output PI Positive Limit, and PI Negative Limit. The limits are used in two places; on the integrator and on the sum of the Kp + Ki terms.

Providing an external source doesn't turn on Hold, the integrator is allowed to integrate all the way to Positive or Negative limit. If the integrator reaches the limit the value is clamped and the InLimit bit is set in the PI Status parameter to indicate this condition.

The limits are entered in the range of ±100.00.

PI Positive Limit must always be greater than PI Negative Limit.

If the application is Process Control, typically these limits would be set to the maximum allowable frequency setting. This allows the PI regulator to control over the entire required speed range.

If the application is Process Trim, large trim corrections may not be desirable and the limits would be programmed for smaller values.



Output Scaling

The output value produced by the PI is displayed as ±100.00. Internally this is represented by ±32767 which corresponds to ±maximum frequency.

Vector FV Output Scaling for Torque Trim

The output value from the Process PI loop, when in torque trim mode, is displayed as +/–100% which corresponds to +/–100% of rated motor torque.

Figure 2.28 Process PI Block Diagram



Figure 2.29 Vector Control Option Process PI Loop Overview



PowerFlex 700 Firmware 3.001 (& later) Enhancements

Process PID Control and Trim enhancements have been included in firmware version 3.001 (and later) for the PowerFlex 700 Vector Control drive, including:

- Derivative term added to Process PI controller to create PID
- Ability to scale output of PID to a percentage of Speed Reference
- Connect scale blocks to the Reference and Feedback selections on PID
- Ability to select % of Reference for the Speed Trim function

Derivative Term

The Derivative term has been added to the Process PI. This adds to the flexibility of the Process control.

459	**Vector v3** **[PI Deriv Time]**	Default:	0.00 Secs
	Refer to formula below:	Min/Max:	0.00/100.00 Secs
	$PI_{Out} = KD\ (Sec) \times \frac{d_{PI\ Error\ (\%)}}{d_t\ (Sec)}$	Units:	0.01 Secs

For example, winders using torque control rely on PD control not PI control. Also, [PI BW Filter] is useful in filtering out unwanted signal response in the PID loop. The filter is a Radians/Second low pass filter.

Percent of Reference

	124	**[PI Configuration]** Sets configuration of the PI regulator.	124 thru 138


% of Ref **
Torque Trim *
Anti-Wind Up
Stop Mode
Feedback Sqrt
Zero Clamp
Ramp Ref
Preload Mode
Invert Error
Excl Mode
x x x x x x 0 0 0 0 0 0 0 0 0 0
15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0
1 = Enabled
0 = Disabled
x = Reserved
Bit #
Factory Default Bit Values
* Vector Control Option Only
** Vector firmware 3.001 & later

When using Process PID control the output can be selected as percent of the Speed Reference. This works in Speed trim mode only, not in Torque Trim or Exclusive Mode.

Example

% of Ref selected, Speed Reference = 43 Hz, PID Output = 10%, Maximum Frequency = 130 Hz . 4.3 Hz will be added to the final speed reference.

% of Ref not selected, Speed Reference = 43 Hz, PID Output = 10%, Maximum Frequency = 130 Hz. 13.0 Hz will be added to the final speed reference.

Scale Blocks with PID

Scale Blocks are now included in the Reference and Feedback selections of the Process PID controller. This selects the output of the scale block for use as Reference or Feedback to the Process PID.

	126	**[PI Reference Sel]** Selects the source of the PI reference. (1) Vector firmware 3.001 and later.	Default:	0	"PI Setpoint"	024 124 thru 138
			Options:	0	"PI Setpoint"	
				1	"Analog In 1"	
				2	"Analog In 2"	
				3-6	"Reserved"	
				7	"Pulse In"	
				8	"Encoder"	
				9	"MOP Level"	
				10	"Master Ref"	
				11-17	"Preset Spd1-7"	
				18-22	"DPI Port 1-5"	
				23-24	"Reserved"	
				25	"Scale Block 1" (1)	
				26	"Scale Block 2" (1)	
				27	"Scale Block 3" (1)	
				28	"Scale Block 4" (1)	

Trim % of Reference

The Trim function of the drive can be selected as % of Reference or % of Maximum Frequency.

	118	**[Trim Out Select]** Specifies which speed references are to be trimmed.	117 119 120


Add or % *
Trim Ref B
Trim Ref A
x x x x x x x x x x x x 0 0 0
15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0
1 = Trimmed/%
0 = Not Trimmed/Add
x = Reserved
Bit #
Factory Default Bit Values
* Vector firmware 3.001 & later.

For example, % selected, Max Frequency = 130, Speed Reference = 22 Hz, Trim Reference = 20%. 4.4 Hz will be added to the Speed Reference.

% not selected, Max Frequency = 130, Speed Reference = 22 Hz, Trim Reference = 20%. 26 Hz will be added to the Speed Reference.

Reflected Wave

[Compensation]

The pulses from a Pulse Width Modulation (PWM) inverter using IGBTs are very short in duration (50 nanoseconds to 1 millisecond). These short pulse times combined with the fast rise times (50 to 400 nanoseconds) of the IGBT, will result in excessive over-voltage transients at the motor.

Voltages in excess of twice the DC bus voltage (650V DC nominal at 480V input) will occur at the motor and can cause motor winding failure.

The patented reflected wave correction software in the PowerFlex 70/700 will reduce these over-voltage transients from a VFD to the motor. The correction software modifies the PWM modulator to prevent PWM pulses less than a minimum time from being applied to the motor. The minimum time between PWM pulses is 10 microseconds. The modifications to the PWM modulator limit the over-voltage transient to 2.25 per unit volts line-to-line peak at 600 feet of cable.

400 V Line = 540V DC bus x 2.25 = 1215V
480 V Line = 650V DC bus x 2.25 = 1463V
600 V Line = 810V DC bus x 2.25 = 1823 V

The software is standard and requires no special parameters or settings.



The above figure shows the inverter line-to-line output voltage (top trace) and the motor line-to-line voltage (bottom trace) for a 10 HP, 460V AC inverter, and an unloaded 10 HP AC induction motor at 60 Hz operation. 500 ft. of #12 AWG cable connects the drive to the motor.

Initially, the cable is in a fully charged condition. A transient disturbance occurs by discharging the cable for approximately 4ms. The propagation delay between the inverter terminals and motor terminals is approximately 1ms. The small time between pulses of 4ms does not provide sufficient time to allow the decay of the cable transient. Thus, the second pulse arrives at a point in the motor terminal voltage's natural response and excites a motor over-voltage transient greater than 2 pu. The amplitude of the double pulsed motor over-voltage is determined by a number of variables. These include the damping characteristics of the cable, bus voltage, and the time between pulses, the carrier frequency, modulation technique, and duty cycle.

The plot below shows the per unit motor overvoltage as a function of cable length. This is for no correction versus the modulation correction code for varied lengths of #12 AWG cable to 600 feet for 4 and 8 kHz carrier frequencies. The output line-to-line voltage was measured at the motor terminals in 100 feet increments.



Without the correction, the overvoltage increases to unsafe levels with increasing cable length for both carrier frequencies.

The patented modulation correction code reduces the overvoltage for both carrier frequencies and maintains a relatively flat overvoltage level for increasing cable lengths beyond 300 feet.

To determine the maximum recommended motor cable lengths for a particular drive refer to Cable, Motor Lengths on page 2-51.

Refer to: **www.ab.com/drives/techpapers/menu** for detailed technical papers.

Regen Power Limit

Vector FV The [Regen Power Lim] is programmed as a percentage of the rated power. The mechanical energy that is transformed into electrical power during a deceleration or overhauling load condition is clamped at this level. Without the proper limit, a bus overvoltage may occur.

When using the bus regulator [Regen Power Lim] can be left at factory default, –50%. When using dynamic braking or a regenerative supply, [Regen Power Lim] can be set to the most negative limit possible (–800%). When the user has dynamic braking or regenerative supply, but wishes to limit the power to the dynamic brake or regenerative supply, [Regen Power Lim] can be set to a level specified by the user.

Reset Meters

The Elapsed kW Hour meter and/or Elapsed Time meter parameters are reset when parameter 200 is set to a value not equal to zero. After the reset has occurred, this parameter automatically returns to a value of zero.

		200	**[Reset Meters]**	Default:	0	"Ready"	
			Resets selected meters to zero.	Options:	0 1 2	"Ready" "MWh" "Elapsed Time"	

0 = Ready
1 = Reset kW Hour Meter
2 = Reset Elapsed Time Meter

Reset Run

Refer to Auto Restart (Reset/Run) on page 2-29.

RFI Filter Grounding

Refer to "*Wiring and Grounding Guidelines for PWM AC Drives,*" publication DRIVES-IN001.

S Curve

The S Curve function of the PowerFlex family of drives allows control of the "jerk" component of acceleration and deceleration through user adjustment of the S Curve parameter. Jerk is the rate of change of acceleration and controls the transition from steady state speed to acceleration or deceleration and vice versa. By adjusting the percentage of S Curve applied to the normal accel/decel ramps, the ramp takes the shape of an "S". This allows a smoother transition that produces less mechanical stress and smoother control for light loads.

Linear Accel & Decel

Acceleration is defined as moving away from zero; deceleration is defined as moving toward zero. The linear acc / dec ramp is active when the S curve% is set to zero. The accel time and maximum frequency determine the ramp rate for speed increases while decel time and maximum frequency determine the ramp rate for speed decreases. Separate times can be set for accel and decel. In addition, a second set of accel and decel times is available. In this example Ta = 1.0 sec, Td = 2.0 sec and Maximum Frequency is set to 60.0 Hz.



S-Curve Selection

S-curve is enabled by defining the time to extend the acceleration and deceleration. The time is entered as a percentage of acceleration and deceleration time. In this case acceleration time is 2.0 seconds. The line on the left has s-curve set to 0%. The other lines show 25%, 50%, and 100% S-curve. At 25% S-curve acceleration time is extended by 0.5 seconds (2.0 * 25%). Note that the linear portion of this line has the same slope as when s-curve is set to zero.



The acceleration and deceleration times are independent but the same S-curve percentage is applied to both of them. With S-curve set to 50%, acceleration time is extended by 0.5 seconds (1.0 * 50%), and deceleration time is extended by 1.0 seconds (2.0 * 50%).



Time to Max Speed

Note that S-curve time is defined for accelerating from 0 to maximum speed. With maximum speed = 60 Hz, Ta = 2.0 sec, and S-curve = 25%, acceleration time is extended by 0.5 seconds (2.0 * 25%). When accelerating to only 30 Hz the acceleration time is still extended by the same amount of time.



Crossing Zero Speed

When the commanded frequency passes through zero the frequency will S-curve to zero and then S-curve to the commanded frequency.



The following graph shows an acceleration time of 1.0 second. After 0.75 seconds, the acceleration time is changed to 6.0 seconds. When the acceleration rate is changed, the commanded rate is reduced to match the requested rate based on the initial S-curve calculation. After reaching the new acceleration rate, the S-curve is then changed to be a function of the new acceleration rate.



Scale Blocks

See also Analog Scaling on page 2-12 and page 2-22.

Vector Scale blocks are used to scale a parameter value. [Scalex In Value] is linked to the parameter that you wish to scale. [Scalex In Hi] determines the high value for the input to the scale block. [Scalex Out Hi] determines the corresponding high value for the output of the scale block. [Scalex In Lo] determines the low value for the input to the scale block. [Scalex Out Lo] determines the corresponding low value for the output of the scale block. [Scalex Out Value] is the resulting output of the scale block.

There are (3) ways to use the output of the scale block:

1. A linkable destination parameter can be linked to [Scalex Out Value]. See Example Configuration #1.

2. [Analog Outx Sel] can be set to:
   - 20, “Scale Block1”
   - 21, “Scale Block2”
   - 22, “Scale Block3”
   - 23, “Scale Block4”

   Note that when the Analog Outputs are set to use the scale blocks, the [Scale x Out Hi] and [Scale x Out Lo] parameters are not active. Instead, [Analog Outx Hi] and [Analog Outx Lo] determine the scaling for the output of the scale block. See Example Configuration #2.

3. [PI Reference Sel] and [PI Feedback Sel] can also use the output of the scale block by setting them to:
   - 25, “Scale Block1 Out”
   - 26, “Scale Block2 Out”

   Note that when [PI Reference Sel] and [PI Feedback Sel] are set to use the scale blocks, the [Scale x Out Hi] and [Scale x Out Lo] parameters are not active. Instead, [PI Reference Hi] and [PI Reference Lo], or [PI Feedback Hi] and [PI Feedback Lo], determine the scaling for the output of the scale block. See Example Configuration #3.

Example Configuration #1

Use the scale blocks to add a speed trim as a percentage of the speed reference instead of as a percent of full speed. Analog In 2 will be used to provide a 0-10V DC trim signal. For example, when the commanded speed is 800 RPM, the maximum trim with 10V DC at Analog In 2 will be 80 RPM. If the commanded speed is 1800 RPM the maximum trim will be 180 RPM.



Parameter Settings

Parameter	Value	Description
[Trim In Select]	11, Preset 1	Preset 1 becomes the trim speed
[Scale1 In Hi]	10.0 V	Hi value of Analog In 2
[Scale1 In Lo]	0 V	Lo value of Analog In 2
[Scale1 Out Lo]	0 RPM	Lo value of desired Trim
[Scale2 In Hi]	1800 RPM	Hi value of Commanded Speed (Max Speed)
[Scale2 In Lo]	0 RPM	Lo value of Commanded Speed
[Scale2 Out Hi]	180 RPM	10% of Max Speed
[Scale2 Out Lo]	0 RPM	Corresponds to lo value of Commanded Speed

Parameter Links

Destination Parameter	Source Parameter	Description
[Scale1 In Value]	[Analog In2 Value]	We are scaling Analog In 2 for our trim
[Scale2 In Value]	[Commanded Speed]	Use Commanded Speed as Input to Scale Block 2
[Scale1 Out Hi]	[Scale2 Out Value]	Use the output of Scale Block 2 to set the upper limit of Scale Block 1 output
[Preset Speed 1]	[Scale 1 Out Value]	Use the scaled analog input as the trim reference into Preset Speed 1



Example Configuration #2

Setup a scale block to send parameter 415, [Encoder Speed] to Analog Output 1 as a 0-10V signal.



Parameter Settings

Parameter	Value	Description
[Analog Out1 Sel]	Scale Block1 Out	Scale Block1 Output goes to Analog Out1
[Analog Out1 Hi]	10 V	Hi value of Analog Output 1 corresponding to Hi value of encoder speed
[Analog Out1 Lo]	0 V	Lo value of Analog Output 1 corresponding to Lo value of encoder speed
[Scale1 In Hi]	1800 RPM	Hi value of the encoder speed
[Scale1 In Lo]	0 RPM	Lo value of the encoder speed

Parameter Links

Destination Parameter	Source Parameter	Description
[Scale1 In Value]	[Encoder Speed]	We are scaling Encoder Speed



Example Configuration #3

In this configuration Analog In 2 is a –10V to +10V signal which corresponds to –800% to +800% motor torque from another drive. We want to use the –200% to +200% range (–2.5V to +2.5V) of that motor torque and correspond it to –100% to +100% of the PI Reference.



Parameter Settings

Parameter	Value	Description
[Scale 1 In Hi]	2.5 V	2.5 V = 200% torque from other drive
[Scale 1 In Lo]	–2.5V	–2.5 V = –200% torque from other drive
[PI Reference Sel]	25, Scale Block1 Out	The PI Reference becomes the output of the scale block
[PI Reference Hi]	100 %	100% PI Reference corresponds to 200% torque from other drive
[PI Reference Lo]	–100 %	–100% PI Reference corresponds to –200% torque from other drive

Parameter Links

Destination Parameter	Source Parameter	Description
[Scale1 In Value]	[Analog In2 Value]	We are scaling Analog In 2 value



Shear Pin Fault

This feature allows the user to select programming that will fault the drive if the drive output current exceeds the programmed current limit. As a default, exceeding the set current limit is not a fault condition. However, if the user wants to stop the process in the event of excess current, the Shear Pin feature can be activated. By programming the drive current limit value and enabling the electronic shear pin, current to the motor is limited, and if excess current is demanded by the motor, the drive will fault.

Configuration

The Shear Pin Fault is activated by setting Bit 4 of [Fault Config 1] to "1."


238
[Fault Config 1]
Enables/disables annunciation of the listed faults.
Out PhaseLoss *
ShearPNo Acc *
Load Loss *
In PhaseLoss *
MotorTherm *
Decel Inhibit
AutRst Tries
Shear Pin
Motor OverLd
UnderVoltage
Power Loss
x x x 0 0 x 0 0 0 1 0 0 1 x 1 0
15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0
1 = Enabled
0 = Disabled
x = Reserved
Bit #
* Vector firmware 3.001 & later
Factory Default Bit Values

The programmable current limit [Current Lmt Sel] should also set to identify the source of the current limit value. If "Cur Lim Val" is selected, then [Current Lmt Val] should be set to the required limit value.

DYNAMIC CONTROL	147	**[Current Lmt Sel]** Selects the source for the adjustment of current limit (i.e. parameter, analog input, etc.).	Default:	0	"Cur Lim Val"	146 149
			Options:	0	"Cur Lim Val"	
				1	"Analog In 1"	
				2	"Analog In 2"	

A separate fault (**Shear Pin Fault, F63)** dedicated to the Shear Pin feature, will be generated if the function is activated.

Application Example

In some applications, mechanical hardware can be damaged if the motor is allowed to develop excess torque. If a mechanical jam should occur, shutting down the system may be the only way to prevent damage. For example, a chain conveyor may be able to "hook" itself, causing a jam on the conveyor. Excess torque from the motor could cause chain or other mechanical damage.



By programming the Shear Pin feature, the user can cause the drive to fault, stopping the excess torque before mechanical damage occurs.

Skip Frequency

Figure 2.30 Skip Frequency



Some machinery may have a resonant operating frequency that must be avoided to minimize the risk of equipment damage. To assure that the motor cannot continuously operate at one or more of the points, skip frequencies are used. Parameters 084-086, ([Skip Frequency 1-3]) are available to set the frequencies to be avoided.

The value programmed into the skip frequency parameters sets the center point for an entire “skip band” of frequencies. The width of the band (range of frequency around the center point) is determined by parameter 87, [Skip Freq Band]. The range is split, half above and half below the skip frequency parameter.

If the commanded frequency of the drive is greater than or equal to the skip (center) frequency and less than or equal to the high value of the band (skip plus 1/2 band), the drive will set the output frequency to the high value of the band. See (A) in Figure 2.30.

If the commanded frequency is less than the skip (center) frequency and greater than or equal to the low value of the band (skip minus 1/2 band), the drive will set the output frequency to the low value of the band. See (C) in Figure 2.30.

Skip Frequency Examples	
The skip frequency will have hysteresis so the output does not toggle between high and low values. Three distinct bands can be programmed. If none of the skip bands touch or overlap, each band has its own high/low limit.	
If skip bands overlap or touch, the center frequency is recalculated based on the highest and lowest band values.	
If a skip band(s) extend beyond the max frequency limits, the highest band value will be clamped at the max frequency limit. The center frequency is recalculated based on the highest and lowest band values.	
If the band is outside the limits, the skip band is inactive.	

Acceleration and deceleration are not affected by the skip frequencies. Normal accel/decel will proceed through the band once the commanded frequency is greater than the skip frequency. See (A) & (B) in Figure 2.30. This function affects only continuous operation within the band.

Sleep Mode

Operation

The basic operation of the Sleep-Wake function is to **Start** (wake) the drive when an analog signal is greater than or equal to the user specified [Wake Level], and **Stop** (sleep) the drive when an analog signal is less than or equal to the user specified [Sleep Level]. Setting [Sleep-Wake Mode] to "Direct" enables the sleep wake function.

Requirements

In addition to enabling the sleep function with [Sleep-Wake Mode], at least one of the following assignments **must** be made to a digital input: Enable, Stop-CF, Run, Run Fwd or Run Rev, and the input must be closed. All normal Start Permissives must also be satisfied (Not Stop, Enable, Not Fault, Not Alarm, etc.).

Conditions to Start/Restart

ATTENTION: Enabling the Sleep-Wake function can cause unexpected machine operation during the Wake mode. Equipment damage and/or personal injury can result if this parameter is used in an inappropriate application. Do Not use this function without considering the table below and applicable local, national & international codes, standards, regulations or industry guidelines.

Table 2.AA Conditions Required to Start Drive (1)(2)(3)

Input	After Power-Up	After a Drive Fault		After a Stop Command
		Reset by Stop-CF, HIM or TB	*Reset by Clear Faults (TB)*	*HIM or TB*
Stop	Stop Closed Wake Signal	Stop Closed Wake Signal New Start or Run Cmd.(4)	Stop Closed Wake Signal	Stop Closed Analog Sig. > Sleep Level(6) New Start or Run Cmd.(4)
Enable	Enable Closed Wake Signal(4)	Enable Closed Wake Signal New Start or Run Cmd.(4)	Enable Closed Wake Signal	Enable Closed Analog Sig. > Sleep Level(6) New Start or Run Cmd.(4)
Run Run For. Run Rev.	Run Closed Wake Signal	New Run Cmd.(5) Wake Signal	Run Closed Wake Signal	New Run Cmd.(5) Wake Signal

(1) When power is cycled, if all conditions are present after power is restored, restart will occur.

(2) If all conditions are present when [Sleep-Wake Mode] is "enabled," the drive will start.

(3) The active speed reference is determined as explained in the User Manual. The Sleep/Wake function and the speed reference may be assigned to the same input.

(4) Command must be issued from HIM, TB or network.

(5) Run Command must be cycled.

(6) Signal does not need to be greater than wake level.

Timers

Timers will determine the length of time required for Sleep/Wake levels to produce true functions. These timers will start counting when the Sleep/Wake levels are satisfied and will count in the opposite direction whenever the respective level is dissatisfied. If the timer counts all the way to the user specified time, it creates an edge to toggle the Sleep/Wake function to the respective condition (sleep or wake). On power up, timers are initialized to the state that does not permit a start condition. When the analog signal satisfies the level requirement, the timers start counting.

Interactive functions

Separate start commands are also honored (including a digital input “start”), but only when the sleep timer is not satisfied. Once the sleep timer times out, the sleep function acts as a continuous stop. There are two exceptions to this, which will ignore the Sleep/Wake function:

1. When a device is commanding “local” control

2. When a jog command is being issued.

When a device is commanding “local” control, the port that is commanding it has exclusive start control (in addition to ref select), essentially overriding the Sleep/Wake function, and allowing the drive to run in the presence of a sleep situation. This holds true even for the case of Port 0, where a digital input start or run will be able to override a sleep situation.

Sleep/Wake Levels

Normal operation will require that [Wake Level] be set greater than or equal to [Sleep Level]. However, there are no limits that prevent the parameter settings from crossing, but the drive will not start until such settings are corrected. These levels are programmable while the drive is running. If [Sleep Level] is made greater than [Wake Level] while the drive is running, the drive will continue to run as long as the analog input remains at a level that doesn’t trigger the sleep condition. Once the drive goes to sleep in this situation, it will not be allowed to restart until the level settings are corrected (increase wake, or decrease sleep). If however, the levels are corrected prior to the drive going to sleep, normal Sleep/Wake operation will continue.

Sleep/Wake Sources

All defined analog inputs for a product shall be considered as valid Sleep/ Wake sources. The Sleep/Wake function is completely independent of any other functions that are also using the assigned analog input. Thus, using the same analog input for both speed reference and wake control is permitted. Also, [Analog In x Hi] and [Analog In x Lo] parameters have no affect on the function. However, the factory calibrated result will be used. In addition, the absolute value of the calibrated result will be used, thus making the function useful for bipolar direction applications. The analog in loss function is unaffected and therefore operational with the Sleep/Wake function, but not tied to the sleep or wake levels.

Figure 2.31 Sleep/Wake Function



Speed Control, Mode, Regulation & Vector Speed Feedback

The purpose of speed regulation is to allow the drive to adjust certain operating conditions, such as output frequency, to compensate for actual motor speed losses in an attempt to maintain motor shaft speed within the specified regulation percentage.

The [Speed Mode] parameter selects the speed regulation method for the drive, and can be set to one of 3 choices on the PowerFlex 70/700. The PowerFlex 700 Vector option has 5 choices. In addition, [Feedback Select] in the Vector option, chooses the feedback used for the speed regulator.

- Open Loop - No speed control is offered
- Slip Comp - Slip Compensation is active – approximately 5% regulation
- Process PI - The PI Loop sets the actual speed based on process variables

	080	Standard **[Speed Mode]**	Default:	0	"Open Loop"
		Sets the method of speed regulation.	Options:	0	"Open Loop"
				1	"Slip Comp"
				2	"Process PI"
		Vector **[Feedback Select]**	Default:	0	"Open Loop"
		Selects the source for motor speed feedback. Note that all selections are available when using Process PI. "Open Loop" (0) - no encoder is present, and slip compensation is not needed. "Slip Comp" (1) - tight speed control is needed, and encoder is not present. "Encoder" (3) - an encoder is present. "Simulator" (5) - Simulates a motor for testing drive operation & interface check.	Options:	0	"Open Loop"
				1	"Slip Comp"
				2	"Reserved"
				3	"Encoder"
				4	"Reserved"
				5	"Simulator"

Open Loop

As the load on an induction motor increases, the rotor speed or shaft speed of the motor decreases, creating additional slip (and therefore torque) to drive the larger load. This decrease in motor speed may have adverse effects on the process. If the [Speed Mode] parameter is set to "Open Loop," no speed control will be exercised. Motor speed will be dependent on load changes and the drive will make no attempt to correct for increasing or decreasing output frequency due to load.

Slip Compensation

As the load on an induction motor increases, the rotor speed or shaft speed of the motor decreases, creating additional slip (and therefore torque) to drive the larger load. This decrease in motor speed may have adverse effects on the process. If speed control is required to maintain proper process control, the slip compensation feature of the PowerFlex drives can be enabled by the user to more accurately regulate the speed of the motor without additional speed transducers.

When the slip compensation mode is selected, the drive calculates an amount to increase the output frequency to maintain a consistent motor speed independent of load. The amount of slip compensation to provide is selected in [Slip RPM @ FLA]. During drive commissioning this parameter is set to the RPM that the motor will slip when operating with Full Load Amps. The user may adjust this parameter to provide more or less slip.

As mentioned above, induction motors exhibit slip which is the difference between the stator electrical frequency, or output frequency of the drive, and the induced rotor frequency.

The slip frequency translates into a slip speed resulting in a reduction in rotor speed as the load increases on the motor. This can be easily seen by examining Figure 2.32.

Figure 2.32 Rotor Speed with/without Slip Compensation



Without slip compensation active, as the load increases from no load to 150% of the motor rating, the rotor speed decreases approximately proportional to the load.

With slip compensation, the correct amount of slip compensation is added to the drive output frequency based on motor load. Thus, the rotor speed returns to the original speed. Conversely, when the load is removed, the rotor speed increases momentarily until the slip compensation decays to zero.

Motor nameplate data must be entered by the user in order for the drive to correctly calculate the proper amount of slip compensation. The motor nameplate reflects slip in the rated speed value at rated load. The user can enter the Motor Nameplate RPM, Motor Nameplate Frequency, the Motor Nameplate Current, Motor Nameplate Voltage, and Motor Nameplate HP/kW and during commissioning the drive calculates the motor rated slip frequency and displays it in [Slip RPM @ FLA]. The user can adjust the slip compensation for more accurate speed regulation, by increasing or decreasing [Slip RPM @ FLA] value.

Internally, the drive converts the rated slip in RPM to rated slip in frequency. To more accurately determine the rated slip frequency in hertz, an estimate of flux current is necessary. This parameter is either a default value based on motor nameplate data or the auto tune value. The drive scales the amount of slip compensation to the motor rated current. The amount of slip frequency added to the frequency command is then scaled by the sensed torque current (indirect measurement of the load) and displayed.

Slip compensation also affects the dynamic speed accuracy (ability to maintain speed during “shock” loading). The effect of slip compensation during transient operation is illustrated in Figure 2.33. Initially, the motor is operating at some speed and no load. At some time later, an impact load is applied to the motor and the rotor speed decreases as a function of load and inertia. And finally, the impact load is removed and the rotor speed increases momentarily until the slip compensation is reduced based on the applied load.

When slip compensation is enabled the dynamic speed accuracy is dependent on the filtering applied to the torque current. The filtering delays the speed response of the motor/drive to the impact load and reduces the dynamic speed accuracy. Reducing the amount of filtering applied to the torque current can increase the dynamic speed accuracy of the system. However, minimizing the amount of filtering can result in an unstable motor/drive. The user can adjust the Slip Comp Gain parameter to decrease or increase the filtering applied to the torque current and improve the system performance.

Figure 2.33 Rotor Speed Response Due to Impact Load and Slip Com Gain



Application Example - Baking Line

The diagram below shows a typical application for the Slip Compensation feature. The PLC controls the frequency reference for all four of the drives. Drive #1 and Drive #3 control the speed of the belt conveyor. Slip compensation will be used to maintain the RPM independent of load changes caused by the cutter or dough feed. By maintaining the required RPM, the baking time remains constant and therefore the end product is consistent.

With the Slip Compensation feature, the process will only require a new speed reference when the product is changed. The user will not have to tune the drive due to a different load characteristic.



Process PI – *See* *Process PI Loop on page 2-137*

Vector **Encoder**

There is (1) encoder input on the I/O board of the PowerFlex 700VC. The encoder input must be line driver type, quadrature (dual channel) or pulse (single channel). The encoder input accepts 8 or 12V DC encoder signals. There is a 12V DC supply on the drive that can be used to supply power for the encoders.

An encoder offers the best performance for both speed and torque regulation applications. Encoder feedback is required for applications with high bandwidth response, tight speed regulation, torque regulation of (+/- 2%) or when the motor is required to operate at less than 1/120th its' base speed.

[Motor Fdbk Type] selects the type of encoder:

- "Quadrature" – dual channel.
- "Quad Check" – dual channel and detects loss of encoder signal when using differential inputs.
- "Single Chan" – pulse type, single channel.
- "Single Check" – pulse type, single channel and detects loss of encoder signal when using differential inputs.

[Encoder PPR] sets the number of encoder pulses per revolution.

[Enc Position Fdbk] displays the raw encoder count. For single channel encoders, this count will increase (per rev.) by the amount in [Encoder PPR]. For quadrature encoders this count will increase by 4 times the amount defined in [Encoder PPR].

Vector Encoderless/Deadband

Encoderless/Deadband is recommended when more than a 120:1 speed range of operation is not required and the user will set the speed reference below 0.5Hz/15 RPM. The deadband will help prevent cogging and unstable motor operation below a reference of 0.5Hz/15RPM by clamping the speed and torque regulators to zero.

Vector Simulator

The simulator mode allows the drive to be operated without a motor connected and is meant for demo purposes only. If a motor is connected with this mode selected very erratic and unpredictable operation will occur.

Speed Feedback Filter

Vector [Fdbk Filter Select] determines the type of filter to use for the speed feedback. The filter is used to filter out high frequency signals (noise) by reducing the gain at high frequencies. The selections for the filter are:

Description	To select this type of filter . . .	Select this value . . .
No filter		0
A light 35/49 radian feedback filter		1
A heavy 20/40 radian feedback filter		2

Speed Reference

Operation

The output frequency of the drive is controlled, in part, by the speed command or speed reference given to it. This reference can come from a variety of sources including:

- HIM (local or remote)
- Analog Input
- Preset Speed Parameter
- Jog Speed Parameter
- Communications Adapter
- Process PI Loop
- Digital Input MOP

Selection

Binary Logic

Some references can be selected by binary logic, through digital inputs to the terminal block or bit manipulation of the Logic Command Word in a communications adapter. These sources are used when the drive is in "Auto" mode. The default reference is from the source selected in [Speed Ref A Sel], parameter 90. This parameter can be set to any one of the 22 choices. If the binary logic selection is zero, this will be the active speed reference.

Auto/Manual

Many applications require a "manual mode" where adjustments can be made and setup can be done by taking local control of the drive speed. Typically, these adjustments would be made via a "local" HIM mounted on the drive. When all setup is complete, control of the drive frequency command is turned over to automatic control from a remote source such as a PLC, analog input etc.

The source of the speed reference is switched to one of two "manual" sources when the drive is put into manual mode:

1. Local HIM
2. Analog Input to terminal block

If the selection is the HIM, then the digital or analog speed control on the HIM provides the reference.

If the switch to manual mode was made via a digital input, (parameters 361-366 set to "18, Auto/Manual") then the source for the reference is defined in [TB Man Ref Sel], parameter 96. This can be either of the 2 analog inputs or the digital MOP.

When the drive is returned to automatic mode, the speed reference returns to the source selected by the binary logic. Also see Auto/Manual on page 2-27.

DPI

See the DPI on page 2-83 for a description of DPI. One of the DPI ports can be selected as the source of the speed reference.

In the PowerFlex 70, 700, and 700VC the speed reference from DPI is scaled so that [Maximum Freq] = 32767. [Maximum Freq] is the largest **output** frequency that the drive will deliver to the motor.

Additionally, the PowerFlex 70 and 700 drives have a parameter called [Maximum Speed]. [Maximum Speed] limits the drive speed **reference**, such as from a communication network or analog input.

PowerFlex drives contain the following necessary rule:
[Maximum Speed] + [Overspeed Limit] = [Maximum Freq]

[Overspeed Limit] allows the drive to operate above [Maximum Speed] for certain functions such as bus regulation, current limit (during regeneration), PI control, and slip compensation. It is important that [Overspeed Limit] is set to allow enough headroom for the application. For example, let's assume we have an application where [Speed Mode] = "Slip Comp". Slip compensation adds some frequency to the commanded speed in order to compensate for slip in a loaded motor. In this case, [Overspeed Limit] should not be set to 0. Otherwise, if the drive is running with a commanded frequency of 60 Hz and the motor is loaded at all, slip compensation will add some frequency and we would get a nuisance "Overspeed" fault.

Defaults are as follows:

- [Maximum Speed] = 60 Hz
- [Overspeed Limit] = 10 Hz
- [Maximum Freq] = 130 Hz (this is default so that users who want to go twice base speed don't have to change it).

To send out a speed reference to the drive from a controller over RIO, you can perform the following calculation:

$$\text{SpeedRef} = \frac{\text{CommandFreq}}{\text{[Maximum Freq]}} \times 32767$$

For example, to send out a command frequency of 60 Hz on a PowerFlex 70 or 700 with default settings we would calculate the following:

$$\text{SpeedRef} = \frac{60\ \text{Hz}}{130\ \text{Hz}} \times 32767 = 15123$$

The following example illustrates how a change in P55 [Maximum Freq] in the PowerFlex 70 or 700 affects the speed reference scaling:

[Overspeed Limit] = 10 Hz (this is factory default)
[Maximum Speed] = 60 Hz (this is factory default).
[Maximum Freq] = [Maximum Speed] + [Overspeed Limit] = 60 Hz + 10 Hz = 70 Hz.

Using the above formula, calculate the Speed Reference sent from a network using a DPI adapter.

For example, to send out a command frequency of 60 Hz with [Maximum Freq] = 70 Hz, we would calculate the following:

$$\text{SpeedRef} = \frac{60\ \text{Hz}}{70\ \text{Hz}} \times 32767 = 28086$$

Jog

When the drive is not running, pressing the HIM Jog button or a programmed Jog digital input will cause the drive to jog at a separately programmed jog reference. This speed reference value is entered in [Jog Speed], parameter 100.

Figure 2.34 Speed Reference Selection



Scaling

Scaling applies only to references from analog inputs and reference sources selected in [Speed Ref x Sel], parameters 90/93.

Each analog input has its own set of scale parameters:

- [Analog In x Hi] sets the maximum level on input to be seen (i.e. 10 Volts).
- [Analog In x Lo] sets the minimum level on input to be seen (i.e. 0 Volts).

Each [Speed Ref x Sel] parameter has an additional set of scale parameters:

- [Speed Ref x Hi] selects the reference value for the maximum input specified in [Analog In x Hi].
- [Speed Ref x Lo] selects the reference value for the minimum input specified in [Analog In x Lo].

For example, if the following parameters are set:

[Analog In x Hi] = 10 V
[Analog In x Lo] = 0 V
[Speed Ref A Hi] = 45 Hz
[Speed Ref x Lo] = 5 Hz

then the speed command for the drive will be linearly scaled between 45 Hz at maximum analog signal and 5 Hz at minimum analog signal. See additional examples under Analog Inputs on page 2-12.

Polarity

The reference can be selected as either unipolar or bipolar. Unipolar is limited to positive values and supplies only the speed reference. Bipolar supplies both the speed reference AND the direction command: + signals = forward direction and – signals = reverse direction.

Trim

If the speed reference is coming from the source specified in [Speed Ref A Sel] or [Speed Ref B Sel], the a trim signal can be applied to adjust the speed reference by a programmable amount. The source of the trim signal is made via [Trim In Sel], parameter 117 and can be any of the sources that are also used as references. [Trim Out Select], parameter 118 selects which of the references, A/B will be trimmed.

If the trim source is an analog input, two additional scale parameters are provide to scale the trim signal.

Figure 2.35 Trim



Min/Max Speed

[Max Speed]

Maximum and minimum speed limits are applied to the reference. These limits apply to the positive and negative references. The minimum speed limits will create a band that the drive will not run continuously within, but will ramp through. This is due to the positive and negative minimum speeds. If the reference is positive and less than the positive minimum, it is set to the positive minimum. If the reference is negative and greater than negative minimum, it is set to the negative minimum. If the minimum is not 0, hysteresis is applied at 0 to prevent bouncing between positive and negative minimums. See below.



Maximum frequency

The maximum frequency defines the maximum reference frequency. The actual output frequency may be greater as a result of slip compensation and other types of regulation. This parameter also defines scaling for frequency reference. This is the frequency that corresponds to 32767 counts when the frequency reference is provided by a network.

Speed Regulator

Vector FV The drive takes the speed reference that is specified by the speed reference control loop and compares it to the speed feedback. The speed regulator uses proportional and integral gains to adjust the torque reference that is sent to the motor. This torque reference attempts to operate the motor at the specified speed. This regulator also produces a high bandwidth response to speed command and load changes.

Vector FV Integral Gain

The integral gain block outputs a torque command relative to the error integrated over a period of time.

[Ki Speed Loop] sets the integral gain of the speed regulator. Its value is automatically calculated based on the bandwidth setting in [Speed Desired BW]. Integral gain may be manually adjusted by setting [Speed Desired BW] to a value of zero. Units are (per unit torque/sec) / (per unit speed). For example, when [Ki Speed Loop] is 50 and the speed error is 1%, the integral output will integrate from 0 to 50% motor rated torque in 1 second.

Vector FV Proportional Gain

The proportional gain determines how much of a speed error occurs during a load transient.

[Kp Speed Loop] sets the proportional gain of the speed regulator. Its value is automatically calculated based on the bandwidth setting in [Speed Desired BW]. Proportional gain may be manually adjusted by setting [Speed Desired BW] to a value of zero. Units are (per unit torque) / (per unit speed). For example, when [Kp Speed Loop] is 20, the proportional gain block will output 20% motor rated torque for every 1% error of motor rated speed.

Vector FV Feed Forward Gain

The first section of the PI regulator is the feed forward block. [Kf Speed Loop] allows the speed regulator to be dampened during speed changes. To reduce speed overshoot, reduce the value of [Kf Speed Loop]. During auto-tune, the feed forward is left open (no dampening).

Vector FV Speed Desired BW

[Speed Desired BW] sets the speed loop bandwidth and determines the dynamic behavior of the speed loop. As bandwidth increases, the speed loop becomes more responsive and can track a faster changing speed reference. Adjusting this parameter will cause the drive to calculate and change [Ki Speed Loop] and [Kp Speed Loop] gains.

Vector FV Total Inertia

[Total Inertia] represents the time in seconds, for a motor coupled to a load to accelerate from zero to base speed, at rated motor torque. The drive calculates Total Inertia during the autotune inertia procedure. Adjusting this parameter will cause the drive to calculate and change [Ki Speed Loop] and [Kp Speed Loop] gains.

Speed/Torque Select

Vector FV [Speed/Torque Mod] is used to choose the operating mode for the drive. The drive can be programmed to operate as a velocity regulator, a torque regulator, or a combination of the two. Refer to 2.36.

Figure 2.36



As shown, [Speed/Torque Mod] (parameter 88) is used to select the mode of operation. Zero torque current is allowed when set to "0."

When set to a "1," the drive/motor is operated in speed mode. The torque command changes as needed to maintain the desired speed.

A value of "2" selects torque mode. In torque regulation mode, the drive controls the desired motor torque. The motor speed will be a result of the torque command and load present at the motor shaft.

Min and Max mode are selected by values 3 and 4, respectively. These two modes offer a combination of speed and torque operation. The algebraic minimum or maximum of speed/torque will be the operating point for the Min and Max modes. The drive will automatically switch from speed to torque mode (or from torque to speed) based on the dynamics of the motor/load.

The Min mode is typically used with positive torque and forward speed operation, the minimum of the two being closest to zero. The Max mode is opposite, typically used with reverse speed and negative torque, the maximum being the least negative (closest to zero).

Sum mode is selected when set to "5." This mode allows an external torque command to be added to the speed regulator output when desired.

Speed Regulation Mode

Operating as a speed regulator is the most common and therefore simplest mode to setup. Examples of speed regulated applications are blowers, conveyors, feeders, pumps, saws, and tools.

In a speed regulated application, the torque reference is generated by the speed regulator output. Note that under steady state conditions the speed feedback is steady while the torque reference is a constantly adjusting signal. This is required to maintain the desired speed. At transient state, the torque reference will change dramatically to compensate for a speed change. A short duration change in speed is the result of increasing or decreasing the load very rapidly.

Torque Regulation Mode

A torque regulated application can be described as any process that requires some tension control. An example of this is a winder or unwind where material is being “drawn” or pulled with a specific tension required. The process requires another element setting the speed. Configuring the drive for torque regulation requires [Speed/Torque Mod] to be set to “2.” In addition, a reference signal must be selected (Torque Ref A or Torque Ref B). If an analog signal is used for the reference, select that from the Torque Ref A or Torque Ref B selections.

When operating in a torque mode, the motor current will be adjusted to achieve the desired torque. If the material being wound/unwound breaks, the load will decrease dramatically and the motor can potentially go into a “runaway” condition.

Figure 2.37



Torque Reference:

[Torque Ref A Sel], parameter 427 is scaled by [Torque Ref A Hi] and [Torque Ref A Lo]. Then divided by [Torq Ref A Div].

[Torque Ref B Sel], parameter 431 is scaled by [Torque Ref B Hi] and [Torque Ref B Lo]. Then multiplied by [Torq Ref B Mult].

The final torque reference, in the Torque Mode, is the sum of scaled Torque Ref A and scaled Torque Ref B.

Min Mode/Max Mode

This operating mode compares the speed and torque commands. The algebraically minimum value is used. This mode can be thought of as a Speed Limited Adjustable Torque operation. Instead of operating the drive as a pure torque regulator, the “runaway” condition can be avoided by limiting the speed. A winder is a good example for the application of the Min Spd/Trq operating mode. Max mode would be used if both speed and torque are negative.

Figure 2.38 illustrates how min mode operates. The drive starts out operating as a torque regulator. The torque reference causes the motor to operate at 308rpm. The speed reference is 468rpm, so the minimum is to operate as a torque regulator. While operating in torque regulation, the load decreases and the motor speeds up. Notice the torque command has not changed. When the speed regulator comes out of saturation, it clamps the speed and now the drive operates as a speed regulator. The At Speed Relay then closes.

Figure 2.38



Sum Mode

Configuring the drive in this mode allows an external torque input to be summed with the torque command generated by the speed regulator. The drive requires both a speed reference and a torque reference to be linked. This mode can be used for applications that have precise speed changes with critical time constraints. If the torque requirement and timing is known for a given speed change, then the external torque input can be used to preload the integrator. The timing of the speed change and the application of an external torque command change must be coordinated for this mode to be useful. The sum mode will then work as a feed forward to the torque regulator.

Zero Torque Mode

Operation in zero torque mode allows the motor to be fully fluxed and ready to rotate when a speed command or torque command is given. For a cyclical application where through put is a high priority this mode can be used. The control logic can select zero torque during the “rest” portion of a machine cycle instead of stopping the drive. When the cycle start occurs, instead of issuing a start to the drive, a speed regulate mode can be selected. The drive will then immediately accelerate the motor without the need for “flux up” time.

Important: Zero Torque may excessively heat the motor if operated in this mode for extended periods of time. No load or flux current is still present when the drive is operating in zero torque mode. A motor with an extended speed range or separate cooling methods (blower) may be required.

Speed Units

Vector [Speed Units] selects the units to be used for all speed related parameters. The options for [Speed Units] are:

- “Hz” – converts status parameters only to Hz.
- “RPM” – converts status parameters only to RPM.
- “Convert Hz” - converts all speed based parameters to Hz, and changes the value proportionately (i.e. 1800 RPM = 60 Hz).
- “Convert RPM” - converts all speed based parameters to RPM, and changes the value proportionately.

Start Inhibits

The [Start Inhibits] parameter indicates the inverted state of all start permissive conditions. If the bit is on (HI or 1), the corresponding permissive requirement has not been met and the drive is inhibited from starting. It will be updated continually, not only when a start attempt is made. See also Start Permissives on page 2-180.

Start Permissives

Start permissives are conditions required to permit the drive to start in any mode – run, jog, auto-tune, etc. When all permissive conditions are met the drive is considered *read*y to start. The ready condition is available as the *drive ready* status.

Permissive Conditions

1. No faults can be active.
2. No type2 alarms can be active.
3. The TB Enable input (if configured) must be closed.
4. The DC bus precharge logic must indicate it is a start permissive.
5. All Stop inputs must be negated (See special Digital Inputs Stops Configuration issues below).
6. No configuration changes (parameters being modified) can be in-progress.

If all permissive conditions are met, a valid start, run or jog command will start the drive. The status of all inhibit conditions, except for item 6 above, are reflected in the output parameter Start Inhibits. The configuration change condition is a transient (short-term) condition and not directly user controlled. It is therefore not reflected in the Start Inhibits parameter.

Note that the Start Inhibits conditions do not include any of the functionality imposed by the DPI logic such as owners, masks, local control, etc.

Start-Up

Start-Up Routines

PowerFlex drives offer a variety of Start Up routines to help the user commission the drive in the easiest manner and the quickest possible time. PowerFlex 70 Drives have the S.M.A.R.T Start routine and a Basic assisted routine for more complex setups. PowerFlex 700 drives have both of the above plus an advanced startup routine.

S.M.A.R.T. Start

During a Start Up, the majority of applications require changes to only a few parameters. The LCD HIM on a PowerFlex 70 drive offers S.M.A.R.T. start, which displays the most commonly changed parameters. With these parameters, you can set the following functions:

S - Start Mode and Stop Mode
M - Minimum and Maximum Speed
A - Accel Time 1 and Decel Time 1
R - Reference Source
T - Thermal Motor Overload

To run a S.M.A.R.T. start routine:

Step	Key(s)	Example LCD Displays
1. Press ALT and then Esc (S.M.A.R.T). The S.M.A.R.T. start screen appears. 2. View and change parameter values as desired. For HIM information, see Appendix B. 3. Press ALT and then Sel (Exit) to exit the S.M.A.R.T. start.	ALT Esc ALT Sel	S.M.A.R.T. List Start Mode Stop Mode Minimum Speed

Basic Start Up

The Basic Start Up routine leads the user through the necessary information in a simple question and answer format. The user can make the choice to execute or skip any section of the routine. Below is a complete flow chart of the routine.

Figure 2.39 PowerFlex 70 & 700 Standard Control Option Startup



Figure 2.39 PowerFlex 70 & 700 Standard Control Option Startup (1)



Figure 2.39 PowerFlex 70 & 700 Standard Control Option Startup (2)



Figure 2.39 PowerFlex 70 & 700 Standard Control Option Startup (3)



Figure 2.39 PowerFlex 70 & 700 Standard Control Option Startup (4)



Figure 2.39 PowerFlex 70 & 700 Standard Control Option Startup (5)



Figure 2.39 PowerFlex 70 & 700 Standard Control Option Startup (6)



Figure 2.39 PowerFlex 70 & 700 Standard Control Option Startup (7)

Basic Start Up (Start,Stop,I/O [2])



Figure 2.40 PowerFlex 700 Vector Control Option Startup



Figure 2.40 PowerFlex 700 Vector Control Option Startup (1)



Figure 2.40 PowerFlex 700 Vector Control Option Startup (2)



Note:
- For V/Hz mode, only states 2-0 thru 2-6 & 2-14 are displayed.
- For V/Hz mode, configure Stop Mode A as Coast to Stop.
- Going from state 2-7 to 2-10 directly sets the DC Brake Level/Time parameters to their default value.

Figure 2.40 PowerFlex 700 Vector Control Option Startup (3)



Figure 2.40 PowerFlex 700 Vector Control Option Startup (4)



Figure 2.40 PowerFlex 700 Vector Control Option Startup (5)



Figure 2.40 PowerFlex 700 Vector Control Option Startup (6)



Note:
- For V/Hz mode, states 6-3 - 6-5, & 6-11 - 6-16 are not displayed.

Figure 2.40 PowerFlex 700 Vector Control Option Startup (7)



Figure 2.40 PowerFlex 700 Vector Control Option Startup (8)



Figure 2.40 PowerFlex 700 Vector Control Option Startup (9)



Figure 2.40 PowerFlex 700 Vector Control Option Startup (10)



Stop Modes

[Stop Mode A, B]
[DC Brake Lvl Sel]
[DC Brake Level]
[DC Brake Time]

1. **Coast to Stop** - When in Coast to Stop, the drive acknowledges the Stop command by shutting off the output transistors and releasing control of the motor. The load/motor will coast or free spin until the mechanical energy is dissipated.



2. **Dynamic Braking** is explained in detail in the PowerFlex Dynamic Braking Selection Guide, presented in Appendix A.

3. **DC Brake** is selected by setting [Stop Mode A] to a value of "3." The user can also select the amount of time the braking will be applied and the magnitude of the current used for braking with [DC Brake Time] and [DC Brake Level]. This mode of braking will generate up to 40% of rated motor torque for braking and is typically used for low inertia loads.

   When in Brake to Stop, the drive acknowledges the Stop command by immediately stopping the output and then applying a programmable DC voltage [DC Brake Level] to 1 phase of the motor.

   The voltage is applied for the time programmed in [DC Brake Time]. After this time has expired, all output ceases. If the load is not stopped, it will continue to coast until all energy is depleted (A on the diagram below). If the time programmed exceeds the needed time to stop, the drive will continue to apply the DC hold voltage to the non-rotating motor (B on the diagram below). Excess motor current could cause motor damage. The user is also cautioned that motor voltage can exist long after the Stop command is issued. The right combination of Brake Level and Brake Time must be determined to provide the safest, most efficient stop (C on the diagram below).



4. **Ramp To Stop** is selected by setting [Stop Mode x]. The drive will ramp the frequency to zero based on the deceleration time programmed into [Decel Time 1/2]. The “normal” mode of machine operation can utilize [Decel Time 1]. If the “Machine Stop” mode requires a faster deceleration than desired for normal mode, the “Machine Stop” can activate [Decel Time 2] with a faster rate selected. When in Ramp to Stop, the drive acknowledges the Stop command by decreasing or “ramping” the output voltage and frequency to zero in a programmed period (Decel Time), maintaining control of the motor until the drive output reaches zero. The output transistors are then shut off.

   The load/motor should follow the decel ramp. Other factors such as bus regulation and current limit can alter the decel time and modify the ramp function.

   Ramp mode can also include a “timed” hold brake. Once the drive has reached zero output hertz on a Ramp-to-Stop and both parameters [DC Hold Time] and [DC Hold Level] are not zero, the drive applies DC to the motor producing current at the DC Hold Level for the DC Hold Time.



   Motor speed during and after the application of DC depends upon the combination of the these two parameter settings, and the mechanical system. The drive output voltage will be zero when the hold time is finished.

   The level and uniformity of the DC braking offered at zero speed may not be suitably smooth for many applications. If this is an application requirement, a vector control drive, motion control drive or mechanical brake should be used.

   The drive output voltage will be zero when the hold time is finished

5. **Ramp To Hold** is selected by setting [Stop Select x]. The drive will ramp the frequency to zero based on the deceleration time programmed into [Decel Time 1/2]. Once the drive reaches zero hertz, a DC Injection holding current is applied to the motor. The level of current is set in [DC Brake Level].

   In this mode, the braking is applied Continuously. [DC Hold Time] has no effect in this mode. Braking will continue until one of the following events occur:

   – The Enable Input is opened, or . . .
   – A Start command is re-issued.

   Again, caution must be exercised to not overheat the motor by applying excess voltage and/or for excess time, particularly if the motor is not rotating.



Test Points

UTILITY (File E)	Diagnostics	234 236	**[Testpoint 1 Sel]** **[Testpoint 2 Sel]** Selects the function whose value is displayed value in [Testpoint x Data]. These are internal values that are not accessible through parameters. See Testpoint Codes and Functions on page 4-10 for a listing of available codes and functions.	Default: 499 Min/Max: 0/999 Display: 1	
		235 237 32	**[Testpoint 1 Data]** **[Testpoint 2 Data]** The present value of the function selected in [Testpoint x Sel].	Default: Read Only Min/Max: 0/65535 Display: 1	

Table 2.AB Testpoint Codes and Functions

Code Selected in [Testpoint x Sel]	Function Whose Value is Displayed in [Testpoint x Data]
0	DPI Error Status
1	Heatsink Temperature
2	Active Current Limit
3	Active PWM Frequency
4	Lifetime MegaWatt Hours
5	Lifetime Run Time
6	Lifetime Powered Up Time
7	Lifetime Power Cycles
8-99	Reserved for Factory Use

Thermal Regulator

See Drive Overload on page 2-86.

Torque Limits

Vector FV The bus regulator, when enabled, generates a regenerative power limit to prevent the DC bus voltage from rising. The maximum (value closest to zero) of the bus regulator regen power limit and [Regen Power Limit] is converted into a positive and negative torque limit. The positive limit is used when the motor is regenerating in the reverse direction. The negative limit is used when the motor is motoring in the reverse direction. Finally, the drive's torque reference is limited by the minimum (value closest to zero) of the positive torque limit from the power limit section and [Pos Torque Limit]. The drive's torque reference is also limited by the maximum (value closest to zero) of the negative torque limit from the power limit section and [Neg Torque Limit].



Torque Performance Modes

[Torque Perf Mode] or [Motor Cntl Sel] (Vector) selects the output mode of the drive. The choices are:

- Custom Volts/Hertz
  Used in multi-motor or synchronous motor applications.
- Fan/Pump Volts/Hertz
  Used for centrifugal fan/pump (variable torque) installations for additional energy savings.
- Sensorless Vector
  Used for most general constant torque applications. Provides excellent starting, acceleration and running torque.
- Sensorless Vector w/Economizer
  Used in constant torque applications that have significant “idle” time (time spent at greatly reduced load) to offer additional energy conservation.

The following table shows the performance differences between V/Hz and Sensorless Vector.

Torque Mode	Fan/Pump and Custom V/Hz with Slip Comp	SVC with Slip Comp	SVC with Feedback	Flux Vector without Feedback	Flux Vector with Feedback
Speed Regulation (% of base speed)	0.5%	0.5%	0.1%	0.1%	0.001%
Operating Speed Range	40:1	80:1	80:1	120:1	1000:1
Speed Bandwidth	10 rad/sec	20 rad/sec	20 rad/sec	50 rad/sec	250 rad/sec

Volts/Hertz

Volts/Hertz operation creates a fixed relationship between output voltage and output frequency. The relationship can be defined in two ways.

1. Fan/Pump
   When this option is chosen, the relationship is $1/X^2$. Therefore; for full frequency, full voltage is supplied and for ½1/2 rated frequency, 1/4 voltage is applied, etc. This pattern closely matches the torque requirement of a variable torque load (centrifugal fan or pump – load increases as speed increases) and offers the best energy savings for these applications.



2. Custom
   Custom Volts/Hertz allows a wide variety of patterns using linear segments. The default configuration is a straight line from zero to rated voltage and frequency. This is the same volts/hertz ratio that the motor

would see if it were started across the line. As seen in the diagram below, the volts/hertz ratio can be changed to provide increased torque performance when required. The shaping takes place by programming 5 distinct points on the curve:

– **Start Boost** - Used to create additional torque for breakaway from zero speed and acceleration of heavy loads at lower speeds
– **Run Boost** - Used to create additional running torque at low speeds. The value is typically less than the required acceleration torque. The drive will lower the boost voltage to this level when running at low speeds (not accelerating). This reduces excess motor heating that could be caused if the higher start / accel boost level were used.
– **Break Voltage/Frequency** - Used to increase the slope of the lower portion of the Volts / hertz curve, providing additional torque.
– **Motor Nameplate Voltage/Frequency** - sets the upper portion of the curve to match the motor design. Marks the beginning of the constant horsepower region
– **Maximum Voltage/Frequency** - Slopes that portion of the curve used above base speed.



Sensorless Vector

Sensorless Vector technology consists of a basic V/Hz core surrounded by excellent current resolution (the ability to differentiate flux producing current from torque producing current), a slip estimator, a high performance current limiter (or regulator) and the vector algorithms.



The algorithms operate on the knowledge that motor current is the vector sum of the torque and flux producing components. Values can be entered to identify the motor values or an autotune routine can be run to interrogate and identify the motor values (see Autotune on page 2-31). Early versions required feedback, but today, performance is sensorless. It offers high breakaway torque, exceptional running torque, a wider speed range than V/Hz, higher dynamic response and a fast accel “feed forward” selectable for low inertia loads (adaptive current limit).

Sensorless vector is not a torque regulating technology. It does NOT independently control the flux and torque producing currents. Therefore, it cannot be used to regulate torque (torque follower).

In sensorless vector control, the drive maintains a constant flux current up to base speed, allowing the balance of the drive available current to develop maximum motor torque. By manipulating output voltage as a function of load, excellent motor torque can be generated.



Vector FV Flux Vector Control

The drive takes the speed reference that is specified by the Speed Reference Selection Block and compares it to the speed feedback. The speed regulator uses Proportional and Integral gains to adjust the torque reference for the motor. This torque reference attempts to operate the motor at the specified speed. The torque reference is then converted to the torque producing component of the motor current. This type of speed regulator produces a high bandwidth response to speed command and load changes.

In flux vector control, the flux and torque producing currents are indepently controlled. Therefore, we can send a torque reference directly instead of a speed reference. The independent flux control also allows us to reduce the flux in order to run above base motor speed.

Figure 2.41 Flux Vector



Torque Reference

Vector FV When the PowerFlex 700 Vector Control drive is operated in Torque mode, an external signal is used for a Torque reference. Refer to Figure 2.42.

Figure 2.42



Torque Reference Input

[Torque Ref A], parameter 427 is used to supply an external reference for how much torque is desired. The scaling of this parameter is from –800 to +800, via [Torq Ref A Hi] and [Torq Ref A Lo].

Torque Ref 1 is then divided by [Torq Ref A Div], parameter 430. This defines the scaled Torque Ref A.

[Torque Ref B], parameter 431 is used to supply an external reference for how much torque is desired. The scaling of this parameter is from –800 to +800, via [Torq Ref B Hi] and [Torq Ref B Lo].

The Torque Ref B is then multiplied by [Torq Ref B Mul], parameter 434. This defines the scaled Torque Ref B.

Once the scaling is complete on both Torque Ref A and Torque Ref B, the output is summed to create the external torque reference

This can be utilized when a master/slave multi-drive system is configured. The torque reference into the “slave” can be scaled to create the proper torque output. Keep in mind that the motors may be different ratings and this function is used to help the “system” share the load.

PowerFlex 700 Firmware 3.001 (& later) Enhancements

Extra selections have been added to [Torque Ref A Sel] and [Torque Ref B Sel] in firmware version 3.001 (and later) for the PowerFlex 700 Vector Control drive:

- Scale Block Output available as a selection
- Torque Setpoint 2 is new and available as a selection

		427 431	Vector **[Torque Ref A Sel]** Vector **[Torque Ref B Sel]**	Default:	1 1	“Torque Setpt” “Disabled”	053
			Selects the source of the external torque reference to the drive. How this reference is used is dependent upon [Speed/ Torque Mod]. (1) See *User Manual* for DPI port locations. (2) Vector firmware 3.001 and later.	Options:	0 1 2 3-17 18-22 23 24 25-28 29	“Torque Setpt” “Torque Stpt1”(2) “Analog In 1” “Analog In 2” “Reserved” “DPI Port 1-5”(1) “Reserved” “Disabled” “Scale Block1-4”(2) “Torque Stpt2”(2)	

		438	Vector v3 **[Torque Setpoint2]**	Default:	0.0%		
			Provides an internal fixed value for Torque Setpoint when [Torque Ref Sel] is set to “Torque Setpt 2.”	Min/Max: Units:	–/+800.0% 0.1%		

Troubleshooting

See Faults on page 2-93 and Advanced Tuning on page 2-2.

Unbalanced or Ungrounded Distribution Systems

Refer to *"Wiring and Grounding Guidelines for Pulse Width Modulated (PWM) AC Drives*," publication DRIVES-IN001 for detailed information on Unbalanced or Ungrounded Distribution Systems.

User Sets

After a drive has been configured for a given application the user can store a copy of all of the parameter settings in a specific EEPROM area known as a "User Set." Up to 3 User Sets can be stored in the drives memory to be used for backup, batch "switching" or other needs. All parameter information is stored. The user can then recall this data to the active drive operating memory as needed. Each User Set can also be identified with a programmable name, selected by the user for clarity.

Two operations are available to manage User Sets, "Save To User Set" and "Restore From User Set." The user selects 1, 2, or 3 as the area in which to store data. After data is successfully transferred, "Save User Set" returns to a value of 0. To copy a given area back into the active EEprom memory, the user selects Set 1, 2, or 3 for "Restore User Set." After data is successfully transferred, "Restore User Set" returns to a value of 0. When shipped from the factory all user sets have the same factory default values. Reset Defaults does not effect the contents of User Sets.

Important: User Sets can only be transferred via the HIM. No provisions exist for control via digital I/O or communications module.

Figure 2.43 User Sets



Voltage Class

PowerFlex drives are sometimes referred to by voltage “class.” This class identifies the general input voltage to the drive. This general voltage includes a range of actual voltages. For example, a 400 Volt Class drive will have an input voltage range of 380-480VAC. While the hardware remains the same for each class, other variables, such as factory defaults, catalog number and power unit ratings will change. In most cases, all drives within a voltage class can be reprogrammed to another drive in the class by resetting the defaults to something other than “factory” settings. The [Voltage Class] parameter can be used to reset a drive to a different setup within the voltage class.

As an example, consider a 480 volt drive. This drive comes with factory default values for 480V, 60 Hz with motor data defaulted for U.S. motors (HP rated, 1750 RPM, etc.) By setting the [Voltage Class] parameter to “low Voltage” (this represents 400V in this case) the defaults are changed to 400V, 50 Hz settings with motor data for European motors (kW rated, 1500 RPM, etc.). Refer to Figure 2.43.

Voltage Tolerance

Drive Rating	Nominal Line Voltage	Nominal Motor Voltage	Drive Full Power Range	Drive Operating Range
200-240	200	200*	200-264	180-264
	208	208	208-264	
	240	230	230-264	
380-400	380	380*	380-528	342-528
	400	400	400-528	
	480	460	460-528	
500-600 *(Frames 0-4 Only)*	600	575*	575-660	432-660
500-690 *(Frames 5-6 Only)*	600	575*	575-660	475-759
	690	690	690-759	475-759

Drive Full Power Range =	Nominal Motor Voltage to Drive Rated Voltage +10%. Rated power is available across the entire Drive Full Power Range.
Drive Operating Range =	Lowest (*) Nominal Motor Voltage –10% to Drive Rated Voltage +10%. Drive Output is linearly derated when Actual Line Voltage is less than the Nominal Motor Voltage.



Example:

Calculate the maximum power of a 5 HP, 460V motor connected to a 480V rated drive supplied with 342V Actual Line Voltage input.

- Actual Line Voltage / Nominal Motor Voltage = 74.3%
- 74.3% × 5 HP = 3.7 HP
- 74.3% × 60 Hz = 44.6 Hz

At 342V Actual Line Voltage, the maximum power the 5 HP, 460V motor can produce is 3.7 HP at 44.6 Hz.



Watts Loss

The following table lists watts loss data for PowerFlex drives running at full load, full speed and a factory default PWM Frequency of 4 kHz.

PowerFlex 70

For PowerFlex 70 drives, Internal Watts are those dissipated by the control structure of the drive and will be dissipated into the cabinet regardless of mounting style. External Watts are those dissipated directly through the heatsink and will be outside the cabinet for flange mount and inside the cabinet for panel mount.

Table 2.AC PowerFlex 70 Watts Loss at Full Load/Speed, 4kHz(1)

Voltage	ND HP	External Watts	Internal Watts	Total Watts Loss
480	0.5	11.5	17.9	29.4
	1	27.8	19.5	47.3
	2	43.6	21.6	65.2
	3	64.6	24.0	88.6
	5	99.5	28.2	127.7
	7.5	140.0	27.8	167.8
	10	193.3	32.0	225.3
	15	305.4	34.2	339.6
	20	432.9	42.9	475.8
240V	0.5	12.2	19.2	31.4
	1	30.7	20.5	51.2
	2	44.6	22.6	67.2
	3	67.3	25.4	92.7
	5	141.3	33.2	174.5
	7.5	205.7	34.2	239.9
	10	270.4	48.1	318.5

(1) Includes HIM.

PowerFlex 700

PowerFlex 700 drives are offered in panel mount versions only. At this time, no method exists for venting outside of a secondary enclosure. This requires enclosure sizing for total watts. see Table 2.AD.

Table 2.AD PowerFlex 700 Watts Loss (Rated Load, Speed & PWM)(2)

Voltage	ND HP	External Watts	Internal Watts	Total Watts Loss
240V	0.5	9	37	46
	1	22	39	61
	2	38	39	77
	3	57	41	98
	5	97	82	179
	7.5	134	74	208
	10	192	77	269
	15	276	92	368
	20	354	82	436
	25	602	96	698
	30	780	96	876
	40	860	107	967
	50	1132	138	1270
	60	1296	200	1496
	75	1716	277	1993
	100	1837	418	2255

Voltage	ND HP	External Watts	Internal Watts	Total Watts Loss
480V	0.5	11	42	53
	1	19	44	63
	2	31	45	76
	3	46	46	93
	5	78	87	164
	7.5	115	79	194
	10	134	84	218
	15	226	99	326
	20	303	91	394
	25	339	102	441
	30	357	103	459
	40	492	117	610
	50	568	148	717
	60	722	207	930
	75	821	286	1107
	100	1130	397	1479
	125	1402	443	1845
	150	1711	493	2204
	200	1930	583	2512
600V	0.5	9	37	46
	1	14	40	54
	2	25	40	65
	3	41	42	83
	5	59	83	142
	7.5	83	75	157
	10	109	77	186
	15	177	93	270
	20	260	83	343
	25	291	95	385
	30	324	95	419
	40	459	109	569
	50	569	141	710
	60	630	195	825
	75	1053	308	1361
	100	1467	407	1874
	125	1400	500	1900
	150	1668	612	2280

(2) Worst case condition including Vector Control board, HIM and Communication Module

Dynamic Brake Selection Guide

The Dynamic Braking Selection Guide provided on the following pages contains detailed information on selecting and using dynamic brakes.

Allen-Bradley

PowerFlex

Dynamic Braking Resistor Calculator

Selection Guide

Rockwell Automation

Allen-Bradley

PowerFlex®

Dynamic Braking Resistor Calculator

Rockwell Automation

Important User Information

Solid state equipment has operational characteristics differing from those of electromechanical equipment. "*Safety Guidelines for the Application, Installation and Maintenance of Solid State Controls*" (Publication SGI-1.1 available from your local Rockwell Automation Sales Office or online at **http://www.ab.com/manuals/gi**) describes some important differences between solid state equipment and hard-wired electromechanical devices. Because of this difference, and also because of the wide variety of uses for solid state equipment, all persons responsible for applying this equipment must satisfy themselves that each intended application of this equipment is acceptable.

In no event will the Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, the Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of the Rockwell Automation, Inc. is prohibited.

Throughout this manual we use notes to make you aware of safety considerations.

ATTENTION: Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss.

Attentions help you:

- identify a hazard
- avoid the hazard
- recognize the consequences

Important: Identifies information that is especially important for successful application and understanding of the product.

Shock Hazard labels may be located on or inside the drive to alert people that dangerous voltage may be present.

DriveExplorer, DriveTools32, and SCANport are trademarks of Rockwell Automation.
PLC is a registered trademark of Rockwell Automation.
ControlNet is a trademark of ControlNet International, Ltd.
DeviceNet is a trademark of the Open DeviceNet Vendor Association.

Table of Contents

Section 1 **Understanding How Dynamic Braking Works**
This section provides an overview of the components required to do Dynamic Braking and their functionality.

How Dynamic Braking Works 1-1
Dynamic Brake Components 1-2

Section 2 **Determining Dynamic Brake Requirements**
This section steps you through the calculations necessary to determine the amount of Dynamic Braking required for your application.

How to Determine Dynamic Brake Requirements 2-1
Determine Values of Equation Variables 2-4
Example Calculation 2-9

Section 3 **Evaluating the Internal Resistor**
This section steps you through the process to determine whether or not the available PowerFlex internal resistors are adequate for your application.

Evaluating the Capability of the
Internal Dynamic Brake Resistor 3-1
PowerFlex 70 Power Curves 3-4
PowerFlex 700 Power Curves 3-8

Section 4 **Selecting An External Resistor**
This section steps you through the process of selecting an external resistor when the internal resistors prove to be insufficient for your application.

How to Select an External Dynamic Brake Resistor 4-1

Appendix A

Understanding How Dynamic Braking Works

How Dynamic Braking Works

When an induction motor's rotor is turning slower than the synchronous speed set by the drive's output power, the motor is transforming electrical energy obtained from the drive into mechanical energy available at the drive shaft of the motor. This process is referred to as *motoring*. When the rotor is turning faster than the synchronous speed set by the drive's output power, the motor is transforming mechanical energy available at the drive shaft of the motor into electrical energy that can be transferred back to the drive. This process is referred to as *regeneration*.

Most AC PWM drives convert AC power from the fixed frequency utility grid into DC power by means of a diode rectifier bridge or controlled SCR bridge before it is inverted into variable frequency AC power. Diode and SCR bridges are cost effective, but can only handle power in the motoring direction. Therefore, if the motor is regenerating, the bridge cannot conduct the necessary negative DC current, the DC bus voltage will increase and cause an overvoltage fault at the drive. More complex bridge configurations use SCRs or transistors that can transform DC regenerative electrical power into fixed frequency utility electrical energy. This process is known as *line regeneration*.

A more cost effective solution can be provided by allowing the drive to feed the regenerated electrical power to a resistor which transforms it into thermal energy. This process is referred to as *dynamic braking*.

Dynamic Brake Components

A Dynamic Brake consists of a Chopper (the chopper transistor and related control components are built into PowerFlex drives) and a Dynamic Brake Resistor.

Figure 1.1 shows a simplified Dynamic Braking schematic.

Figure 1.1 Simplified Dynamic Brake Schematic



Chopper

The **Chopper** is the Dynamic Braking circuitry that senses rising DC bus voltage and shunts the excess energy to the Dynamic Brake Resistor. A Chopper contains three significant power components:

The **Chopper Transistor** is an Isolated Gate Bipolar Transistor (IGBT). The Chopper Transistor is either ON or OFF, connecting the Dynamic Brake Resistor to the DC bus and dissipating power, or isolating the resistor from the DC bus. The most important rating is the collector current rating of the Chopper Transistor that helps to determine the minimum resistance value used for the Dynamic Brake Resistor.

Chopper Transistor Voltage Control regulates the voltage of the DC bus during regeneration. The average values of DC bus voltages are:

Drive Input Voltage	Transistor Turn-On Voltage	Maximum Power Calculation Voltage
208	375V DC	395V DC
240	375V DC	395V DC
400	750V DC	790V DC
480	750V DC	790V DC
575	937.5V DC	987V DC
600	937.5V DC	987V DC
600 (Frame 5 & 6)	1076V DC	1135V DC
690	1076V DC	1135V DC

Voltage dividers reduce the DC bus voltage to a value that is usable in signal circuit isolation and control. The DC bus feedback voltage from the voltage dividers is compared to a reference voltage to actuate the Chopper Transistor.

The **Freewheel Diode** (FWD), in parallel with the Dynamic Brake Resistor, allows any magnetic energy stored in the parasitic inductance of that circuit to be safely dissipated during turn off of the Chopper Transistor.

Resistor

The **Resistor** dissipates the regenerated energy in the form of heat. The PowerFlex Family of Drives can use either the internal dynamic brake resistor option or an externally mounted dynamic brake resistor wired to the drive.

Wiring

Frames 0-4
Wire to the DB resistor should be no longer than 10 feet from the drive terminals. Wire should be twisted to minimize inductance.

Frames 5-6
Wire to the DB resistor should be no longer than 100 feet from the drive terminals.

Notes:

Determining Dynamic Brake Requirements

How to Determine Dynamic Brake Requirements

When a drive is consistently operating in the regenerative mode of operation, serious consideration should be given to equipment that will transform the electrical energy back to the fixed frequency utility grid.

As a general rule, Dynamic Braking can be used when the need to dissipate regenerative energy is on an occasional or periodic basis. In general, the motor power rating, speed, torque, and details regarding the regenerative mode of operation will be needed in order to estimate what Dynamic Brake Resistor value is needed.

The **Peak Regenerative Power** and **Average Regenerative Power** required for the application must be calculated in order to determine the resistor needed for the application. Once these values are determined, the resistors can be chosen. If an internal resistor is chosen, the resistor must be capable of handling the regenerated power or the drive will trip. If an external resistor is chosen, in addition to the power capabilities, the resistance must also be less than the application maximum and greater than the drive minimum or the drive will trip.

The power rating of the Dynamic Brake Resistor is estimated by applying what is known about the drive's motoring and regenerating modes of operation. The **Average Power Dissipation** must be estimated and the power rating of the Dynamic Brake Resistor chosen to be greater than that average. If the Dynamic Brake Resistor has a large thermodynamic heat capacity, then the resistor element will be able to absorb a large amount of energy without the temperature of the resistor element exceeding the operational temperature rating. Thermal time constants in the order of 50 seconds and higher satisfy the criteria of large heat capacities for these applications. If a resistor has a small heat capacity (defined as thermal time constants less than 5 seconds) the temperature of the resistor element could exceed its maximum.

Peak Regenerative Power can be calculated as:

- Horsepower (English units)
- Watts (The International System of Units, SI)
- Per Unit System (pu) which is relative to a value

The final number must be in watts of power to estimate the resistance value of the Dynamic Brake Resistor. The following calculations are demonstrated in SI units.

Gather the Following Information

- Power rating from motor nameplate in watts, kilowatts, or horsepower
- Speed rating from motor nameplate in rpm or rps (radians per second)
- Required decel time (per Figure 2.1, $t_3 - t_2$). This time is a process requirement and must be within the capabilities of the drive programming.
- Motor inertia and load inertia in kg-m^2 or WK^2 in lb.-$ft.^2$
- Gear ratio (GR) if a gear is present between the motor and load
- Motor shaft speed, torque, and power profile of the drive application

Figure 2.1 shows typical application profiles for speed, torque and power. The examples are for cyclical application that is periodic over t_4 seconds. The following variables are defined for Figure 2.1:

$\omega(t)$ = Motor shaft speed in radians per second (rps) $\omega = \frac{2\pi N}{60}$

N = Motor shaft speed in Revolutions Per Minute (RPM)

T(t) = Motor shaft torque in Newton-meters
1.0 lb.-ft. = 1.355818 N-m

P(t) = Motor shaft power in watts
1.0 HP = 746 watts

ω_b = Rated angular rotational speed $\frac{Rad}{s}$

ω_o = Angular rotational speed less than ω_b (can equal 0) $\frac{Rad}{s}$

$-P_b$ = Motor shaft peak regenerative power in watts

Figure 2.1 Application Speed, Torque and Power Profiles



Determine Values of Equation Variables

Step 2 Total Inertia

$$J_T = J_m + (GR^2 \times J_L)$$

J_T = Total inertia reflected to the motor shaft (kg-m^2 or WK^2 in lb.-ft.^{2})

J_m = Motor inertia (kg-m^2 or WK^2 in lb.-ft.^{2})

GR = Gear ratio for any gear between motor and load (dimensionless)

$$GR = \frac{\text{Load Speed}}{\text{Motor Speed}}$$

If the gear ratio is 2:1 then $GR = \frac{1}{2} = 0.5$

J_L = Load inertia (kg-m^2 or WK^2 in lb.-ft.^{2})
1.0 lb.-ft.^{2} = 0.04214011 kg-m^2

Calculate Total Inertia:

J_T = [ ] + (×)

Record Total Inertia:

J_T =

Step 3 Peak Braking Power

$$P_b = \frac{J_T[\omega_b(\omega_b - \omega_o)]}{(t_3 - t_2)}$$

P_b = Peak braking power (watts)
1.0 HP = 746 watts

J_T = Total inertia reflected to the motor shaft (kg-m^2)

ω_b = Rated angular rotational speed $\frac{Rad}{s} = \frac{2\pi N_b}{60}$

ω_o = Angular rotational speed, less than rated speed down to zero $\frac{Rad}{s}$

N_b = Rated motor speed (RPM)

$t_3 - t_2$ = Deceleration time from ω_b to ω_o (seconds)

Calculate Peak Braking Power:

$$P_b = \frac{[\qquad\qquad] \times [\qquad\qquad] \times (\qquad\qquad - \qquad\qquad)}{(\qquad\qquad - \qquad\qquad)}$$

Record Peak Braking Power:

P_b =

Compare the peak braking power (P_b) to the drive rated regenerative power (P_{rg}). If the peak braking power is greater than the drive rated regenerative power, the decel time will have to be increased so that the drive does not enter current limit. Drive rated regenerative power (P_{rg}) is determined by:

$$P_{rg} = \frac{V^2}{R}$$

P_{rg} = Drive rated regenerative power

V = DC bus regulation voltage from Table A.A

R = Minimum brake resistance from Table A.A

$$P_{rg} = \frac{[\qquad\qquad]^2}{(\qquad\qquad)}$$

Record Rated Regenerative Power:

P_{rg} =

For the purposes of this document, it is assumed that the motor used in the application is capable of producing the required regenerative torque and power.

Step 4 Minimum Power Requirements for the Dynamic Brake Resistors

It is assumed that the application exhibits a periodic function of acceleration and deceleration. If $(t_3 - t_2)$ equals the time in seconds necessary for deceleration from rated speed to ω_o speed, and t_4 is the time in seconds before the process repeats itself, then the average duty cycle is $(t_3 - t_2)/t_4$. The power as a function of time is a linearly decreasing function from a value equal to the peak regenerative power to some lesser value after $(t_3 - t_2)$ seconds have elapsed. The average power regenerated over the interval of $(t_3 - t_2)$ seconds is: $\frac{P_b}{2} \times \frac{(\omega_b + \omega_o)}{\omega_b}$

P_{av} = Average dynamic brake resister dissipation (watts)

$t_3 - t_2$ = Deceleration time from ω_b to ω_o (seconds)

t_4 = Total cycle time or period of process (seconds)

P_b = Peak braking power (watts)

ω_b = Rated angular rotational speed $\frac{Rad}{s}$

ω_o = Angular rotational speed, less than rated speed down to zero $\frac{Rad}{s}$

The Average Power in watts regenerated over the period t_4 is:

$$P_{av} = \left[\frac{(t_3 - t_2)}{t_4}\right]\frac{P_b}{2}\left[\frac{(\omega_b + \omega_o)}{\omega_b}\right]$$

Calculate Average Power in watts regenerated over the period t_4:

$$P_{av} = \left[\frac{(\quad - \quad)}{[\quad]}\right] \times \frac{[\quad]}{2} \times \left[\frac{(\quad + \quad)}{[\quad]}\right]$$

Record Average Power in watts regenerated over the period t_4:

P_{av} =

Step 5 Percent Average Load of the Internal Dynamic Brake Resistor

Skip this calculation if an external dynamic brake resistor will be used.

$$AL = \frac{P_{av}}{P_{db}} \times 100$$

AL = Average load in percent of dynamic brake resistor.
Important: The value of AL should not exceed 100%.

P_{av} = Average dynamic brake resistor dissipation calculated in Step 4 (watts)

P_{db} = Steady state power dissipation capacity of dynamic brake resistors obtained from Table A.A (watts)

Calculate Percent Average Load of the dynamic brake resistor:

$$AL = \frac{[\qquad\qquad]}{[\qquad\qquad]} \times 100$$

Record Percent Average Load of the dynamic brake resistor:

AL =

The calculation of AL is the Dynamic Brake Resistor load expressed as a percent. P_{db} is the sum of the Dynamic Brake dissipation capacity and is obtained from Table A.A. This will give a data point for a line to be drawn on one the curves provided in Section 3.

Step 6 Percent Peak Load of the Internal Dynamic Brake Resistor

Skip this calculation if an external dynamic brake resistor will be used.

$$PL = \frac{P_b}{P_{db}} \times 100$$

PL = Peak load in percent of dynamic brake resistor

P_{av} = Peak braking power calculated in Step 2 (watts)

P_{db} = Steady state power dissipation capacity of dynamic brake resistors obtained from Table A.A (watts)

Calculate Percent Peak Load of the dynamic brake resistor:

$$PL = \frac{[\qquad\qquad]}{[\qquad\qquad]} \times 100$$

Record Percent Average Load of the dynamic brake resistor:

PL =

The calculation of PL in percent gives the percentage of the instantaneous power dissipated by the Dynamic Brake Resistors relative to the steady state power dissipation capacity of the resistors. This will give a data point to be drawn on one of the curves provided in Section 3.

Example Calculation

A 10 HP, 4 Pole, 480 Volt motor and drive is accelerating and decelerating as depicted in Figure 2.1.

- Cycle period t_4 is 40 seconds
- Rated speed is 1785 RPM and is to be decelerated to 0 speed in 15.0 seconds
- Motor load can be considered purely as inertia, and all power expended or absorbed by the motor is absorbed by the motor and load inertia
- Load inertia is 4.0 lb.-ft.^{2} and is directly coupled to the motor
- Motor rotor inertia is 2.2 lb.-ft.^{2}
- A PowerFlex 70, 10 HP 480V Normal Duty rating is chosen.

Calculate the necessary values to choose an acceptable Dynamic Brake.

$$\text{Rated Power} = 10\ \text{HP} \times 746\ \text{watts} = 7.46\ \text{kW}$$

This information was given and must be known before the calculation process begins. This can be given in HP, but must be converted to watts before it can be used in the equations.

$$\text{Rated Speed} = \omega_b = 1785\ \text{RPM} = 2\pi \times \frac{1785}{60} = \frac{186.98\ \text{Rad}}{\text{s}}$$

$$\text{Lower Speed} = \omega_o = 0\ \text{RPM} = 2\pi \times \frac{0}{60} = \frac{0\ \text{Rad}}{\text{s}}$$

This information was given and must be known before the calculation process begins. This can be given in RPM, but must be converted to radians per second before it can be used in the equations.

$$\text{Total Inertia} = J_T = 6.2\ \text{lb.-ft.}^2 = 0.261\ \text{kg-m}^2$$

This value can be in lb.-ft.^{2} or Wk^2, but must be converted into kg-m^2 before it can be used in the equations.

$$\text{Deceleration Time} = (t_3 - t_2) = 15\ \text{seconds}$$

$$\text{Period of Cycle} = t_4 = 40\ \text{seconds}$$

$$V_d = 790 \text{ Volts}$$

This was known because the drive is rated at 480 Volts rms. If the drive were rated 230 Volts rms, then V_d = 395 Volts.

All of the preceding data and calculations were made from knowledge of the application under consideration. The total inertia was given and did not need further calculations as outlined in Step 2.

$$\text{Peak Braking Power} = P_b = \frac{J_T[\omega_b(\omega_b - \omega_o)]}{(t_3 - t_2)}$$

$$P_b = \frac{0.261[186.92(186.92 - 0)]}{15} = 608.6 \text{ watts}$$

Note that this is 8.1% of rated power and is less than the maximum drive limit of 150% current limit. This calculation is the result of Step 3 and determines the peak power that must be dissipated by the Dynamic Brake Resistor.

$$\text{Average Braking Power} = P_{av} = \left[\frac{(t_3 - t_2)}{t_4}\right]\frac{P_b}{2}\left[\frac{(\omega_b + \omega_o)}{\omega_b}\right]$$

$$P_{av} = \left(\frac{15}{40}\right)\left(\frac{608.6}{2}\right)\left(\frac{186.92 + 0}{186.92}\right) = 114.1 \text{ watts}$$

This is the result of calculating the average power dissipation as outlined in Step 5. Verify that the sum of the power ratings of the Dynamic Brake Resistors chosen in Step 4 is greater than the value calculated in Step 5.

For an internal resistor, refer to Table A.A to determine the continuous power rating of the resistor in the given drive you are using. Skip this calculation if an external dynamic brake resistor will be used.

In this case, a 10 HP PowerFlex 70 drive has an internal resistor rated for 40 continuous watts. Because P_{av} = 114.1 watts, and is greater than the resistor's continuous watts rating, the drive will eventually trip on a Resistor Over Heated fault. Calculate the minimum cycle time (in seconds) using the formula in Section 3, number 2 B.

$$\frac{\left(\frac{608.6}{2} \times 15\right)}{40} = 114.1 \text{ seconds}$$

Recalculate the average power dissipation.

$$P_{av} = \left(\frac{15}{114.1}\right)\left(\frac{608.6}{2}\right)\left(\frac{186.92 + 0}{186.92}\right) = 40 \text{ watts}$$

If the cycle cannot be adjusted, the decel time must be extended or the system inertia lowered to reduce the average load on the resistor. Another option is to use an external resistor.

Calculate the Percent Average Load. You will need this number to calculate the Percent Peak Load.

$$\text{Percent Average Load} = AL = 100 \times \frac{P_{av}}{P_{db}}$$

$$AL = 100 \times \frac{40}{40} = 100\%$$

Important: The value of AL should not exceed 100%.

This is the result of the calculation outlined in Step 6. Record this value on page 3-1.

$$\text{Percent Peak Load} = PL = 100 \times \frac{P_b}{P_{db}}$$

$$PL = 100 \times \frac{608.6}{40} = 1521\%$$

This is the result of the calculation outlined in Step 6. Record this value on page 3-1.

Now that the values of AL and PL have been calculated, they can be used to determine whether an internal or external resistor can be used. Since the internal resistor package offers significant cost and space advantages, it will be evaluated first.

Notes:

Evaluating the Internal Resistor

Evaluating the Capability of the Internal Dynamic Brake Resistor

To investigate the capabilities of the internal resistor package, the values of AL (Average Percent Load) and PL (Peak Percent Load) are plotted onto a graph of the Dynamic Brake Resistor's constant temperature power curve and connected with a straight line. If any portion of this line lies to the right of the constant temperature power curve, the resistor element temperature will exceed the operating temperature limit.

Important: The drive will protect the resistor and shut down the Chopper transistor. The drive will then likely trip on an overvoltage fault.

1. Record the values calculated in Section 2.

AL =

PL =

$t_3 - t_2$ =

P_{ave} =

2. A. Compare the calculated average power to the continuous rating of the dynamic brake resistor in the frame drive you have selected. See Table A.A.
Record the resistor's continuous rating.

$R_{cont.}$ =

B. If P_{ave} is greater than $R_{cont.}$ you will need to extend the cycle time (in seconds) by the result of the following equation.

$$\frac{\left(\frac{P_b}{2} \times \text{Decel}\right)}{R_{cont}} = \text{seconds}$$

3. Find the correct constant temperature Power Curve for your drive type, voltage and frame.

Power Curves for PowerFlex 70 Internal DB Resistors

Drive Voltage	Drive Frame(s)	Figure Number
240	A and B	3.1
240	C	3.3
240	D	3.4
400/480	A and B	3.5
400/480	C	3.6
400/480	D	3.7

OR

Power Curves for PowerFlex 700 Internal DB Resistors

Drive Voltage	Drive Frame	Figure Number
400/480	0	3.13
400/480	1	3.14
400/480	2	3.15
400/480	3	Uses external DB resistors only. Refer to Section 4

4. Plot the point where the value of AL, calculated in Step 5 of Section 2, and the desired deceleration time ($t_3 - t_2$) intersect.
5. Plot the value of PL, calculated in Step 6 of Section 2, on the vertical axis (0 seconds).
6. Connect AL at ($t_3 - t_2$) and PL at 0 seconds with a straight line. This line is the power curve described by the motor as it decelerates to minimum speed.

If the line connecting AL and PL lies entirely to the left of the Power Curve, then the capability of the internal resistor is **sufficient** for the proposed application.

Figure 3.1 Example of an Acceptable Resistor Power Curve



If any portion of the line connecting AL and PL lies to the right of the Power Curve, then the capability of the internal resistor is **insufficient** for the proposed application.

- Increase deceleration time ($t_3 - t_2$) until the line connecting AL and PL lies entirely to the left of the Power Curve

  or

- Go to Section 4 and select an external resistor from the tables

PowerFlex 70 Power Curves

Figure 3.2 PowerFlex 70 – 240 Volt, Frames A and B



Figure 3.3 PowerFlex 70 – 240 Volt, Frame C



Figure 3.4 PowerFlex 70 – 240 Volt, Frame D



Figure 3.5 PowerFlex 70 – 480 Volt, Frames A and B



Figure 3.6 PowerFlex 70 – 480 Volt, Frame C



Figure 3.7 PowerFlex 70 – 480 Volt, Frame D



Figure 3.8 PowerFlex 70 – 600 Volt, Frames A and B



Figure 3.9 PowerFlex 70 – 600 Volt, Frame C



PowerFlex 700 Power Curves

Figure 3.10 PowerFlex 700 – 240 Volt, Frame 1 to 5 HP



Figure 3.11 PowerFlex 700 – 240 Volt, Frame 1 - 7.5 HP



Figure 3.12 PowerFlex 700 – 240 Volt, Frame 2



Figure 3.13 PowerFlex 700 – 480 Volt, Frame 0



Figure 3.14 PowerFlex 700 – 480 Volt, Frame 1



Figure 3.15 PowerFlex 700 – 480 Volt, Frame 2



Selecting An External Resistor

How to Select an External Dynamic Brake Resistor

In order to select the appropriate External Dynamic Brake Resistor for your application, the following data must be calculated.

Peak Regenerative Power

(Expressed in watts)

This value is used to determine the maximum resistance value of the Dynamic Brake Resistor. If this value is greater than the maximum imposed by the peak regenerative power of the drive, the drive can trip off due to transient DC bus overvoltage problems.

Power Rating of the Dynamic Brake Resistor

The average power dissipation of the regenerative mode must be estimated and the power rating of the Dynamic Brake Resistor chosen to be greater than the average regenerative power dissipation of the drive.

Protecting External Resistor Packages

ATTENTION: PowerFlex drives do not offer protection for externally mounted brake resistors. A risk of fire exists if external braking resistors are not protected. External resistor packages must be self-protected from over temperature or the protective circuit show below, or equivalent, must be supplied.

Figure 4.1 External Brake Resistor Circuitry



Record the Values Calculated in Section 2

P_b =

P_{av} =

Calculate Maximum Dynamic Brake Resistance Value

When using an internal Dynamic Brake Resistor, the value is fixed. However, when choosing an external resistor, the maximum allowable Dynamic Brake resistance value (R_{db1}) must be calculated.

$$R_{db1} = \frac{(V_d)^2}{P_b}$$

R_{db1} = Maximum allowable value for the dynamic brake resistor (ohms)

V_d = DC bus voltage used for calculating maximum power. (395V DC, 790V DC, 987V DC, or 1135V DC)

P_b = Peak breaking power calculated in Section 2: Step 3 (watts)

Calculate Maximum Dynamic Brake Resistance:

$$R_{db1} = \frac{(\qquad\qquad)^2}{[\qquad\qquad]}$$

Record Maximum Dynamic Brake Resistance:

R_{db1} =

The choice of the Dynamic Brake resistance value should be less than the value calculated in this step. If the value is greater, the drive can trip on DC bus overvoltage.

Calculate required joule rating (joules = watt-seconds):

$$\left(\frac{P_b}{2}\right) \times (t_3 - t_2) = \text{watt-seconds}$$

$$\text{watt-second losses} = \left[\frac{P_b}{2} \times (t_3 - t_2)\right] \times [1 - (\text{motor efficiency} \times \text{drive efficiency})]$$

Drive Efficiency = 0.975

$$\text{Total watt-seconds} = \text{watt-seconds} - \text{watt-second losses}$$

Select Resistor

Select a resistor bank from the following tables or from your resistor supplier that has **all** of the following:

- a resistance value that is less than the value calculated (R_{db1} in ohms)
- a resistance value that is greater than the minimum resistance listed in Table A.A
- a power value that is greater than the value calculated in Step 4 (P_{av} in watts)
- a watt-second value greater than the value calculated.

ATTENTION: The internal dynamic brake IGBT will be damaged if the resistance value of the resistor bank is less than the minimum resistance value of the drive. Use Table A.A to verify that the resistance value of the selected resistor bank is greater than the minimum resistance of the drive.

If no resistor appears in the following tables that is greater than the minimum allowable resistance **and** is less than the calculated maximum resistance:

- Adjust the deceleration time of the application to fit an available resistor package.

  or

- Use the calculated data to purchase resistors locally.

  or

- Consult the factory for other possible resistor packages.

Table 4.A Resistor Selection – 240V AC Drives

Ohms	Watts	Watt Seconds	Catalog Number
154	913	16431	220-1
154	610	16431	220-1A
154	604	16431	225-1
154	408	6416	225-1A
154	242	6416	222-1
154	182	6416	222-1A
117	3000	20800	T117R3K0
117	2700	14300	T117R2K7
117	2100	18600	T117R2K1
117	1500	15800	T117R1K5
117	1200	12500	T117R1K2
117	900	10600	T117R900W
117	600	10100	T117R600W
117	300	7950	T117R300W
110	1278	46947	220-2
110	850	18779	220-2A
110	845	18779	225-2
110	570	18779	225-2A
110	338	7511	222-2
110	255	7511	222-2A
97	4200	19100	T97R4K2
97	3600	22400	T97R3K6
97	3000	16800	T97R3K0
97	2700	19100	T97R2K7
97	2100	15400	T97R2K1
97	1500	20800	T97R1K5
97	1200	16500	T97R1K2
97	900	13800	T97R900W
97	600	13400	T97R600W
97	300	10300	T97R300W
91	86	17000	AKR2091P500
85	1654	57901	220-3
85	1094	36384	225-3
85	1089	36384	220-3A
85	730	23004	225-3A
85	438	9076	222-3
85	326	9076	222-3A
80	9300	230000	T80R9K3
80	9000	209000	T80R9K0
80	5700	29400	T80R5K7
80	4500	23300	T80R4K5
80	4200	25100	T80R4K2
80	3600	18500	T80R3K6
80	3000	22100	T80R3K0
80	2700	24600	T80R2K7
80	2100	19100	T80R2K1
80	1500	17500	T80R1K5
80	1200	13700	T80R1K2
80	900	18500	T80R900W
80	600	10900	T80R600W
80	300	8530	T80R300W
77	9300	230000	T77R9K3
77	9000	209000	T77R9K0
77	5700	28700	T77R5K7
77	4500	22400	T77R4K5
77	4200	24200	T77R4K2
77	3600	28100	T77R3K6
77	3000	21300	T77R3K0
77	2700	23800	T77R2K7
77	2100	19100	T77R2K1
77	1500	16400	T77R1K5
77	1200	20800	T77R1K2
77	900	17900	T77R900W
77	600	10600	T77R600W
77	300	8210	T77R300W
60	11000	448000	T60R11K0
60	6900	164000	T60R6K9
60	4500	28000	T60R4K5
60	3600	22000	T60R3K6
60	2700	18500	T60R2K7
60	1500	20800	T60R1K5
60	1200	16400	T60R1K2
60	900	13700	T60R900W
60	600	13000	T60R600W
60	300	10300	T60R300W
59	2384	99762	220-4
59	1577	64161	220-4A
59	1576	64161	225-4
59	1056	39201	225-4A
59	631	25038	222-4
59	473	10094	222-4A
48	20400	716000	T48R20K4
48	19100	656000	T48R19K1
48	12600	359000	T48R12K6
48	6600	131000	T48R6K6
48	5670	131000	T48R5K67
48	4200	23800	T48R4K2
48	3600	28000	T48R3K6
48	3000	21100	T48R3K0

240V AC Drives Continued

Ohms	Watts	Watt Seconds	Catalog Number
48	2700	23300	T48R2K7
48	1500	16600	T48R1K5
48	1200	20800	T48R1K2
48	900	17500	T48R900W
48	600	16500	T48R600W
48	300	13100	T48R300W
47	166	33000	AKR2047P500
45	19100	656000	T45R19K1
45	12600	359000	T45R12K6
45	6000	125000	T45R6K0
45	3600	26600	T45R3K6
45	3125	197177	220-5
45	3000	19800	T45R3K0
45	2700	22000	T45R2K7
45	2100	28100	T45R2K1
45	2066	124800	225-5
45	2056	124800	220-5A
45	1500	24900	T45R1K5
45	1378	49529	225-5A
45	1200	19100	T45R1K2
45	827	30828	222-5
45	617	30828	222-5A
45	600	15800	T45R600W
45	300	12300	T45R300W
40	22000	1202000	T40R22K0
40	19000	568000	T40R19K0
40	17000	574000	T40R17K0
40	16000	521000	T40R16K0
40	11000	333000	T40R11K0
40	10000	309000	T40R10K0
40	4000	105000	T40R4K0
40	1800	18500	T40R1K8
40	1200	17300	T40R1K2
40	900	14300	T40R900W
40	300	10900	T40R300W
34	26000	1591000	T34R26K0
34	19000	1048000	T34R19K0
34	18000	1017000	T34R18K0
34	17000	990000	T34R17K0
34	15000	456000	T34R15K0
34	13000	456000	T34R13K0
34	9000	285000	T34R9K0
34	8000	262000	T34R8K0
34	4000	98600	T34R4K0
34	3600	93000	T34R3K6

Ohms	Watts	Watt Seconds	Catalog Number
34	2400	30100	T34R2K4
34	1800	25100	T34R1K8
34	900	19100	T34R900W
34	300	14700	T34R300W
32	28000	2304000	T32R28K0
32	26000	1591000	T32R26K0
32	18000	1017000	T32R18K0
32	17100	931000	T32R17K1
32	12700	410000	T32R12K7
32	8420	246000	T32R8K42
32	4500	105000	T32R4K5
32	4395	222215	220-6
32	4000	83300	T32R4K0
32	2918	82626	220-6A
32	2906	82626	225-6
32	2700	25200	T32R2K7
32	2100	20200	T32R2K1
32	1955	88573	225-6A
32	1500	28100	T32R1K5
32	1162	55162	222-6
32	900	19100	T32R900W
32	875	35054	222-6A
32	600	17500	T32R600W
32	300	13800	T32R300W
30	260	52000	AKR2030P1K2
27	27400	2075000	T27R27K4
27	21600	1346000	T27R21K6
27	15000	931000	T27R15K0
27	11500	391000	T27R11K5
27	8420	358000	T27R8K42
27	3300	73900	T27R3K3
27	2100	27300	T27R2K1
27	1500	23700	T27R1K5
27	1200	18800	T27R1K2
27	900	24900	T27R900W
27	600	15400	T27R600W
27	300	18500	T27R300W
25	8420	328000	T25R8K42
25	3900	190000	T25R3K9
25	3300	73900	T25R3K3
25	1500	22000	T25R1K5
25	1200	27700	T25R1K2
25	900	23000	T25R900W
25	600	14300	T25R600W
25	300	17200	T25R300W

240V AC Drives Continued

Ohms	Watts	Watt Seconds	Catalog Number
23	10200	310000	T23R10K2
23	7490	328000	T23R7K49
23	6310	179000	T23R6K31
23	2100	23100	T23R2K1
23	1500	20200	T23R1K5
23	900	21300	T23R900W
23	600	20800	T23R600W
23	300	15800	T23R300W
20	34600	1148000	T20R34K6
20	28400	1066000	T20R28K4
20	20600	1602000	T20R20K6
20	15200	924000	T20R15K2
20	10700	582000	T20R10K7
20	8920	267000	T20R8K92
20	7031	169227	220-7
20	5940	260000	T20R5K94
20	4650	221432	225-7
20	4572	222215	220-7A
20	3063	138493	225-7A
20	1860	55084	222-7
20	1500	28000	T20R1K5
20	1372	87086	222-7A
20	900	18500	T20R900W
20	600	17300	T20R600W
20	300	13700	T20R300W
15	11400	734000	T15R11K4
15	8570	466000	T15R8K57
15	6160	232000	T15R6K16
15	4210	143000	T15R4K21
15	1500	38800	T15R1K5
15	900	22000	T15R900W
15	600	20800	T15R600W
15	520	104000	(2) AKR2030P1K2
15	300	16400	T15R300W
14	12700	1038000	T14R12K7
14	11400	734000	T14R11K4
14	10045	523728	220-8
14	6708	172138	220-8A
14	6642	172138	225-8
14	6160	232000	T14R6K16
14	4495	117367	225-8A
14	2657	154455	222-8
14	2012	61344	222-8A
14	1800	27800	T14R1K8
14	1200	24500	T14R1K2

Ohms	Watts	Watt Seconds	Catalog Number
14	900	20700	T14R900W
14	600	19400	T14R600W
14	300	15400	T14R300W
11	12784	890985	220-9
11	8537	407344	220-9A
11	8454	407344	225-9
11	5720	237243	225-9A
11	3381	100080	222-9
11	2561	121123	222-9A
10.4	72300	4620000	T10F4R72K3
10.4	43900	1367000	T10F4R43K9
10.4	35600	1230000	T10F4R35K6
10.4	26000	2002000	T10F4R26K0
10.4	18900	1991000	T10F4R18K9
10.4	15500	1742000	T10F4R15K5
10.4	11000	359000	T10F4R11K0
10.4	8890	801000	T10F4R8K89
10.4	6040	489000	T10F4R6K4
10.4	5360	329000	T10F4R5K36
10.4	2970	95100	T10F4R2K97
10.4	1500	25400	T10F4R1K5
10.4	900	24500	T10F4R900W
10.4	600	22900	T10F4R600W
10.4	300	17300	T10F4R300W
7.3	19264	656981	220-10
7.3	12754	359925	220-10A
7.3	12738	359925	225-10
7.3	8545	566990	225-10A
7.3	5095	267369	222-10
7.3	3826	164245	222-10A
5.7	24694	1781970	220-11
5.7	16461	880744	220-11A
5.7	16314	880744	225-11
5.7	11029	905640	225-11A
5.7	6525	421193	222-11
5.7	4938	260816	222-11A
5.4	104000	3444000	T5F4R104K0
5.4	51900	1953000	T5F4R51K9
5.4	48100	1845000	T5F4R48K1
5.4	37700	2310000	T5F4R37K7
5.4	22000	717000	T5F4R22K0
5.4	20300	738000	T5F4R20K3
5.4	12000	699000	T5F4R12K0
5.4	7280	328000	T5F4R7K28
5.4	5780	169000	T5F4R5K78

240V AC Drives Continued

Ohms	Watts	Watt Seconds	Catalog Number
5.4	5080	401000	T5F4R5K8
5.4	2680	185000	T5F4R2K68
5.4	1670	55700	T5F4R1K67
4.8	132000	8077000	T4F8R132K0
4.8	99300	6159000	T4F8R99K3
4.8	61000	3916000	T4F8R61K0
4.8	58200	3696000	T4F8R58K2
4.8	34600	2310000	T4F8R34K6
4.8	25800	984000	T4F8R25K8
4.8	19200	586000	T4F8R19K2
4.8	10900	359000	T4F8R10K9
4.8	8880	260000	T4F8R8K88
4.8	5490	169000	T4F8R5K49
4.8	4590	401000	T4F8R4K59
4.8	2580	185000	T4F8R2K58
4.5	30918	1486256	220-12
4.5	20715	1425576	225-12
4.5	20612	1425576	220-12A
4.5	13810	660558	225-12A
4.5	8266	239950	222-12
4.5	6184	152850	222-12A
3.8	36138	2672955	220-13
3.8	24212	1321116	225-13
3.8	24089	751149	220-13A
3.8	16139	430346	225-13A
3.8	9788	328491	222-13
3.8	7227	182571	222-13A
2.7	35178	2187360	225-14
2.7	35003	2164091	220-14A
2.7	23452	1173670	225-14A
2.7	15750	520110	222-14
2.7	10500	521631	222-14A
2.2	44785	1724576	225-15
2.2	29860	1685270	225-15A
2.2	20053	1603773	222-15
2.2	13370	316618	222-15A
1.8	34281	2138364	225-16A
1.8	23026	1570711	222-16
1.8	15350	782447	222-16A
1.5	19884	1308926	222-17A

Table 4.B Resistor Selection – 480V AC Drives

Ohms	Watts	Watt Seconds	Catalog Number
615	915	13302	440-1
615	605	13615	445-1
615	602	13302	440-1A
615	404	4225	445-1A
615	242	4225	442-1
615	180	4225	442-1A
439	1281	24647	440-2
439	848	9389	440-2A
439	847	11267	445-2
439	568	2973	445-2A
439	339	2973	442-2
439	254	2973	442-2A
360	86	17000	AKR2360P500
342	1645	36306	440-3
342	1096	22534	440-3A
342	1088	23473	445-3
342	734	14397	445-3A
342	435	3677	442-3
342	329	3677	442-3A
237	2373	61422	440-4
237	1577	39748	440-4A
237	1570	38496	445-4
237	1057	25351	445-4A
237	628	15649	442-4
237	473	5321	442-4A
181	3108	77775	440-5
181	2068	77853	440-5A
181	2055	77853	445-5
181	1385	30985	445-5A
181	822	19248	442-5
181	620	19248	442-5A
128	4395	138024	440-6
128	2912	82626	440-6A
128	2906	86382	445-6
128	1951	55397	445-6A
128	1162	32863	442-6
128	874	22065	442-6A
120	260	52000	AKR2120P1K2
117	3000	20800	T117R3K0
117	2700	14300	T117R2K7
117	2100	18600	T117R2K1
117	1500	15800	T117R1K5
117	1200	12500	T117R1K2
117	900	10600	T117R900W
117	600	10100	T117R600W
117	300	7950	T117R300W
97	4200	19100	T97R4K2
97	3600	22400	T97R3K6
97	3000	16800	T97R3K0
97	2700	19100	T97R2K7
97	2100	15400	T97R2K1
97	1500	20800	T97R1K5
97	1200	16500	T97R1K2
97	900	13800	T97R900W
97	600	13400	T97R600W
97	300	10300	T97R300W
81	6944	221276	440-7
81	4629	221432	440-7A
81	4592	224640	445-7
81	3102	55319	445-7A
81	1837	55084	442-7
81	1389	34975	442-7A
80	9300	230000	T80R9K3
80	9000	209000	T80R9K0
80	5700	29400	T80R5K7
80	4500	23300	T80R4K5
80	4200	25100	T80R4K2
80	3600	18500	T80R3K6
80	3000	22100	T80R3K0
80	2700	24600	T80R2K7
80	2100	19100	T80R2K1
80	1500	17500	T80R1K5
80	1200	13700	T80R1K2
80	900	18500	T80R900W
80	600	10900	T80R600W
80	300	8530	T80R300W
77	9300	230000	T77R9K3
77	9000	209000	T77R9K0
77	5700	28700	T77R5K7
77	4500	22400	T77R4K5
77	4200	24200	T77R4K2
77	3600	28100	T77R3K6
77	3000	21300	T77R3K0
77	2700	23800	T77R2K7
77	2100	19100	T77R2K1
77	1500	16400	T77R1K5
77	1200	20800	T77R1K2
77	900	17900	T77R900W

480V AC Drives Continued

Ohms	Watts	Watt Seconds	Catalog Number
77	600	10600	T77R600W
77	300	8210	T77R300W
60	11000	448000	T60R11K0
60	6900	164000	T60R6K9
60	4500	28000	T60R4K5
60	3600	22000	T60R3K6
60	2700	18500	T60R2K7
60	1500	20800	T60R1K5
60	1200	16400	T60R1K2
60	900	13700	T60R900W
60	600	13000	T60R600W
60	520	104000	(2) AKR2120P1K2
60	300	10300	T60R300W
56	10045	388094	440-8
56	6702	245375	440-8A
56	6642	245375	445-8
56	4490	245062	445-8A
56	2657	154455	442-8
56	2010	61344	442-8A
48	20400	716000	T48R20K4
48	19100	656000	T48R19K1
48	12600	359000	T48R12K6
48	6600	131000	T48R6K6
48	5670	131000	T48R5K67
48	4200	23800	T48R4K2
48	3600	28000	T48R3K6
48	3000	21100	T48R3K0
48	2700	23300	T48R2K7
48	1500	16600	T48R1K5
48	1200	20800	T48R1K2
48	900	17500	T48R900W
48	600	16500	T48R600W
48	300	13100	T48R300W
45	19100	656000	T45R19K1
45	12600	359000	T45R12K6
45	6000	125000	T45R6K0
45	3600	26600	T45R3K6
45	3000	19800	T45R3K0
45	2700	22000	T45R2K7
45	2100	28100	T45R2K1
45	1500	24900	T45R1K5
45	1200	19100	T45R1K2
45	600	15800	T45R600W
45	300	12300	T45R300W

Ohms	Watts	Watt Seconds	Catalog Number
44	12784	369388	440-9
44	8537	302807	440-9A
44	8454	305624	445-9
44	5720	184031	445-9A
44	3381	190604	442-9
44	2561	121670	442-9A
40	22000	1202000	T40R22K0
40	19000	568000	T40R19K0
40	17000	574000	T40R17K0
40	16000	521000	T40R16K0
40	11000	333000	T40R11K0
40	10000	309000	T40R10K0
40	4000	105000	T40R4K0
40	1800	18500	T40R1K8
40	1200	17300	T40R1K2
40	900	14300	T40R900W
40	300	10900	T40R300W
34	26000	1591000	T34R26K0
34	19000	1048000	T34R19K0
34	18000	1017000	T34R18K0
34	17000	990000	T34R17K0
34	15000	456000	T34R15K0
34	13000	456000	T34R13K0
34	9000	285000	T34R9K0
34	8000	262000	T34R8K0
34	4000	98600	T34R4K0
34	3600	93000	T34R3K6
34	2400	30100	T34R2K4
34	1800	25100	T34R1K8
34	900	19100	T34R900W
34	300	14700	T34R300W
32	28000	2304000	T32R28K0
32	26000	1591000	T32R26K0
32	18000	1017000	T32R18K0
32	17100	931000	T32R17K1
32	12700	410000	T32R12K7
32	8420	246000	T32R8K42
32	4500	105000	T32R4K5
32	4000	83300	T32R4K0
32	2700	25200	T32R2K7
32	2100	20200	T32R2K1
32	1500	28100	T32R1K5
32	900	19100	T32R900W
32	600	17500	T32R600W
32	300	13800	T32R300W

480V AC Drives Continued

Ohms	Watts	Watt Seconds	Catalog Number
29	19396	615920	440-10
29	12826	359925	445-10
29	12667	359925	440-10A
29	8487	253840	445-10A
29	5130	199993	442-10
29	3800	127069	442-10A
27	27400	2075000	T27R27K4
27	21600	1346000	T27R21K6
27	15000	931000	T27R15K0
27	11500	391000	T27R11K5
27	8420	358000	T27R8K42
27	3300	73900	T27R3K3
27	2100	27300	T27R2K1
27	1500	23700	T27R1K5
27	1200	18800	T27R1K2
27	900	24900	T27R900W
27	600	15400	T27R600W
27	300	18500	T27R300W
25	8420	328000	T25R8K42
25	3900	190000	T25R3K9
25	3300	73900	T25R3K3
25	1500	22000	T25R1K5
25	1200	27700	T25R1K2
25	900	23000	T25R900W
25	600	14300	T25R600W
25	300	17200	T25R300W
23	16172	825698	445-11
23	11125	492736	445-11A
23	10200	310000	T23R10K2
23	7490	328000	T23R7K49
23	6469	399830	442-11
23	6310	179000	T23R6K31
23	4982	254295	442-11A
23	2100	23100	T23R2K1
23	1500	20200	T23R1K5
23	900	21300	T23R900W
23	600	20800	T23R600W
23	300	15800	T23R300W
20	34600	1148000	T20R34K6
20	28400	1066000	T20R28K4
20	24910	1781970	440-11
20	20600	1602000	T20R20K6
20	16605	825698	440-11A
20	15200	924000	T20R15K2
20	10700	582000	T20R10K7
20	8920	267000	T20R8K92
20	5940	260000	T20R5K94
20	1500	28000	T20R1K5
20	900	18500	T20R900W
20	600	17300	T20R600W
20	300	13700	T20R300W
18	30910	899814	440-12
18	20664	1336477	445-12
18	20612	1336477	440-12A
18	13810	660558	445-12A
18	8266	234734	442-12
18	6184	152850	442-12A
15	35663	1313963	440-13
15	23894	719851	445-13
15	23772	719851	440-13A
15	15927	1158280	445-13A
15	11400	734000	T15R11K4
15	9919	328491	442-13
15	8570	466000	T15R8K57
15	7132	179963	442-13A
15	6160	232000	T15R6K16
15	4210	143000	T15R4K21
15	1500	38800	T15R1K5
15	900	22000	T15R900W
15	600	20800	T15R600W
15	300	16400	T15R300W
14	12700	1038000	T14R12K7
14	11400	734000	T14R11K4
14	6160	232000	T14R6K16
14	1800	27800	T14R1K8
14	1200	24500	T14R1K2
14	900	20700	T14R900W
14	600	19400	T14R600W
14	300	15400	T14R300W
12	48204	1314510	440-14
12	32297	1040221	445-14
12	32136	1040221	440-14A
12	21531	1924486	445-14A
12	12398	890985	442-14
12	9641	440372	442-14A
10.4	72300	4620000	T10F4R72K3
10.4	43900	1367000	T10F4R43K9
10.4	35600	1230000	T10F4R35K6
10.4	26000	2002000	T10F4R26K0
10.4	18900	1991000	T10F4R18K9

480V AC Drives Continued

Ohms	Watts	Watt Seconds	Catalog Number
10.4	15500	1742000	T10F4R15K5
10.4	11000	359000	T10F4R11K0
10.4	8890	801000	T10F4R8K89
10.4	6040	489000	T10F4R6K4
10.4	5360	329000	T10F4R5K36
10.4	2970	95100	T10F4R2K97
10.4	1500	25400	T10F4R1K5
10.4	900	24500	T10F4R900W
10.4	600	22900	T10F4R600W
10.4	300	17300	T10F4R300W
9.5	59635	1820386	440-15
9.5	39955	1079776	445-15
9.5	39755	2851152	440-15A
9.5	26636	3000513	445-15A
9.5	17890	479901	442-15
9.5	11926	316618	442-15A
8	70477	3325398	440-16
8	47219	1560331	445-16
8	46977	2966898	440-16A
8	31474	1564893	445-16A
8	21143	693480	442-16
8	14093	401656	442-16A
6.4	58718	4929414	445-17
6.4	58430	4818224	440-17A
6.4	39148	1231840	445-17A
6.4	26292	719851	442-17
6.4	17529	574859	442-17A
5.4	104000	3444000	T5F4R104K0
5.4	51900	1953000	T5F4R51K9
5.4	48100	1845000	T5F4R48K1
5.4	37700	2310000	T5F4R37K7
5.4	22000	717000	T5F4R22K0
5.4	20300	738000	T5F4R20K3
5.4	12000	699000	T5F4R12K0
5.4	7280	328000	T5F4R7K28
5.4	5780	169000	T5F4R5K78
5.4	5080	401000	T5F4R5K8
5.4	2680	185000	T5F4R2K68
5.4	1670	55700	T5F4R1K67
5	76534	3651418	445-18
5	51028	1733701	445-18A
5	34269	959801	442-18
5	22848	1603773	442-18A

Ohms	Watts	Watt Seconds	Catalog Number
4.8	132000	8077000	T4F8R132K0
4.8	99300	6159000	T4F8R99K3
4.8	61000	3916000	T4F8R61K0
4.8	58200	3696000	T4F8R58K2
4.8	34600	2310000	T4F8R34K6
4.8	25800	984000	T4F8R25K8
4.8	19200	586000	T4F8R19K2
4.8	10900	359000	T4F8R10K9
4.8	8880	260000	T4F8R8K88
4.8	5490	169000	T4F8R5K49
4.8	4590	401000	T4F8R4K59
4.8	2580	185000	T4F8R2K58
4	42308	1386961	442-19
4	28207	1321116	442-19A
3.9	62996	8013142	445-19A
3.9	49108	3246136	442-20
3.9	32736	2405659	442-20A
2.6	44505	1126723	442-21A

Table 4.C Resistor Selection – 600V AC Drives

Ohms	Watts	Watt Seconds	Catalog Number
956	915	6260	550-1
956	605	6260	555-1
956	597	6260	550-1A
956	400	6260	555-1A
956	242	4225	552-1
956	179	4225	552-1A
695	1258	15258	550-2
695	832	7981	555-2
695	825	7981	550-2A
695	553	7981	555-2A
695	333	4929	552-2
695	248	4929	552-2A
546	1601	36619	550-3
546	1059	23004	555-3
546	1055	23004	550-3A
546	707	12050	555-3A
546	424	12050	552-3
546	316	5634	552-3A
364	2402	39514	550-4
364	1590	38496	550-4A
364	1588	38496	555-4
364	1065	24412	555-4A
364	635	15336	552-4
364	477	3990	552-4A
360	86	17000	AKR2360P500
283	3089	76680	550-5
283	2048	47338	550-5A
283	2043	48120	555-5
283	1372	30046	555-5A
283	817	19092	552-5
283	614	19092	552-5A
196	4460	130669	550-6
196	2965	83096	550-6A
196	2950	83096	555-6
196	1987	53519	555-6A
196	1180	33567	552-6
196	890	20970	552-6A
125	6994	212513	550-7
125	4625	208131	555-7
125	4620	208131	550-7A
125	3095	130903	555-7A
125	1850	51954	552-7
125	1386	32863	552-7A

Ohms	Watts	Watt Seconds	Catalog Number
120	260	52000	AKR2120P1K2
117	3000	20800	T117R3K0
117	2700	14300	T117R2K7
117	2100	18600	T117R2K1
117	1500	15800	T117R1K5
117	1200	12500	T117R1K2
117	900	10600	T117R900W
117	600	10100	T117R600W
117	300	7950	T117R300W
97	4200	19100	T97R4K2
97	3600	22400	T97R3K6
97	3000	16800	T97R3K0
97	2700	19100	T97R2K7
97	2100	15400	T97R2K1
97	1500	20800	T97R1K5
97	1200	16500	T97R1K2
97	900	13800	T97R900W
97	600	13400	T97R600W
97	300	10300	T97R300W
85	10285	361490	550-8
85	6854	231135	550-8A
85	6801	231135	555-8
85	4592	233795	555-8A
85	2720	92016	552-8
85	2056	57588	552-8A
80	9300	230000	T80R9K3
80	9000	209000	T80R9K0
80	5700	29400	T80R5K7
80	4500	23300	T80R4K5
80	4200	25100	T80R4K2
80	3600	18500	T80R3K6
80	3000	22100	T80R3K0
80	2700	24600	T80R2K7
80	2100	19100	T80R2K1
80	1500	17500	T80R1K5
80	1200	13700	T80R1K2
80	900	18500	T80R900W
80	600	10900	T80R600W
80	300	8530	T80R300W
77	9300	230000	T77R9K3
77	9000	209000	T77R9K0
77	5700	28700	T77R5K7
77	4500	22400	T77R4K5
77	4200	24200	T77R4K2
77	3600	28100	T77R3K6

600V AC Drives Continued

Ohms	Watts	Watt Seconds	Catalog Number
77	3000	21300	T77R3K0
77	2700	23800	T77R2K7
77	2100	19100	T77R2K1
77	1500	16400	T77R1K5
77	1200	20800	T77R1K2
77	900	17900	T77R900W
77	600	10600	T77R600W
77	300	8210	T77R300W
70	12489	482144	550-9
70	8424	295765	550-9A
70	8258	297173	555-9
70	5643	189665	555-9A
70	3303	144048	552-9
70	2527	76680	552-9A
60	11000	448000	T60R11K0
60	6900	164000	T60R6K9
60	4500	28000	T60R4K5
60	3600	22000	T60R3K6
60	2700	18500	T60R2K7
60	1500	20800	T60R1K5
60	1200	16400	T60R1K2
60	900	13700	T60R900W
60	600	13000	T60R600W
60	520	104000	(2) AKR2120P1K2
60	300	10300	T60R300W
48	20400	716000	T48R20K4
48	19100	656000	T48R19K1
48	12600	359000	T48R12K6
48	6600	131000	T48R6K6
48	5670	131000	T48R5K67
48	4200	23800	T48R4K2
48	3600	28000	T48R3K6
48	3000	21100	T48R3K0
48	2700	23300	T48R2K7
48	1500	16600	T48R1K5
48	1200	20800	T48R1K2
48	900	17500	T48R900W
48	600	16500	T48R600W
48	300	13100	T48R300W
45	19427	563362	550-10
45	19100	656000	T45R19K1
45	12943	409420	550-10A
45	12846	409420	555-10
45	12600	359000	T45R12K6

Ohms	Watts	Watt Seconds	Catalog Number
45	8672	370410	555-10A
45	6000	125000	T45R6K0
45	5138	308128	552-10
45	3883	120810	552-10A
45	3600	26600	T45R3K6
45	3000	19800	T45R3K0
45	2700	22000	T45R2K7
45	2100	28100	T45R2K1
45	1500	24900	T45R1K5
45	1200	19100	T45R1K2
45	600	15800	T45R600W
45	300	12300	T45R300W
40	22000	1202000	T40R22K0
40	19000	568000	T40R19K0
40	17000	574000	T40R17K0
40	16000	521000	T40R16K0
40	11000	333000	T40R11K0
40	10000	309000	T40R10K0
40	4000	105000	T40R4K0
40	1800	18500	T40R1K8
40	1200	17300	T40R1K2
40	900	14300	T40R900W
40	300	10900	T40R300W
36	24978	1321116	550-11
36	16863	449907	550-11A
36	16517	449907	555-11
36	11298	316618	555-11A
35	6423	249757	552-11
35	5058	157272	552-11A
34	26000	1591000	T34R26K0
34	19000	1048000	T34R19K0
34	18000	1017000	T34R18K0
34	17000	990000	T34R17K0
34	15000	456000	T34R15K0
34	13000	456000	T34R13K0
34	9000	285000	T34R9K0
34	8000	262000	T34R8K0
34	4000	98600	T34R4K0
34	3600	93000	T34R3K6
34	2400	30100	T34R2K4
34	1800	25100	T34R1K8
34	900	19100	T34R900W
34	300	14700	T34R300W
32	28000	2304000	T32R28K0
32	26000	1591000	T32R26K0

600V AC Drives Continued

Ohms	Watts	Watt Seconds	Catalog Number
32	18000	1017000	T32R18K0
32	17100	931000	T32R17K1
32	12700	410000	T32R12K7
32	8420	246000	T32R8K42
32	4500	105000	T32R4K5
32	4000	83300	T32R4K0
32	2700	25200	T32R2K7
32	2100	20200	T32R2K1
32	1500	28100	T32R1K5
32	900	19100	T32R900W
32	600	17500	T32R600W
32	300	13800	T32R300W
28	30492	2138364	550-12
28	20646	1033301	555-12
28	20321	1100930	550-12A
28	13615	359925	555-12A
28	8258	237463	552-12
28	6096	299521	552-12A
27	27400	2075000	T27R27K4
27	21600	1346000	T27R21K6
27	15000	931000	T27R15K0
27	11500	391000	T27R11K5
27	8420	358000	T27R8K42
27	3300	73900	T27R3K3
27	2100	27300	T27R2K1
27	1500	23700	T27R1K5
27	1200	18800	T27R1K2
27	900	24900	T27R900W
27	600	15400	T27R600W
27	300	18500	T27R300W
25	8420	328000	T25R8K42
25	3900	190000	T25R3K9
25	3300	73900	T25R3K3
25	1500	22000	T25R1K5
25	1200	27700	T25R1K2
25	900	23000	T25R900W
25	600	14300	T25R600W
25	300	17200	T25R300W
24	36710	844315	550-13
24	24468	1871068	550-13A
24	24086	1173670	555-13
24	16393	533797	555-13A
24	9635	299938	552-13
24	7340	211079	552-13A
23	10200	310000	T23R10K2
23	7490	328000	T23R7K49
23	6310	179000	T23R6K31
23	2100	23100	T23R2K1
23	1500	20200	T23R1K5
23	900	21300	T23R900W
23	600	20800	T23R600W
23	300	15800	T23R300W
20	34600	1148000	T20R34K6
20	28400	1066000	T20R28K4
20	20600	1602000	T20R20K6
20	15200	924000	T20R15K2
20	10700	582000	T20R10K7
20	8920	267000	T20R8K92
20	5940	260000	T20R5K94
20	1500	28000	T20R1K5
20	900	18500	T20R900W
20	600	17300	T20R600W
20	300	13700	T20R300W
19	47709	5953399	550-14
19	31965	2913365	555-14
19	31798	3029900	550-14A
19	21305	1514674	555-14A
19	12170	410613	552-14
19	9540	410613	552-14A
15	60579	7591398	550-15
15	40587	1313963	555-15
15	40388	1300276	550-15A
15	27060	719851	555-15A
15	18173	1158280	552-15
15	12112	550465	552-15A
15	11400	734000	T15R11K4
15	8570	466000	T15R8K57
15	6160	232000	T15R6K16
15	4210	143000	T15R4K21
15	1500	38800	T15R1K5
15	900	22000	T15R900W
15	600	20800	T15R600W
15	300	16400	T15R300W
14	12700	1038000	T14R12K7
14	11400	734000	T14R11K4
14	6160	232000	T14R6K16
14	1800	27800	T14R1K8
14	1200	24500	T14R1K2
14	900	20700	T14R900W
14	600	19400	T14R600W

600V AC Drives Continued

Ohms	Watts	Watt Seconds	Catalog Number
14	300	15400	T14R300W
12	68911	10015318	550-16
12	46170	2247026	555-16
12	45934	2387466	550-16A
12	30776	1040221	555-16A
12	20673	599876	552-16
12	13780	890985	552-16A
10.4	72300	4620000	T10F4R72K3
10.4	43900	1367000	T10F4R43K9
10.4	35600	1230000	T10F4R35K6
10.4	26000	2002000	T10F4R26K0
10.4	18900	1991000	T10F4R18K9
10.4	15500	1742000	T10F4R15K5
10.4	11000	359000	T10F4R11K0
10.4	8890	801000	T10F4R8K89
10.4	6040	489000	T10F4R6K4
10.4	5360	329000	T10F4R5K36
10.4	2970	95100	T10F4R2K97
10.4	1500	25400	T10F4R1K5
10.4	900	24500	T10F4R900W
10.4	600	22900	T10F4R600W
10.4	300	17300	T10F4R300W
10	59339	1950414	555-17
10	59043	1950414	550-17A
10	39559	1956117	555-17A
10	26569	903350	552-17
10	17713	479901	552-17A
8	78475	5345909	555-18
8	52321	1559677	555-18A
8	35138	2494758	552-18
8	23427	1211023	552-18A
6	62551	2135190	555-19A
6	42015	1981674	552-19
6	28008	1960167	552-19A
5.4	104000	3444000	T5F4R104K0
5.4	51900	1953000	T5F4R51K9
5.4	48100	1845000	T5F4R48K1
5.4	37700	2310000	T5F4R37K7
5.4	22000	717000	T5F4R22K0
5.4	20300	738000	T5F4R20K3
5.4	12000	699000	T5F4R12K0
5.4	7280	328000	T5F4R7K28
5.4	5780	169000	T5F4R5K78
5.4	5080	401000	T5F4R5K8
5.4	2680	185000	T5F4R2K68
5.4	1670	55700	T5F4R1K67
5	46464	3891643	552-20
5	30978	1651395	552-20A
4.8	132000	8077000	T4F8R132K0
4.8	99300	6159000	T4F8R99K3
4.8	61000	3916000	T4F8R61K0
4.8	58200	3696000	T4F8R58K2
4.8	34600	2310000	T4F8R34K6
4.8	25800	984000	T4F8R25K8
4.8	19200	586000	T4F8R19K2
4.8	10900	359000	T4F8R10K9
4.8	8880	260000	T4F8R8K88
4.8	5490	169000	T4F8R5K49
4.8	4590	401000	T4F8R4K59
4.8	2580	185000	T4F8R2K58
4	66084	1799627	552-21
4	44057	3441020	552-21A

Table A.A Minimum Dynamic Brake Resistance

Drive Normal Duty Rating	Regen DC Bus Voltage (V_d)	Rated Continuous Power, Internal Resistors (P_{db})				Minimum Ohms (±10%), External Resistors[1]		
		PowerFlex 70		PowerFlex 700		PowerFlex Product		
		Frame	Watts	Frame	Watts	4	70	700
240V, 0.5 HP	395	A	48	0	50		30.4	35.8
240V, 1 HP		A	48	0	50	60	30.4	35.8
240V, 2 HP		B	28	1	50	60	30.4	35.8
240V, 3 HP		B	40	1	50	48	30.4	35.8
240V, 5 HP		C	40	1	50	32	27.4	29.5
240V, 7.5 HP		D	36	1	50		20.9	22.7
240V, 10 HP		D	36	2	50		20.9	21
240V, 15 HP								11.2
240V, 20 HP								9
240V, 25 HP								9
240V, 30 HP								7
240V, 40 HP								4.6
240V, 50 HP								4.6
240V, 60 HP								2.1
240V, 70 HP								2.1
400V, 0.37 kW 480V, 0.5 HP	790 for 400V and 480V Drives	A	48	0	50		61.7	63.1
400V, 0.75 kW 480V, 1 HP		A	48	0	50	121	61.7	63.1
400V, 1.5 kW 480V, 2 HP		A	48	0	50	121	61.7	63.1
400V, 2.2 kW 480V, 3 HP		B	28	0	50	97	61.7	63.1
400V, 4 kW 480V, 5 HP		B	28	0	50	97	61.7	63.1
400V, 5.5 kW 480V, 7.5 HP		C	40	0	50		66.9	63.1
400V, 7.5 kW 480V, 10 HP		C	40	1	50		66.9	63.1
400V, 11 kW 480V, 15 HP		D	36	1	50		39.9	43.3
400V, 15 kW 480V, 20 HP		D	36	2	50		27.8	40.2
400V, 18.5 kW 480V, 25 HP		D		2	50		24.6	28.2
400V, 22 kW 480V, 30 HP		D					25.1	21.7
400V, 30 kW 480V, 40 HP								18.7

(1) Does not include a resistor tolerance.

Drive Normal Duty Rating	Regen DC Bus Voltage (V_d)	Rated Continuous Power, Internal Resistors (P_{db})				Minimum Ohms (±10%), External Resistors[1]		
		PowerFlex 70		PowerFlex 700		PowerFlex Product		
		Frame	Watts	Frame	Watts	4	70	700
400V, 37 kW 480V, 50 HP	790 for 400V and 480V Drives							18.7
400V, 45 kW 480V, 60 HP								15.4
400V, 55 kW 480V, 75 HP								9.2
400V, 75 kW 480V, 100 HP								9.2
400V, 90 kW 480V, 125 HP								4.4
400V, 110 kW 480V, 150 HP								4.4
400V, 132 kW 480V, 200 HP								3.3
600V, 0.5 HP	987.5	A	48	0	50		117	84
600V, 1 HP		A	48	0	50		117	84
600V, 2 HP		A	48	0	50		117	84
600V, 3 HP		B	28	0	50		117	84
600V, 5 HP		B	28	0	50		80	84
600V, 7.5 HP		C	40	0	50		80	75.5
600V, 10 HP		C	40	1	50		80	75.5
600V, 15 HP		D					48	52
600V, 20 HP		D					48	41.8
600V, 25 HP								36.1
600V, 30 HP								28.9
600V, 40 HP								24.3
600V, 50 HP								24.3
600V, 60 HP								17.7
600V, 75 HP	1135							18.1
600V, 100 HP								18.1
600V, 125 HP								6.3
600V, 150 HP								6.3
690V, 45 kW	1135							NA
690V, 55 kW								18.1
690V, 75 kW								18.1
690V, 90 kW								18.1
690V, 110 kW								6.3
690V, 132 kW								6.3

(1) Does not include a resistor tolerance.

www.rockwellautomation.com

Corporate Headquarters
Rockwell Automation, 777 East Wisconsin Avenue, Suite 1400, Milwaukee, WI, 53202-5302 USA, Tel: (1) 414.212.5200, Fax: (1) 414.212.5201

Headquarters for Allen-Bradley Products, Rockwell Software Products and Global Manufacturing Solutions
Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444
Europe/Middle East/Africa: Rockwell Automation SA/NV, Vorstlaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640
Asia Pacific: Rockwell Automation, 27/F Citicorp Centre, 18 Whitfield Road, Causeway Bay, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Headquarters for Dodge and Reliance Electric Products
Americas: Rockwell Automation, 6040 Ponders Court, Greenville, SC 29615-4617 USA, Tel: (1) 864.297.4800, Fax: (1) 864.281.2433
Europe/Middle East/Africa: Rockwell Automation, Brühlstraße 22, D-74834 Elztal-Dallau, Germany, Tel: (49) 6261 9410, Fax: (49) 6261 17741
Asia Pacific: Rockwell Automation, 55 Newton Road, #11-01/02 Revenue House, Singapore 307987, Tel: (65) 6356-9077, Fax: (65) 6356-9011

U.S. Allen-Bradley Drives Technical Support
Tel: (1) 262.512.8176, Fax: (1) 262.512.2222, Email: support@drives.ra.rockwell.com, Online: www.ab.com/support/abdrives

Publication PFLEX-AT001G-EN-P – May 2004
Supersedes June 2003
Copyright © 2004 Rockwell Automation, Inc. All rights reserved. Printed in USA.

A

Accel Mask, 2-114
Accel Owner, 2-127
Accel Time, 2-1
Accel Time 1/2, 2-1
Advanced Tuning, 2-61
Agency Certification, 1-1
Alarm Queue, 2-9
Alarm x Code, 2-9
Alarms, 2-5
Altitude Derates, 1-3
Ambient Temperature Derates, 1-3
Analog I/O, 2-9
Analog I/O Cable Selection, 2-18
Analog In Lo, 2-12
Analog In1 Value, 2-18
Analog In2 Value, 2-18
Analog Inputs, 2-9
Analog Out Scale, 2-25
Analog Out1 Sel, 2-21
Analog Out2 Sel, 2-21
Analog Outputs, 2-21
Analog Scaling, 2-12
Anlg In 1, 2 Loss, 2-17
Anlg In Config, 2-6, 2-9
Anlg In Loss, 2-7
Anlg In Sqr Root, 2-16
Anlg Out Setpt, 2-26
Auto / Manual, 2-27, 2-171
Auto Restart, 2-29
Auto Rstrt Delay, 2-29
Auto Rstrt Tries, 2-29
Auto-Economizer, 2-91
Autotune, 2-31

B

Block Diagrams, 2-34
Bottom View Dimensions, 1-17
Bus Memory, 2-60
Bus Reg Gain, 2-46
Bus Reg Mode A, B, 2-46
Bus Regulation, 2-46
Bypass Contactor, 2-121

C

Cable
  I/O, Analog, 2-18
  I/O, Digital, 2-61
  Motor, Length, 2-51
Cable Termination, 2-124
Cable Trays, 2-51
Carrier (PWM) Frequency, 2-52
CE
  Conformity, 2-53
  Requirements, 2-53
Circuit Breakers, 2-100
Clear Fault Owner, 2-127
Coast, 2-201
Compensation, 2-152
Conduit, 2-51
Contactor, Output, 2-124
Contactors
  Bypass, 2-121
  Input, 2-121
  Output, 2-121
Copy Cat, 2-55
Current Limit, 2-56
Current Lmt Gain, 2-56
Current Lmt Sel, 2-9, 2-56, 2-160
Current Lmt Val, 2-56

D

Datalinks, 2-58
DC Brake Level, 2-201
DC Brake Lvl Sel, 2-201
DC Brake Time, 2-201
DC Braking, 2-201
DC Bus Voltage, 2-60
Decel Mask, 2-114
Decel Owner, 2-127
Decel Time, 2-60
Decel Time 1/2, 2-60
Derating Guidelines, 1-3
Dig Out Setpt, 2-82
Dig Outx Level, 2-80
Dig Outx OffTime, 2-81
Dig Outx OnTime, 2-81
Digital Input Conflicts, 2-75
Digital Inputs, 2-61
Digital Inputs Group, 2-62, 2-63
Digital Inx Sel, 2-62, 2-63
Digital Output Timers, 2-81
Digital Outputs, 2-78
Digital Outputs Group, 2-62, 2-79
Digital Outx Sel, 2-8, 2-78, 2-79
Dimensions

Bottom View, 1-17
Mounting
PowerFlex 700, 1-13, 1-15
PowerFlex 70
Bottom View, 1-8
Mounting, 1-7
Direction Control, 2-82
Direction Mask, 2-114
Direction Owner, 2-127
DPI, 2-83
Drive Output Contactor, 2-124
Drive Overload, 2-86
Drive Ratings, 2-90
Drive Thermal Manager Protection, 2-88
Droop, 2-90
Dynamic Braking, 2-201, A-1

E

Economizer, 2-91
Efficiency Derates, 1-3, 2-91
EMC
Directive, 2-53
EMC Instructions, 2-53
Encoder, 2-169
Exclusive Ownership, 2-127

F

Fan Curve, 2-92
Fault Clr Mask, 2-114
Fault Configuration, 2-95, 2-160
Fault Queue, 2-93
Faults, 2-93
Feedback Select, 2-166
Flux Up, 2-97
Flux Up Mode, 2-97
Flying Start En, 2-98
Flying Start Gain, 2-98
Flying StartGain, 2-98
Fuses, 2-100

G

Group
Digital Inputs, 2-62, 2-63
Digital Outputs, 2-62, 2-79
Power Loss, 2-132
Speed References, 2-7

H

HIM Memory, 2-107
HIM Operations, 2-107
Human Interface Module
Language, 2-107
Password, 2-107
User Display, 2-108

I

I/O Wiring
Analog, 2-18
Digital, 2-61
Input Contactor
Start/Stop, 2-121
Input Devices, 2-108
Input Modes, 2-109
Input Power Conditioning, 2-110
Input/Output Ratings, 1-3

J

Jog, 2-110
Jog Mask, 2-114
Jog Owner, 2-127

L

Language, 2-111
Language Parameter, 2-111
Language Select, HIM, 2-107
Linking Parameters, 2-112
Local Mask, 2-114
Local Owner, 2-127
Logic Mask, 2-114
Low Voltage Directive, 2-53

M

Manual Preload, 2-27
Masks, 2-114
Max Speed, 2-175
Maximum frequency, 2-175
Min Mode/Max Mode, 2-178
MOP Mask, 2-114
MOP Owner, 2-127
Motor Cable Lengths, 2-51
Motor Nameplate, 2-117
Motor NP FLA, 2-117
Motor NP Hz, 2-117
Motor NP Power, 2-117
Motor NP Pwr Units, 2-117
Motor NP RPM, 2-117
Motor NP Volts, 2-117
Motor Overload, 2-118
Motor Start/Stop, 2-121
Mounting, 2-122

Mounting Dimensions, 1-7

N

Notch Filter, 2-122

O

Output Contactor
  Start/Stop, 2-121
Output Current, 2-124
Output Devices
  Contactors, 2-121, 2-124
  Output Reactor, 2-124
Output Frequency, 2-125
Output Power, 2-125
Output Reactor, 2-124
Output Voltage, 2-125
Overspeed, 2-126
Owners, 2-127

P

Parameter access level, 2-129
Parameters
  Accel Mask, 2-114
  Accel Owner, 2-127
  Alarm x Code, 2-9
  Analog In Hi, 2-12
  Analog In Lo, 2-12
  Analog In1 Value, 2-18
  Analog In2 Value, 2-18
  Analog Out Scale, 2-25
  Analog Out1 Sel, 2-21
  Analog Out2 Sel, 2-21
  Anlg In Config, 2-6, 2-9
  Anlg In Loss, 2-7
  Anlg In Sqr Root, 2-16
  Anlg Out Setpt, 2-26
  Auto Rstrt Delay, 2-29
  Auto Rstrt Tries, 2-29
  Bus Reg Gain, 2-46
  Bus Reg Mode A, B, 2-46
  Clear Fault Owner, 2-127
  Compensation, 2-152
  Current Lmt Sel, 2-9, 2-160
  Decel Mask, 2-114
  Decel Owner, 2-127
  Dig Out Setpt, 2-82
  Dig Outx Level, 2-80
  Dig Outx OffTime, 2-81
  Dig Outx OnTime, 2-81
  Digital Inx Sel, 2-62, 2-63
  Digital Outx Sel, 2-8, 2-78, 2-79
  Direction Mask, 2-114
  Direction Owner, 2-127
  Fault Clr Mask, 2-114
  Fault Config x, 2-160
  Feedback Select, 2-166
  Flying Start En, 2-98
  Flying Start Gain, 2-98
  Flying StartGain, 2-98
  Jog Mask, 2-114
  Jog Owner, 2-127
  Language, 2-111
  Local Mask, 2-114
  Local Owner, 2-127
  Logic Mask, 2-114
  MOP Mask, 2-114
  MOP Owner, 2-127
  PI Configuration, 2-151
  PI Deriv Time, 2-150
  PI Reference Sel, 2-151
  Power Loss Mode, 2-132
  Reference Mask, 2-114
  Reference Owner, 2-127
  Reset Meters, 2-154
  Speed Mode, 2-166
  Speed Ref A Sel, 2-7
  Start Mask, 2-114
  Start Owner, 2-127
  Stop Owner, 2-127
  Testpoint 1 Sel, 2-204
  Testpoint x Data, 2-204
  Torque Perf Mode, 2-205
  Torque Ref x Sel, 2-209
  Torque Setpoint2, 2-209
  Trim Out Select, 2-151
Password, HIM, 2-107
PET Ref Wave, 2-129
PI Config, 2-137
PI Configuration, 2-151
PI Control, 2-137
PI Deriv Time, 2-150
PI Error Meter, 2-137
PI Feedback Meter, 2-137
PI Feedback Sel, 2-137
PI Integral Time, 2-137
PI Output Meter, 2-137
PI Preload, 2-137
PI Prop Gain, 2-137
PI Ref Meter, 2-137
PI Reference Sel, 2-137, 2-151
PI Setpoint, 2-137

PI Status, 2-137
PI Upper/Lower Limit, 2-137
Power Loss, 2-130
Power Loss Group, 2-132
Power Loss Mode, 2-132
Power Up Marker, 2-95
Preset Frequency, 2-137
Process PI Loop, 2-137
PWM Frequency, 2-52, 2-89

R

Reference Mask, 2-114
Reference Owner, 2-127
Reference, Speed, 2-64, 2-68, 2-171
Reflected Wave, 2-152
Repeated Start/Stop, 2-121
Reset Meters, 2-154
Reset Run, 2-154
RFI Filter, 2-154

S

S Curve, 2-154
Scale Blocks, 2-157
Sensorless Vector, 2-207
Shear Pin, 2-160
Signal Loss, 2-17
Skip Frequency, 2-161
Sleep Mode, 2-163
Slip Compensation, 2-166
Specifications
  Agency Certification, 1-1
  Control, 1-2
  Derating Guidelines, 1-3
  Electrical, 1-2
  Encoder, 1-3
  Environment, 1-2
  Heat Dissipation, 1-3
  Input/Output Ratings, 1-3
  Protection, 1-1
Speed
  Control, 2-166
  Regulation, 2-166
Speed Feedback Filter, 2-170
Speed Mode, 2-166
Speed Ref A Sel, 2-7
Speed Reference, 2-64, 2-68, 2-171
Speed Reference Trim, 2-18, 2-174
Speed References Group, 2-7
Speed Regulation Mode, 2-177
Speed Units, 2-180
Speed/Torque Select, 2-177
Start Inhibits, 2-180
Start Mask, 2-114
Start Owner, 2-127
Start Permissives, 2-180
Start/Stop, Repeated, 2-121
Start-Up, 2-181
Stop Mode A, B, 2-201
Stop Modes, 2-201
Stop Owner, 2-127
Sum Mode, 2-179

T

Terminal Designations, 2-18
Test Points, 2-204
Testpoint 1 Sel, 2-204
Testpoint x Data, 2-204
Thermal Manager Protection, 2-88
Thermal Regulator, 2-204
Torque Performance Modes, 2-205
Torque Ref x Sel, 2-209
Torque Reference, 2-208
Torque Regulation Mode, 2-178
Torque Setpoint2, 2-209
Trim, 2-18
Trim Out Select, 2-151
Troubleshooting, 2-209

U

User Display, HIM, 2-108
User Sets, 2-210

V

Vector Control, 2-208
Vector Feedback, 2-166
Vector Speed Feedback, 2-166
Voltage class, 2-211
Voltage Tolerance, 2-212
Volts/Hertz, 2-205

W

Watts Loss, 2-213
Wiring Examples, 2-18
www, 1-1

Z

Zero Torque Mode, 2-179



SIDE VIEW



VIEW FROM DISCHARGE END



PLAN VIEW BELT ACCESS SIDE

REVISIONS

A: 20/3/07 ORIGINAL ISSUE 20/3/07

DRAWN	L.HARTLEY
CHECKED	L.HARTLEY
APPROVED	L.HARTLEY
DATE APP'D	21/3/07
SCALE	1:7.5
	DO NOT SCALE IF IN DOUBT ASK

WEB-TECH AUSTRALIA PTY. LTD.
A.C.N. 010 764 431
11 ELECTRONICS STREET EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA
P.O. BOX 4006 EIGHT MILE PLAINS, QUEENSLAND, 4113, AUSTRALIA
Phone +61-7-3841 2844 Fax +61-7-3841 0005

TITLE MODEL WT1200–600 OPEN WEIGH BELT FEEDER C/W SUPPORT STAND AND HOPPER GENERAL ARRANGEMENT

ALL DIMENSIONS IN MILLIMETRES UNLESS OTHERWISE SPECIFIED

SIZE	A1
DRAWING No. NUMBER	30830001
REV.	A
CUSTOMER	METROMOTION C/No. 3083
PROJECT	SAKATA RICE SNACKS
CAD FILE	30830001

This drawing and any information or descriptive matter set out hereon are the confidential and copyright property of WEB-TECH AUSTRALIA PTY. LTD. © and must not be disclosed, loaned, copied or used for manufacturing / tendering or for any other purpose without their written permission.

OPTIMUS CALIBRATION DATA

Customer : _____ Conveyor Designation : _____

Material : _____ Model : _____ Date : _____

Load Cell: _____ Tacho : _____ Data By : _____

Serial No: _____ Software Build : _____ Contract No : _____

SETUP MENU

1. System Configuration		Units of Measurement:			
		Belt Capacity			
		Resolution			
		Belt Length			
		Maximum Loading		kg/m	
2. Time & Date		Backlight			
		Brightness			
		Contrast			
		Date			
		Time			
3. PID Parameters	**1**	**Setpoint Origin / Status**			
	2	**Output Status**			
	3	**PID Parameters**			
		Prop Band		Reset Rate	
		Integral Lower Limit		Integral Upper Limit	
		Derivative Time			
		Feed Forward		Output Offset	
	5	**PID Mass Rate Filter**			
		Time Constant			
		Fast Track Threshold			
	6	**Volumetric Restart**			
		Restart Period			
		Restart Threshold			
4. Auto ZeroTracking		Auto Zero Tracking			
		Threshold			
		Delay		Period	
		Current Contribution			
5. Rate Deadband		Mass Rate Dead Band		Belt Capacity	
6. Rate Display Filters		Mass Rate Display Filter			
		Time Constant		Fast Track Threshold	
		Mass Rate Trend Filter			
		Time Constant		Fast Track Threshold	
8. Chute Level Control		None			
		Low			
		Mid			
		High			

OPTIMUS CALIBRATION DATA

I.O MENU

1. Current Loop Inputs

Loop 1 _____
Type is _____
Parameters
Master Capacity _____
Slave _____
Filtering
Loop Filter _____
Time Constant _____
Fast Track Threshold _____

Loop 2 _____
Loop 3 _____
Loop 4 _____
Loop 5 _____
Loop 6 _____
Loop 7 _____

2. Current Loop Outputs

Loop 1 _____
Type is _____
Filtering
Time Constant _____
Fast Track Threshold _____

Loop 2 _____
Type is _____
Filtering
Time Constant _____
Fast Track Threshold _____

3. Digital Inputs

Digital Input 1 _____
Digital Input 2 _____
Digital Input 3 _____

Digital Input 4 _____
Digital Input 5 _____
Digital Input 6 _____

4. Digital Outputs

Digital output 1 _____
Digital Output 2 _____
Digital output 3 _____
Emit Pulse Every _____
Pulse Width _____
Polarity _____
Digital output 4 _____
Digital output 5 _____
Digital output 6 _____

7. Load Cell & Tacho

Load Cell (No Load) _____
Load Cell (With Chains) _____
Tacho Freq @ 60Hz _____

CALIBRATION MENU

1. Calibration

Pulses Per Rev _____
Zero Calibration _____
Span Calibration _____
Calibration Target _____

Belt Revolutions _____
AZT _____
AZT (As found) _____
Belt Speed _____

WEB-TECH WEIGHFEEDER DESIGN DATA SHEET

CLIENT : **DATE :** _____

DESIGNATION : **MODEL** _____

CALIBRATION METHOD : BAR(S) / CHAIN

CALIBRATION BAR(S)

1. CALIBRATION BAR QTY AND TOTAL WEIGHT _____ = _____
2. IDLER PITCH _____
3. TOTAL WEIGH AREA _____ **metres**
4. EQUIVALENT LOADING/M WITH CAL BAR(S) (Item 1 x 1/Item 3) = _____
5. BELT SPEED _____ **m/s**
6. SIMULATED MASS RATE (Item 4 x Item 5 x 3600) = _____ **kg/hr**
7. BELT LENGTH _____ **metres**
8. No. OF BELT REVOLUTIONS FOR TEST _____
9. **TARGET WEIGHT (Item 4 x Item 7 x Item 8) =** _____ **kgs**

CALIBRATION CHAIN

1. WEIGHT OF CALIBRATION CHAIN PER STRAND _____ **kg/m**
2. No. OF STRANDS _____
3. TOTAL WEIGHT OF CALIBRATION CHAIN (Item 1 x Item 2) _____ **kg/m**
4. BELT LENGTH _____ **m**
5. No. OF BELT REVOLUTIONS FOR TEST _____
4. **TARGET WEIGHT (Item 3 x Item 4 x Item 5) =** _____ **kgs**

OPTIMUS CALIBRATION DATA

Customer :	**Metromotion**	Conveyor Designation :			
Material :	**Rice crackers**	Model :	**WT1200-600**	Date :	**18/05/2007**
Load Cell:	**RLHBB-5Kg**	Tacho :	**PXT500 x 4**	Data By :	**MW**
Serial No:		Software Build :	**Build 154**	Contract No :	**3083**

SETUP MENU

1. System Configuration		Units of Measurement:	**Kg/hr**		
		Belt Capacity	**500 Kg**		
		Resolution	**0.1 Kg**		
		Belt Length	**2.097 m**		
		Maximum Loading	**0.006** kg/m		
2. Time & Date		Backlight	**5min**		
		Brightness	**highest**		
		Contrast	**3**		
		Date	**18-May**		
		Time	**15:49**		
3. PID Parameters	**1**	**Setpoint Origin / Status**	**remote**		
	2	**Output Status**	**59.00%**		
	3	**PID Parameters**			
		Prop Band	**142.00%**	Reset Rate	**0.005 resets/sec**
		Integral Lower Limit	**-50.00%**	Integral Upper Limit	**50.00%**
		Derivative Time	**0.000**		
		Feed Forward	**1.000**	Output Offset	**0.000**
	5	**PID Mass Rate Filter**			
		Time Constant	**3s**		
		Fast Track Threshold	**100%**		
	6	**Volumetric Restart**			
		Restart Period	**10s**		
		Restart Threshold	**15.00%**		
4. Auto ZeroTracking		Auto Zero Tracking	**disabled**		
		Threshold	**10.00%**	=	
		Delay	**10 sec**	Period	**2 rev**
		Current Contribution	**0.000**		
5. Rate Deadband		Mass Rate Dead Band	**3.00%**	% of Belt Capacity	
6. Rate Display Filters		Mass Rate Display Filter	**enabled**		
		Time Constant	**20 sec**	Fast Track Threshold	**20%**
		Mass Rate Trend Filter	**enabled**		
		Time Constant	**10 sec**	Fast Track Threshold	**20%**
8. Chute Level Control		**Probe ON**	**Ratio**		
		None	**150.00%**		
		Low	**115.00%**		
		Mid	**85.00%**		
		High	**50.00%**		